



INSTRUMENT PROCESSING SHEET

Agency Florida Highway PatrolS/N 80-006638Florida Department of
Law EnforcementDate In 11/02/2018DI Completion Date 11/05/2018 Ship P/U H/D CMI EE

Intake Performed By <u>SQC</u> <input checked="" type="checkbox"/> Annual <input type="checkbox"/> Registration <input type="checkbox"/> Return from CMI / EE Visual Inspection: <input checked="" type="checkbox"/> Case <input checked="" type="checkbox"/> Handle <input checked="" type="checkbox"/> Keyboard <input checked="" type="checkbox"/> Dry Gas Shelf <input checked="" type="checkbox"/> Feet <input checked="" type="checkbox"/> Breath Tube <input checked="" type="checkbox"/> Ports <input checked="" type="checkbox"/> Screws Tight Other Equipment/ Accessories: <input checked="" type="checkbox"/> Power cord <input type="checkbox"/> Printer Cable <input checked="" type="checkbox"/> Static Bag <input type="checkbox"/> 12V DC Cable Notes: _____ _____ _____		Quality Checks Performed By <u>[Signature]</u> <input checked="" type="checkbox"/> Breath Tube Screen <input checked="" type="checkbox"/> Replace External O-Rings <input checked="" type="checkbox"/> Instrument Set Up Verified <input checked="" type="checkbox"/> R-Value <u>202</u> <input checked="" type="checkbox"/> Flow Verification (L/s) Flow Column # <u>ATP 103</u> 32 mm <u>0.148</u> (.139 - .169) 36 mm <u>0.164</u> (.156 - .190) 53 mm <u>0.242</u> (.228 - .278) 103 mm <u>0.500</u> (.447 - .547) <input checked="" type="checkbox"/> Barometric Pressure Check Gauge ID # <u>28662</u> <input checked="" type="checkbox"/> Stability Checks		Flow Calibration Performed By _____ Flow Column # _____ <input type="checkbox"/> 5L/min - 17mm <input type="checkbox"/> 15L/min - 53mm <input type="checkbox"/> 30L/min - 103mm <input type="checkbox"/> R-Value _____ <input type="checkbox"/> Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																
Final Release Date FDLE NOV 06 2018 Alcohol Testing Program		<table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>SD1021</td> <td>201707D 07/25/2019</td> </tr> <tr> <td>0.080</td> <td>DR1275</td> <td>201707E 07/25/2019</td> </tr> <tr> <td>0.200</td> <td>SD1013</td> <td>201707C 07/24/2019</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG805701 02/26/2020</td> </tr> </tbody> </table>		Simulator	Serial #	Lot #/Exp	0.050	SD1021	201707D 07/25/2019	0.080	DR1275	201707E 07/25/2019	0.200	SD1013	201707C 07/24/2019	0.080 DGS	N/A	AG805701 02/26/2020	Maintenance Performed By _____ <input type="checkbox"/> Battery Replacement <input type="checkbox"/> Dry Gas Regulator Replacement <input type="checkbox"/> Breath Tube Replacement <input type="checkbox"/> Other _____ Temperature Checks Performed By <u>[Signature]</u> <input checked="" type="checkbox"/> Lab Temp °C <u>21.2</u> External Digital Therm. ID#: <u>300503</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>SD1021</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>DR1275</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>SD1013</u>	
Simulator	Serial #	Lot #/Exp																		
0.050	SD1021	201707D 07/25/2019																		
0.080	DR1275	201707E 07/25/2019																		
0.200	SD1013	201707C 07/24/2019																		
0.080 DGS	N/A	AG805701 02/26/2020																		

Calibration Adjustment Performed By _____ Barometric Pressure Gauge _____ ID # _____				Department Inspection Performed By <u>[Signature]</u> Barometric Pressure ID# <u>28427</u> Gauge <u>1014</u> Instrument <u>1012</u> Mouth Alcohol Solution Lot # <u>2017-B</u> Acetone Stock Solution Lot # <u>2018-A</u>																																											
<table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> <th>Lot Number</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>				Simulator	Serial Number	Lot Number	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			<table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td>G11621</td> </tr> <tr> <td>Interferent</td> <td>DR3855</td> </tr> <tr> <td>0.050</td> <td>SD1021</td> </tr> <tr> <td>0.080</td> <td>DR1275</td> </tr> <tr> <td>0.200</td> <td>SD1013</td> </tr> </tbody> </table>				Simulator	Serial Number	0.000	G11621	Interferent	DR3855	0.050	SD1021	0.080	DR1275	0.200	SD1013
Simulator	Serial Number	Lot Number	Expiration																																												
0.000		N/A	N/A																																												
0.040																																															
0.100																																															
0.200																																															
0.300																																															
0.080 DGS	N/A																																														
Simulator	Serial Number																																														
0.000	G11621																																														
Interferent	DR3855																																														
0.050	SD1021																																														
0.080	DR1275																																														
0.200	SD1013																																														
<input type="checkbox"/> Post Calibration Adjustment Stability Checks <table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> <th>Lot Number</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>				Simulator	Serial Number	Lot Number	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Attachments <input checked="" type="checkbox"/> Form 41 <input type="checkbox"/> Post-Stability Checks <input checked="" type="checkbox"/> Stability Checks <input type="checkbox"/> Flow Calibration <input checked="" type="checkbox"/> Calibration Certificate <input checked="" type="checkbox"/> Form 40 <input type="checkbox"/> Calibration Adjustment <input checked="" type="checkbox"/> Other <u>Addtl DGS Cks</u>																							
Simulator	Serial Number	Lot Number	Expiration																																												
0.050																																															
0.080																																															
0.200																																															
0.080 DGS	N/A																																														

Notes/Suggested Service: <u>Keyboard arrived not connected. Upon connecting, keyboard did not work. Used alternate keyboard to complete inspection. Instructed AI to order a new keyboard for use with instrument. Instrument arrived with a complaint of ambient fails. Ran 10 DGS without incident. Ran pump for 10+ minutes. Reran 10 DG. No change and no ambient fails. Resumed regular protocols.</u>		<input checked="" type="checkbox"/> Instrument Complies with Chapter 11D-8, FAC <input type="checkbox"/> Instrument Does Not Comply with Chapter 11D-8, FAC <input checked="" type="checkbox"/> Return to/Place into Evidentiary Use <input type="checkbox"/> Remain Out of Evidentiary Use <input checked="" type="checkbox"/> Conduct an Agency Inspection Before Evidentiary Use	
<u>[Signature]</u> Tech Review / Date		<u>[Signature]</u> <u>11/6/18</u> Admin Review / Date	

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: FL HIGHWAY PATROL
Time of Inspection: 15:31

Date of Inspection: 11/05/2018

Serial Number: 80-006638
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:201707D Exp: 07/25/2019	0.08g/210L Test (g/210L) Lot#:201707E Exp: 07/25/2019	0.20g/210L Test (g/210L) Lot#:201707C Exp: 07/24/2019	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG805701 Exp: 02/26/2020
0.000	0.047	0.078	0.198	0.077
0.000	0.047	0.078	0.198	0.077
0.000	0.047	0.079	0.198	0.077
0.000	0.049	0.079	0.199	0.077
0.000	0.046	0.079	0.199	0.077
0.000	0.050	0.079	0.199	0.078
0.000	0.047	0.079	0.198	0.078
0.000	0.048	0.079	0.199	0.077
0.000	0.052	0.079	0.198	0.077
0.000	0.047	0.079	0.199	0.078

Standard Deviations	0.0018	0.0004	0.0005	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0007 Number of Simulators Used: 5

Remarks:

Noticed a high level of condensation in the 0.05g/210L simulator tubing. Suspect condensation affected the "bouncing" within the 0.05g/210L test results. Had to blow out tubing on subsequent instrument being inspected. *WBS*

11/5/18

SP

The above instrument complies () does not comply () with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Danielle M Bell

DANIELLE M BELL

Signature and Printed Name

11/05/2018
Date

11/6/18
JD

Stability Checks & 1 Control test #80-006638 FL Highway Patrol "1/5/18 ~~AMS~~

~~AMS~~

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006638
11/05/2018
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:09
Control Test	0.048	10:10
Air Blank	0.000	10:11
Control Test	0.048	10:11
Air Blank	0.000	10:12
Control Test	0.047	10:13
Air Blank	0.000	10:13
Control Test Stats		
Average	0.0477	
Std Dev	0.0006	
Rel Std Dev(%)	1.2112	

~~AMS~~
Operator's Signature

11/6/18
~~AMS~~

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006638
11/05/2018
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:21
Control Test	0.079	10:22
Air Blank	0.000	10:22
Control Test	0.080	10:23
Air Blank	0.000	10:23
Control Test	0.080	10:24
Air Blank	0.000	10:24
Control Test Stats		
Average	0.0797	
Std Dev	0.0006	
Rel Std Dev(%)	0.7247	

~~AMS~~
Operator's Signature

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006638
11/05/2018
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:26
Control Test	0.197	10:27
Air Blank	0.000	10:27
Control Test	0.200	10:28
Air Blank	0.000	10:29
Control Test	0.199	10:29
Air Blank	0.000	10:30
Control Test Stats		
Average	0.1987	
Std Dev	0.0015	
Rel Std Dev(%)	0.7689	

~~AMS~~
Operator's Signature

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006638
11/05/2018
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:31
Control Test	0.079	10:31
Air Blank	0.000	10:32
Control Test	0.078	10:32
Air Blank	0.000	10:33
Control Test	0.078	10:33
Air Blank	0.000	10:34
Control Test Stats		
Average	0.0783	
Std Dev	0.0006	
Rel Std Dev(%)	0.7370	

~~AMS~~
Operator's Signature

~~AMS~~
FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006638
11/05/2018
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:17
Control Test	0.079	10:18
Air Blank	0.000	10:18

~~AMS~~
Operator's Signature

SP



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2729 Fort Knox Blvd.
Bldg. 2, Suite 1300
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-006638, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-006638</u>	UNCERTAINTY* ±	
Owning Agency:	<u>FL HIGHWAY PATROL</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>11/05/2018</u>	0.080 g/ 210 L	0.005
Calibration Time:	<u>15:31</u>	0.200 g/ 210 L	0.008
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.
Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.
*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence (k=3).

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Thermometer temperatures are checked with NIST traceable Eutechnics 4400 digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the uses of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

11/05/2018

Date

DANIELLE M BELL,
Department Inspector

SP

FDLE/ATP Form 69 July 2018

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

11/6/18
D

Florida Department of Law Enforcement Alcohol Testing Program

AGENCY INSPECTION REPORT - INTOXILYZER 8000

Agency: FL HIGHWAY PATROL
Time of Inspection: 08:33

Date of Inspection: 11/05/2018

Serial Number: 80-006638
Software: 8100.27

Check or Test	YES	NO
Date and/or Time Adjusted		No
Diagnostic Check (Pre-Inspection): OK		No
Alcohol Free Subject Test: 0.000		No
Mouth Alcohol Test: Slope Not Met		No
Interferent Detect Test: Interferent Detect		No
Diagnostic Check (Post-Inspection): OK		No

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#: _____ Exp: _____	0.08g/210L Test (g/210L) Lot#: _____ Exp: _____	0.20g/210L Test (g/210L) Lot#: _____ Exp: _____	0.08 g/210L Dry Gas Std Test (g/210L) Lot#: _____ Exp: _____

Number of Simulators Used: _____

Remarks:
BYPASSED AI TO OPERATE INSTRUMENT. NOT A COMPLIANCE CHECK.

N/A Compliance
Not Determined *DMB* 11/5/18

SP

The above instrument complies () does not comply () with Chapter 11D-8, FAC.

I certify that I hold a valid Florida Department of Law Enforcement Agency Inspector Permit and that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Danielle M Bell

DANIELLE M BELL

Signature and Printed Name

11/05/2018
Date

11/6/18
JD

Additional Dry Gas Standard
Stability Checks
(Looking for AMS/Purge Fails)

80-006638

FL Highway Patrol

11/05/18 ~~AMS~~

Allowed pump to
run for 10+ minutes
between 1st & 2nd run of 10.
✓

DBS

11/05/2018
Software: 8100.27

DBS

Test	g/210L	Time
Air Blank	0.000	08:35
Control Test	0.077	08:35
Air Blank	0.000	08:36
Control Test	0.078	08:36
Air Blank	0.000	08:37
Control Test	0.079	08:37
Air Blank	0.000	08:37
Control Test	0.078	08:38
Air Blank	0.000	08:38
Control Test	0.078	08:39
Air Blank	0.000	08:39
Control Test	0.078	08:39
Air Blank	0.000	08:40
Control Test	0.079	08:40
Air Blank	0.000	08:41
Control Test	0.078	08:41
Air Blank	0.000	08:42
Control Test	0.078	08:42
Air Blank	0.000	08:42
Control Test	0.078	08:43
Air Blank	0.000	08:43
Control Test Stats		
Average	0.0781	
Std Dev	0.0006	
Rel Std Dev(%)	0.7268	

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006638
11/05/2018
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:02
Control Test	0.078	09:02
Air Blank	0.000	09:03
Control Test	0.079	09:03
Air Blank	0.000	09:04
Control Test	0.078	09:04
Air Blank	0.000	09:05
Control Test	0.078	09:05
Air Blank	0.000	09:06
Control Test	0.078	09:06
Air Blank	0.000	09:06
Control Test	0.079	09:07
Air Blank	0.000	09:07
Control Test	0.078	09:07
Air Blank	0.000	09:08
Control Test	0.079	09:08
Air Blank	0.000	09:09
Control Test	0.078	09:09
Air Blank	0.000	09:10
Control Test	0.078	09:10
Air Blank	0.000	09:11
Control Test Stats		
Average	0.0783	
Std Dev	0.0005	
Rel Std Dev(%)	0.6169	

SJP

~~AMS~~

Operator's Signature

~~AMS~~

Operator's Signature

11/6/18
JED



INSTRUMENT PROCESSING SHEET

Agency Florida Highway PatrolS/N 80-006638Florida Department of
Law EnforcementDate In 04/19/2018DI Completion Date 04/24/2018 Ship P/U H/D CMI EE

Intake Performed By <u>JLS</u> <input checked="" type="checkbox"/> Annual <input type="checkbox"/> Registration <input type="checkbox"/> Return from CMI / EE Visual Inspection: <input checked="" type="checkbox"/> Case <input checked="" type="checkbox"/> Handle <input checked="" type="checkbox"/> Keyboard <input checked="" type="checkbox"/> Dry Gas Shelf <input checked="" type="checkbox"/> Feet <input checked="" type="checkbox"/> Breath Tube <input checked="" type="checkbox"/> Ports <input checked="" type="checkbox"/> Screws Tight Other Equipment/ Accessories: <input checked="" type="checkbox"/> Power cord <input type="checkbox"/> Printer Cable <input checked="" type="checkbox"/> Static Bag <input type="checkbox"/> 12V DC Cable Notes: _____ _____ _____	Quality Checks Performed By <u>RWS</u> <input checked="" type="checkbox"/> Breath Tube Screen <input checked="" type="checkbox"/> Replace External O-Rings <input checked="" type="checkbox"/> Instrument Set Up Verified <input checked="" type="checkbox"/> R-Value <u>202</u> <input checked="" type="checkbox"/> Flow Verification (L/s) Flow Column # <u>ATP 102</u> 32 mm <u>0.160</u> (.139 - .169) 36 mm <u>0.179</u> (.156 - .190) 53 mm <u>0.250</u> (.228 - .278) 103 mm <u>0.503</u> (.447 - .547) <input checked="" type="checkbox"/> Barometric Pressure Check Gauge ID # <u>28427</u> <input checked="" type="checkbox"/> Stability Checks	Flow Calibration Performed By _____ Flow Column # _____ <input type="checkbox"/> 5L/min - 17mm <input type="checkbox"/> 15L/min - 53mm <input type="checkbox"/> 30L/min - 103mm <input type="checkbox"/> R-Value _____ <input type="checkbox"/> Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																																												
Final Release Date <div style="text-align: center; padding: 10px;"> FDLE APR 24 2018 Alcohol Testing Program </div>	<table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>G2835</td> <td>201707D 07/25/2019</td> </tr> <tr> <td>0.080</td> <td>G2840</td> <td>201707E 07/25/2019</td> </tr> <tr> <td>0.200</td> <td>SD1025</td> <td>201707C 07/24/2019</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG805702 02/26/2020</td> </tr> </tbody> </table>	Simulator	Serial #	Lot #/Exp	0.050	G2835	201707D 07/25/2019	0.080	G2840	201707E 07/25/2019	0.200	SD1025	201707C 07/24/2019	0.080 DGS	N/A	AG805702 02/26/2020	Maintenance Performed By _____ <input type="checkbox"/> Battery Replacement <input type="checkbox"/> Dry Gas Regulator Replacement <input type="checkbox"/> Breath Tube Replacement <input type="checkbox"/> Other _____ Temperature Checks Performed By <u>RWS</u> <input checked="" type="checkbox"/> Lab Temp °C <u>21.9</u> External Digital Therm. ID#: <u>300502</u> <input checked="" type="checkbox"/> 34°C +- .2 Serial #: <u>G2835</u> <input checked="" type="checkbox"/> 34°C +- .2 Serial #: <u>G2840</u> <input checked="" type="checkbox"/> 34°C +- .2 Serial #: <u>SD1025</u>																																													
Simulator	Serial #	Lot #/Exp																																																												
0.050	G2835	201707D 07/25/2019																																																												
0.080	G2840	201707E 07/25/2019																																																												
0.200	SD1025	201707C 07/24/2019																																																												
0.080 DGS	N/A	AG805702 02/26/2020																																																												
Calibration Adjustment Performed By _____ Barometric Pressure Gauge _____ ID # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> <th>Lot Number</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> <input type="checkbox"/> Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> <th>Lot Number</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>	Simulator	Serial Number	Lot Number	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial Number	Lot Number	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Department Inspection Performed By <u>RWS</u> Barometric Pressure ID# <u>28427</u> Gauge <u>1012</u> Instrument <u>1011</u> Mouth Alcohol Solution Lot # <u>2017-B</u> Acetone Stock Solution Lot # <u>2018-A</u> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td>G2880</td> </tr> <tr> <td>Interferent</td> <td>G2407</td> </tr> <tr> <td>0.050</td> <td>G2835</td> </tr> <tr> <td>0.080</td> <td>G2840</td> </tr> <tr> <td>0.200</td> <td>SD1025</td> </tr> </tbody> </table>	Simulator	Serial Number	0.000	G2880	Interferent	G2407	0.050	G2835	0.080	G2840	0.200	SD1025	Attachments <input checked="" type="checkbox"/> Form 41 <input type="checkbox"/> Post-Stability Checks <input checked="" type="checkbox"/> Stability Checks <input type="checkbox"/> Flow Calibration <input checked="" type="checkbox"/> Calibration Certificate <input type="checkbox"/> Form 40 <input type="checkbox"/> Calibration Adjustment <input type="checkbox"/> Other _____
Simulator	Serial Number	Lot Number	Expiration																																																											
0.000		N/A	N/A																																																											
0.040																																																														
0.100																																																														
0.200																																																														
0.300																																																														
0.080 DGS	N/A																																																													
Simulator	Serial Number	Lot Number	Expiration																																																											
0.050																																																														
0.080																																																														
0.200																																																														
0.080 DGS	N/A																																																													
Simulator	Serial Number																																																													
0.000	G2880																																																													
Interferent	G2407																																																													
0.050	G2835																																																													
0.080	G2840																																																													
0.200	SD1025																																																													
Notes/Suggested Service: _____ _____ _____ _____ _____	<input checked="" type="checkbox"/> Instrument Complies with Chapter 11D-8, FAC <input type="checkbox"/> Instrument Does Not Comply with Chapter 11D-8, FAC <input checked="" type="checkbox"/> Return to/Place into Evidentiary Use <input type="checkbox"/> Remain Out of Evidentiary Use <input checked="" type="checkbox"/> Conduct an Agency Inspection Before Evidentiary Use <div style="display: flex; justify-content: space-between; margin-top: 10px;"> <div style="text-align: center;"> <u>RWS</u> 4/24/18 Tech Review / Date </div> <div style="text-align: center;"> <u>J. Decker</u> 4/24/18 Admin Review / Date </div> </div>																																																													

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: FL HIGHWAY PATROL
Time of Inspection: 12:48

Date of Inspection: 04/24/2018

Serial Number: 80-006638
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:201707D Exp: 07/25/2019	0.08g/210L Test (g/210L) Lot#:201707E Exp: 07/25/2019	0.20g/210L Test (g/210L) Lot#:201707C Exp: 07/24/2019	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG805702 Exp: 02/26/2020
0.000	0.048	0.078	0.196	0.079
0.000	0.048	0.080	0.201	0.079
0.000	0.048	0.080	0.201	0.078
0.000	0.048	0.080	0.200	0.078
0.000	0.048	0.080	0.200	0.078
0.000	0.049	0.080	0.199	0.078
0.000	0.048	0.080	0.199	0.078
0.000	0.048	0.080	0.200	0.079
0.000	0.048	0.080	0.199	0.079
0.000	0.048	0.080	0.199	0.078

Standard Deviations	0.0003	0.0006	0.0014	0.0005
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0007 Number of Simulators Used: 5

Bgam

Remarks:

The above instrument complies () does not comply () with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Danielle M Bell

DANIELLE M BELL

Signature and Printed Name

04/24/2018
Date

*4/24/18
SO*

Stability Checks # 80-006638 FL Highway Patrol 4/24/18 ~~ADS~~

DS

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000
04/24/2018
Software: 8100.27

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000
04/24/2018
Software: 8100.27

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000
04/24/2018
Software: 8100.27

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000
04/24/2018
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:34
Control Test	0.048	10:35
Air Blank	0.000	10:35
Control Test	0.048	10:36
Air Blank	0.000	10:37
Control Test	0.048	10:37
Air Blank	0.000	10:38
Control Test Stats		
Average	0.0480	
Std Dev	0.0000	
Rel. Std Dev(%)	0.0000	

Test	g/210L	Time
Air Blank	0.000	10:40
Control Test	0.079	10:40
Air Blank	0.000	10:41
Control Test	0.080	10:42
Air Blank	0.000	10:42
Control Test	0.079	10:43
Air Blank	0.000	10:43
Control Test Stats		
Average	0.0793	
Std Dev	0.0006	
Rel. Std Dev(%)	0.7277	

Test	g/210L	Time
Air Blank	0.000	10:46
Control Test	0.199	10:46
Air Blank	0.000	10:47
Control Test	0.198	10:47
Air Blank	0.000	10:48
Control Test	0.199	10:48
Air Blank	0.000	10:49
Control Test Stats		
Average	0.1987	
Std Dev	0.0006	
Rel. Std Dev(%)	0.2906	

Test	g/210L	Time
Air Blank	0.000	10:51
Control Test	0.079	10:51
Air Blank	0.000	10:52
Control Test	0.079	10:52
Air Blank	0.000	10:53
Control Test	0.079	10:53
Air Blank	0.000	10:54
Control Test Stats		
Average	0.0790	
Std Dev	0.0000	
Rel. Std Dev(%)	0.0000	

ADS

Operator's Signature

4/24/18
ADS

ADS

Operator's Signature

ADS

Operator's Signature

ADS

Operator's Signature

ADS



Florida Department of Law Enforcement
 Alcohol Testing Program
 2729 Fort Knox Blvd.
 Bldg. 2, Suite 1300
 Tallahassee, FL 32308

Calibration Certificate

This is to certify the calibration of Intoxilyzer 8000 serial number 80-006638, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-006638</u>	UNCERTAINTY* ±
Owning Agency:	<u>FL HIGHWAY PATROL</u>	0.050 g/ 210 L
Calibration Date:	<u>04/24/2018</u>	0.080 g/ 210 L
Calibration Time:	<u>12:48</u>	0.200 g/ 210 L
		0.080 g/ 210 L Dry Gas Control
		0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.
 *Uncertainty is based on fleet-wide data and is expressed to a 99% level of confidence (k=3).

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Thermometer temperatures are checked with NIST traceable Eutechnics 4400 digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the uses of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

04/24/2018

Date

DANIELLE M BELL,
 Department Inspector

FDLE/ATP Form 69 March 2018
 Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

4/24/18
JD

DB