

Alcohol Testing Program - Instrument Processing Sheet

Agency: FL HIGHWAY PATROL

Instrument Serial Number: 80-007442

Date In: 6/15/2026

DI Completion Date: N/A

☐ Ship ☐ P/U ☐ H/D ☒ CMI ☐ EE

Intake By: <u>WKP</u> Date: <u>6/15/2026</u>		Quality Checks By: <u>WKP</u> Date: <u>6/18/2026</u>		Flow Adjustment By: _____																												
☒ Annual ☒ Dropped Off ☐ Registration ☐ Return from CMI / EE ☐ Training Instrument Visual Inspection ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/Accessories ☐ Power Cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes:		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value: <u>219</u> ☒ Flow Verification (L/s) Flow Column #: <u>ATP 105</u> 32 mm <u>0.152</u> (.139-.169) 36 mm <u>0.167</u> (.156-.190) 53 mm <u>0.246</u> (.228-.278) 103 mm <u>0.527</u> (.447-.547) ☒ Barometric Pressure Check Gauge ID #: <u>28427</u> Gauge: <u>1010</u> Instrument: <u>1013</u> ☒ Stability Checks		Flow Column #: _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value: _____ ☐ Post Adjustment Verification (L/S) Flow Column #: _____ 32 mm _____ (.139-.169) 36 mm _____ (.156-.190) 53 mm _____ (.228-.278) 103 mm _____ (.447-.547)																												
		<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot#/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP5088</td><td>202603A 3/3/2028</td></tr><tr><td>0.080</td><td>MP5089</td><td>202603B 3/3/2028</td></tr><tr><td>0.200</td><td>MP5090</td><td>202603D 3/4/2028</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>23825080A1 10/5/2027</td></tr></tbody></table>		Simulator	Serial #	Lot#/Exp	0.050	MP5088	202603A 3/3/2028	0.080	MP5089	202603B 3/3/2028	0.200	MP5090	202603D 3/4/2028	0.080 DGS	N/A	23825080A1 10/5/2027	<table border="1"><thead><tr><th>Maintenance By:</th><th>Date:</th></tr></thead><tbody><tr><td>☐ Battery Replacement</td><td></td></tr><tr><td>☐ Dry Gas Regulator Replacement</td><td></td></tr><tr><td>☐ Tank Sensor Tare</td><td></td></tr><tr><td>☐ Breath Tube Replacement</td><td></td></tr><tr><td>☐ Other:</td><td></td></tr></tbody></table>		Maintenance By:	Date:	☐ Battery Replacement		☐ Dry Gas Regulator Replacement		☐ Tank Sensor Tare		☐ Breath Tube Replacement		☐ Other:	
Simulator	Serial #	Lot#/Exp																														
0.050	MP5088	202603A 3/3/2028																														
0.080	MP5089	202603B 3/3/2028																														
0.200	MP5090	202603D 3/4/2028																														
0.080 DGS	N/A	23825080A1 10/5/2027																														
Maintenance By:	Date:																															
☐ Battery Replacement																																
☐ Dry Gas Regulator Replacement																																
☐ Tank Sensor Tare																																
☐ Breath Tube Replacement																																
☐ Other:																																
Optical Bench Adjustment By: _____		Department Inspection By: _____																														
Barometric Pressure Gauge: _____ ID#: _____		Barometric Pressure ID#: _____																														
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td></td><td></td><td></td></tr><tr><td>0.100</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.300</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Gauge: _____ Instrument: _____ Mouth Alcohol Solution Lot #: _____ Exp: _____ Acetone Stock Solution Lot #: _____ Exp: _____		
Simulator	Serial #	Lot #	Expiration																													
0.000		N/A	N/A																													
0.040																																
0.100																																
0.200																																
0.300																																
0.080 DGS	N/A																															
☐ Post Optical Bench Adjustment Stability Checks		<table border="1"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td></td></tr><tr><td>Interferent</td><td></td></tr><tr><td>0.050</td><td></td></tr><tr><td>0.080</td><td></td></tr><tr><td>0.200</td><td></td></tr></tbody></table>		Simulator	Serial Number	0.000		Interferent		0.050		0.080		0.200																		
Simulator	Serial Number																															
0.000																																
Interferent																																
0.050																																
0.080																																
0.200																																
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td></td><td></td><td></td></tr><tr><td>0.080</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Attachments ☐ Form 41 ☒ Stability Checks ☐ Calibration Certificate ☐ Optical Bench Adjustment										
Simulator	Serial #	Lot #	Expiration																													
0.050																																
0.080																																
0.200																																
0.080 DGS	N/A																															
Gauge ID #: _____ Gauge: _____ Instrument: _____		☐ Post-Stability Checks ☐ Flow Adjustment ☐ Form 40 ☒ Other: Return Material Authorization																														
Notes/Suggested Service:		☐ Instrument Complies with Chapter 11D-8, FAC ☒ Instrument Does Not Comply with Chapter 11D-8, FAC ☐ Return to/Place into Evidentiary Use ☒ Remain Out of Evidentiary Use Shayla Platt Digitally signed by Shayla Platt Date: 2026.06.30 12:49:45 -04'00' Shayla Platt Digitally signed by Shayla Platt Date: 2026.06.30 12:50:01 -04'00'																														

Stability Checks

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L
0.047 to 0.053	0.077 to 0.083	0.194 to 0.206	0.077 to 0.083
☒	☒	☒	☒ 50.003 of Wet

#2

FHP TRP B LAKE CITY
Intoxilyzer - Alcohol Analyzer
Model 8000
06/18/2026
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:45
Control Test	0.050	09:46
Air Blank	0.000	09:46
Control Test	0.050	09:47
Air Blank	0.000	09:47
Control Test	0.050	09:48
Air Blank	0.000	09:49
Control Test Stats		
Average	0.0500	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

menpi
Operator's Signature

FHP TRP B LAKE CITY
Intoxilyzer - Alcohol Analyzer
Model 8000
06/18/2026
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:40
Control Test	0.077	09:41
Air Blank	0.000	09:41
Control Test	0.077	09:42
Air Blank	0.000	09:43
Control Test	0.077	09:43
Air Blank	0.000	09:44
Control Test Stats		
Average	0.0770	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

menpi
Operator's Signature

FHP TRP B LAKE CITY
Intoxilyzer - Alcohol Analyzer
Model 8000
06/18/2026
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:34
Control Test	0.196	09:34
Air Blank	0.000	09:35
Control Test	0.196	09:36
Air Blank	0.000	09:36
Control Test	0.195	09:37
Air Blank	0.000	09:37
Control Test Stats		
Average	0.1957	
Std Dev	0.0006	
Rel Std Dev(%)	0.2951	

menpi
Operator's Signature

FHP TRP B LAKE CITY
Intoxilyzer - Alcohol Analyzer
Model 8000
06/18/2026
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:55
Control Test	0.000	09:55
Air Blank	0.000	09:56
Control Test	0.000	09:56
Air Blank	0.000	09:56
Control Test	0.000	09:57
Air Blank	0.000	09:57
Control Test Stats		
Average	0.0000	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

menpi
Operator's Signature

0.08 DGS

#1

FHP TRP B LAKE CITY
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007442
06/18/2026
Software: 8100.27

Performed troubleshooting on instrument connection with dry gas standard. Repeated test to ensure correct sample type was selected in the control testing menu.

WKP 6/18/2026

Test	g/210L	Time
Air Blank	0.000	09:51
Control Test	0.000	09:51
Air Blank	0.000	09:51
Control Test	0.000	09:52
Air Blank	0.000	09:52
Control Test	0.000	09:52
Air Blank	0.000	09:53
Control Test Stats		
Average	0.0000	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	


Operator's Signature

Return Material Authorization

Ship to:☒ CMI, Inc.☐ Enforcement ElectronicsShipment to repair facility authorized by: Javon Murphy on 6/18/2026Items Returned: ☒ Instrument ☐ Supplies ☐ Other Describe: _____Instrument Model: Intoxilyzer 8000 Serial Number: 80-007442

Bill To Address:

Attn: Javon Murphy
16106 SE Hwy 19
Cross City, FL 32628

Ship to Address:

FDLE Off-Site Mail Facility
c/o Florida Department of Law Enforcement
Alcohol Testing Program
813 B Lake Bradford Road
Tallahassee, FL 32304

Reason for Return:

Instrument is reading zero for the concentration when sampling from the dry gas standard.

I require an estimate **BEFORE** any repairs will be authorized and/or conductedPlease contact: Javon Murphy Phone #: 386-931-3427Email: javonmurphy@flhsmv.gov

ATP Contact Name: Wen-Chi Pierson

ATP Email: Wen-ChiPierson@fdle.state.fl.us