

Alcohol Testing Program - Instrument Processing Sheet

Agency: WINTER HAVEN PD

Instrument Serial Number: 80-001060

Date In: 5/4/2026

DI Completion Date: N/A

☒ Ship ☐ P/U ☐ H/D ☐ CMI ☒ EE

Intake By: <u>WKP</u> Date: <u>5/4/2026</u>		Quality Checks By: <u>KTS</u> Date: <u>5/5/2026</u>		Flow Adjustment By: _____																																	
☒ Annual ☐ Dropped Off ☐ Registration ☐ Return from CMI / EE ☐ Training Instrument Visual Inspection ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/Accessories ☐ Power Cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes:		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value: <u>216</u> ☒ Flow Verification (L/s) Flow Column #: <u>ATP102</u> 32 mm <u>0.152</u> (.139-.169) 36 mm <u>0.171</u> (.156-.190) 53 mm <u>0.242</u> (.228-.278) 103 mm <u>0.488</u> (.447-.547) ☒ Barometric Pressure Check Gauge ID #: <u>28427</u> Gauge: <u>1011</u> Instrument: <u>1012</u> ☒ Stability Checks		Flow Column #: _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value: _____ ☐ Post Adjustment Verification (L/S) Flow Column #: _____ 32 mm _____ (.139-.169) 36 mm _____ (.156-.190) 53 mm _____ (.228-.278) 103 mm _____ (.447-.547)																																	
						<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot#/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>MP5088</td> <td>202603A 3/3/2028</td> </tr> <tr> <td>0.080</td> <td>MP5089</td> <td>202603B 3/3/2028</td> </tr> <tr> <td>0.200</td> <td>MP5090</td> <td>202603D 3/4/2028</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>23825080A1 10/5/2027</td> </tr> </tbody> </table>		Simulator	Serial #	Lot#/Exp	0.050	MP5088	202603A 3/3/2028	0.080	MP5089	202603B 3/3/2028	0.200	MP5090	202603D 3/4/2028	0.080 DGS	N/A	23825080A1 10/5/2027	Maintenance By: _____ Date: _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Tank Sensor Tare ☐ Breath Tube Replacement ☐ Other:														
						Simulator	Serial #	Lot#/Exp																													
						0.050	MP5088	202603A 3/3/2028																													
						0.080	MP5089	202603B 3/3/2028																													
0.200	MP5090	202603D 3/4/2028																																			
0.080 DGS	N/A	23825080A1 10/5/2027																																			
Optical Bench Adjustment By: _____		Department Inspection By: <u>KTS</u>																																			
Barometric Pressure Gauge: _____ ID#: _____		Barometric Pressure ID#: _____																																			
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>		Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Gauge: _____ Instrument: _____ Mouth Alcohol Solution Lot #: _____ Exp: _____ Acetone Stock Solution Lot #: _____ Exp: _____							
Simulator	Serial #	Lot #	Expiration																																		
0.000		N/A	N/A																																		
0.040																																					
0.100																																					
0.200																																					
0.300																																					
0.080 DGS	N/A																																				
☐ Post Optical Bench Adjustment Stability Checks		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>		Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> </tr> <tr> <td>Interferent</td> <td></td> </tr> <tr> <td>0.050</td> <td></td> </tr> <tr> <td>0.080</td> <td></td> </tr> <tr> <td>0.200</td> <td></td> </tr> </tbody> </table>		Simulator	Serial Number	0.000		Interferent		0.050		0.080		0.200	
Simulator	Serial #	Lot #	Expiration																																		
0.050																																					
0.080																																					
0.200																																					
0.080 DGS	N/A																																				
Simulator	Serial Number																																				
0.000																																					
Interferent																																					
0.050																																					
0.080																																					
0.200																																					
Gauge ID #: _____ Gauge: _____ Instrument: _____		Attachments ☒ Form 41 ☒ Stability Checks ☐ Calibration Certificate ☐ Optical Bench Adjustment		☐ Post-Stability Checks ☐ Flow Adjustment ☐ Form 40 ☒ Other: Diagnostic Check, Return Material Authorization.																																	
Notes/Suggested Service: Instrument is DSP failing and will not go into ready mode. DVM check shows the span fluctuating for both 3 and 9 micron regions. KTS 5/12/26 *Tech Review: Typed original word that was scribbled through. KTS 5/20/26		☐ Instrument Complies with Chapter 11D-8, FAC ☒ Instrument Does Not Comply with Chapter 11D-8, FAC ☐ Return to/Place into Evidentiary Use ☒ Remain Out of Evidentiary Use ☐ Conduct an Agency Inspection Before Evidentiary Use																																			
		<table style="width: 100%;"> <tr> <td style="width: 50%; vertical-align: bottom;"> LeAndra Higginbotham Digitally signed by LeAndra Higginbotham Date: 2026.05.20 10:18:23 -04'00' </td> <td style="width: 50%; vertical-align: bottom;"> Wen-Chi Pierson Digitally signed by Wen-Chi Pierson Date: 2026.05.20 11:47:02 -04'00' </td> </tr> </table>				LeAndra Higginbotham Digitally signed by LeAndra Higginbotham Date: 2026.05.20 10:18:23 -04'00'	Wen-Chi Pierson Digitally signed by Wen-Chi Pierson Date: 2026.05.20 11:47:02 -04'00'																														
		LeAndra Higginbotham Digitally signed by LeAndra Higginbotham Date: 2026.05.20 10:18:23 -04'00'	Wen-Chi Pierson Digitally signed by Wen-Chi Pierson Date: 2026.05.20 11:47:02 -04'00'																																		
Tech Review Admin Review																																					

Stability Checks

0.050 g/210L 0.047 to 0.053 g/210L	0.080 g/210L 0.077 to 0.083 g/210L	0.200 g/210L 0.194 to 0.206 g/210L	DGS 0.080 g/210L 0.077 to 0.083 g/210L ≤0.003 g/210L of Wet																																																																																																																																																
WINTER HAVEN PD Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-001060 05/05/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>07:45</td></tr> <tr><td>Control Test</td><td>0.051</td><td>07:46</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>07:46</td></tr> <tr><td>Control Test</td><td>0.051</td><td>07:47</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>07:48</td></tr> <tr><td>Control Test</td><td>0.051</td><td>07:48</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>07:49</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0510</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </tbody> </table> Operator's Signature: <i>Katz</i>	Test	g/210L	Time	Air Blank	0.000	07:45	Control Test	0.051	07:46	Air Blank	0.000	07:46	Control Test	0.051	07:47	Air Blank	0.000	07:48	Control Test	0.051	07:48	Air Blank	0.000	07:49	Control Test Stats			Average	0.0510		Std Dev	0.0000		Rel Std Dev(%)	0.0000		WINTER HAVEN PD Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-001060 05/05/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>07:50</td></tr> <tr><td>Control Test</td><td>0.080</td><td>07:51</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>07:51</td></tr> <tr><td>Control Test</td><td>0.079</td><td>07:52</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>07:53</td></tr> <tr><td>Control Test</td><td>0.080</td><td>07:53</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>07:54</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0797</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.7247</td><td></td></tr> </tbody> </table> Operator's Signature: <i>Katz</i>	Test	g/210L	Time	Air Blank	0.000	07:50	Control Test	0.080	07:51	Air Blank	0.000	07:51	Control Test	0.079	07:52	Air Blank	0.000	07:53	Control Test	0.080	07:53	Air Blank	0.000	07:54	Control Test Stats			Average	0.0797		Std Dev	0.0006		Rel Std Dev(%)	0.7247		WINTER HAVEN PD Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-001060 05/05/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>07:56</td></tr> <tr><td>Control Test</td><td>0.200</td><td>07:57</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>07:57</td></tr> <tr><td>Control Test</td><td>0.198</td><td>07:58</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>07:58</td></tr> <tr><td>Control Test</td><td>0.199</td><td>07:59</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>08:00</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.1990</td><td></td></tr> <tr><td>Std Dev</td><td>0.0010</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.5025</td><td></td></tr> </tbody> </table> Operator's Signature: <i>Katz</i>	Test	g/210L	Time	Air Blank	0.000	07:56	Control Test	0.200	07:57	Air Blank	0.000	07:57	Control Test	0.198	07:58	Air Blank	0.000	07:58	Control Test	0.199	07:59	Air Blank	0.000	08:00	Control Test Stats			Average	0.1990		Std Dev	0.0010		Rel Std Dev(%)	0.5025		WINTER HAVEN PD Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-001060 05/05/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>07:42</td></tr> <tr><td>Control Test</td><td>0.082</td><td>07:42</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>07:42</td></tr> <tr><td>Control Test</td><td>0.082</td><td>07:43</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>07:43</td></tr> <tr><td>Control Test</td><td>0.082</td><td>07:44</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>07:44</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0820</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </tbody> </table> Operator's Signature: <i>Katz</i>	Test	g/210L	Time	Air Blank	0.000	07:42	Control Test	0.082	07:42	Air Blank	0.000	07:42	Control Test	0.082	07:43	Air Blank	0.000	07:43	Control Test	0.082	07:44	Air Blank	0.000	07:44	Control Test Stats			Average	0.0820		Std Dev	0.0000		Rel Std Dev(%)	0.0000	
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	07:45																																																																																																																																																	
Control Test	0.051	07:46																																																																																																																																																	
Air Blank	0.000	07:46																																																																																																																																																	
Control Test	0.051	07:47																																																																																																																																																	
Air Blank	0.000	07:48																																																																																																																																																	
Control Test	0.051	07:48																																																																																																																																																	
Air Blank	0.000	07:49																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0510																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	07:50																																																																																																																																																	
Control Test	0.080	07:51																																																																																																																																																	
Air Blank	0.000	07:51																																																																																																																																																	
Control Test	0.079	07:52																																																																																																																																																	
Air Blank	0.000	07:53																																																																																																																																																	
Control Test	0.080	07:53																																																																																																																																																	
Air Blank	0.000	07:54																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0797																																																																																																																																																		
Std Dev	0.0006																																																																																																																																																		
Rel Std Dev(%)	0.7247																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	07:56																																																																																																																																																	
Control Test	0.200	07:57																																																																																																																																																	
Air Blank	0.000	07:57																																																																																																																																																	
Control Test	0.198	07:58																																																																																																																																																	
Air Blank	0.000	07:58																																																																																																																																																	
Control Test	0.199	07:59																																																																																																																																																	
Air Blank	0.000	08:00																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.1990																																																																																																																																																		
Std Dev	0.0010																																																																																																																																																		
Rel Std Dev(%)	0.5025																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	07:42																																																																																																																																																	
Control Test	0.082	07:42																																																																																																																																																	
Air Blank	0.000	07:42																																																																																																																																																	
Control Test	0.082	07:43																																																																																																																																																	
Air Blank	0.000	07:43																																																																																																																																																	
Control Test	0.082	07:44																																																																																																																																																	
Air Blank	0.000	07:44																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0820																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: WINTER HAVEN PD
Time of Inspection: 07:05

Date of Inspection: 05/07/2026

Serial Number: 80-001060
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK		No	Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK		No	Barometric Pressure Sensor Check: OK		No
Alcohol Free Subject Test: 0.000		No	Mouth Alcohol Test: Slope Not Met		No
Interferent Detect Test: Interferent Detect		No	Diagnostic Check (Post-Inspection): OK		No

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#: Exp:	0.08g/210L Test (g/210L) Lot#: Exp:	0.20g/210L Test (g/210L) Lot#: Exp:	0.08 g/210L Dry Gas Std Test (g/210L) Lot#: Exp:

Standard Deviations				
---------------------	--	--	--	--

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: _____ Number of Simulators Used: _____

Remarks:

AMBIENT FAIL Non-compliance: .

Test* KTS 5/20/26

Attempt #1. Restarted ~~Test~~ Department
Inspection after turning fan on & clearing
area. *Katie* 5/7/26

The above instrument complies () does not comply (X) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Katie

KATIE T SPEARIN

Signature and Printed Name

05/07/2026
Date

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: WINTER HAVEN PD
Time of Inspection: 07:09

Date of Inspection: 05/07/2026

Serial Number: 80-001060
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK		No	Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK		No	Barometric Pressure Sensor Check: OK		No
Alcohol Free Subject Test: 0.000		No	Mouth Alcohol Test: Slope Not Met		No
Interferent Detect Test: Interferent Detect		No	Diagnostic Check (Post-Inspection): OK		No

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#: Exp:	0.08g/210L Test (g/210L) Lot#: Exp:	0.20g/210L Test (g/210L) Lot#: Exp:	0.08 g/210L Dry Gas Std Test (g/210L) Lot#: Exp:

Standard Deviations				
---------------------	--	--	--	--

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: _____ Number of Simulators Used: _____

Remarks:

AMBIENT FAIL AFTER TURNING FAN ON AND CLEARING AREA. Non-compliance: .

Attempt #2 - Repeated after turning fan on &
clearing area.

The above instrument complies () does not comply (X) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



KATIE T SPEARIN

Signature and Printed Name

05/07/2026
Date

WINTER HAVEN PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001060
05/07/2026
Software: 8100.27

DIAGNOSTICS

Voltage/Current Test	OK
RAM Test	OK
EEPROM Checksum Test	OK
Real Time Clock Test	OK
DSP Test	Fail
Analytical Stability Test	OK
Internal Printer Test	OK
Modem Test	OK
Temperature Regulation Test	OK

80-001060

[Signature]

5/7/26

Ran Diagnostic Check after
failed Department Inspections for
Ambient fail.

Return Material Authorization

Ship to:☐ CMI, Inc.☒ Enforcement ElectronicsShipment to repair facility authorized by: Michael Lango on 5/8/2026Items Returned: ☒ Instrument ☐ Supplies ☐ Other Describe: _____Instrument Model: Intoxilyzer 8000 Serial Number: 80-001060

Bill To Address:

Winter Haven PD

Michael Lango

125 N Lake Silver Dr NW

Winter Haven, FL 33881

Ship to Address:

FL Dept of Law Enforcement- ATP

813 B Lake Bradford Rd

Tallahassee, FL 32304

Reason for Return:

Ambient failed during pre-inspection airblank. Instrument then DSP failed with the span for 3 and 9 micron filters fluctuating.

I require an estimate **BEFORE** any repairs will be authorized and/or conductedPlease contact: Michael Lango Phone #: 863-291-5858Email: mlango@mywinterhaven.com

ATP Contact Name: Katie Spearin

ATP Email: KaitlynSpearin@FDLE.State.FL.US