

INSTRUMENT PROCESSING SHEET

Agency FHP - Cocoa S/N 80-00112
 Date In 7/15/16 Date Out 7/28/16 Ship P/U H/D CMI EE

RECEIVED
 JUL 29 2016
 FDLE
 Alcohol Testing Program

Intake Performed By [Signature]

Registration
 Annual
 Return from CMI
 Return from Enforcement Electronics
 Other _____

Visual Inspection:
 Case Handle
 Dry Gas Holder Feet
 Keyboard/Plug Back/Plugs
 Screws tight Breath Hose

Other Equipment:
 Power cord
 Printer Cable
 Other Static Bag

Notes: _____

Quality Checks Performed By [Signature]

Breath Tube Screen
 Replace O-Rings
 Instrument Set Up Verified
 R-Value 136
 Flow Verification (L/s)
 Flow Column # A7P102
 32mm 144 (.139 - .169)
 36mm 167 (.156 - .190)
 53mm 239 (.228 - .278)
 103mm 497 (.447 - .547)

Barometric Pressure Check
 Gauge ID # 28427

Stability Checks

Simulator	Serial #	Lot #/Exp
0.05	G4444	201507A 7/14/17
0.08	G6621	201601F 1/26/18
0.20	SD102	201505A 5/12/17
0.08 DGS	N/A	AG612405 5/31/18

Flow Calibration Performed By _____

Flow Calibration N/A
 Flow Calibration Complete
 Flow Column # _____
 5L/min - 17mm
 15L/min - 53mm
 30L/min - 103mm

R-Value _____
 Post Calibration Verification (L/s)
 Flow Column # _____
 32mm _____ (.139 - .169)
 36mm _____ (.156 - .190)
 53mm _____ (.228 - .278)
 103mm _____ (.447 - .547)

Maintenance Performed By _____

Battery Replacement
 Dry Gas Regulator Replacement
 Breath Tube Replacement
 Other _____

Suggested Service

Optical Bench Calibration Performed By _____

Optical Bench Calibration N/A
 Optical Bench Calibration Complete

Barometric Pressure Gauge ID # _____

Simulator	Serial Number	Lot Number	Expiration
0.000		N/A	N/A
0.040			
0.100			
0.200			
0.400			
0.080 DGS	N/A		

Post Calibration Stability Checks

Simulator	Serial Number	Lot Number	Expiration
0.05			
0.08			
0.20			
0.08 DGS	N/A		

Department Inspection Performed By [Signature]

Barometric Pressure ID# 28427 Gauge 1016 Instrument 1016

Mouth Alcohol Solution Lot # 2016-A
 Acetone Stock Solution Lot # 2016-B

Simulator	Serial Number
0.00	G2835
Interferent	G2840
0.05	G4444
0.08	G6621
0.20	SD102

Attachments

Form 41 Optical Bench Cal
 Pre-Stability Tests Post-Stability Tests
 Flow Calibration Other _____

Notes: QA/OC OK PGM 7/28/16

Instrument Complies with Chapter 11D-8, FAC
 Instrument Does Not Comply with Chapter 11D-8, FAC

Return to/Place into Evidentiary Use
 Remain Out of Evidentiary Use
 Conduct an Agency Inspection Before Evidentiary Use

[Signature]
 Quality Control Review

7/29/16
 Date

80-001112
 Stability Checks
 7/28/16

BSK

FL HIGHWAY PATROL
 Intoxilyzer - Alcohol Analyzer
 Model 8000 SN 80-001112
 07/28/2016
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	08:32
Control Test	0.082	08:32
Air Blank	0.000	08:33
Control Test	0.083	08:33
Air Blank	0.000	08:34
Control Test	0.082	08:34
Air Blank	0.000	08:35
Control Test Stats		
Average	0.0823	
Std Dev	0.0006	
Rel Std Dev(%)	0.7012	

BSM

DCS

Operator's Signature

FL HIGHWAY PATROL
 Intoxilyzer - Alcohol Analyzer
 Model 8000 SN 80-001112
 07/28/2016
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	08:51
Control Test	0.050	08:52
Air Blank	0.000	08:53
Control Test	0.049	08:53
Air Blank	0.000	08:54
Control Test	0.050	08:55
Air Blank	0.000	08:55
Control Test Stats		
Average	0.0497	
Std Dev	0.0005	
Rel Std Dev(%)	1.1625	

Operator's Signature

FL HIGHWAY PATROL
 Intoxilyzer - Alcohol Analyzer
 Model 8000 SN 80-001112
 07/28/2016
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:00
Control Test	0.203	09:01
Air Blank	0.000	09:02
Control Test	0.202	09:02
Air Blank	0.000	09:03
Control Test	0.201	09:04
Air Blank	0.000	09:04
Control Test Stats		
Average	0.2020	
Std Dev	0.0010	
Rel Std Dev(%)	0.4950	

Operator's Signature

Operator's Signature