



Alcohol Testing Program

INSTRUMENT PROCESSING SHEET

Agency Miami Dade Police Department S/N 80-000884Date In 01/09/2017 Date Out 01/09/2017 ☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EEDELLDELL

Intake Performed By <u>DELL</u> ☐ Registration ☒ Annual ☐ Return from CMI ☐ Return from Enforcement Electronics ☐ Other _____ Visual Inspection: <u>OK</u> Case <u>OK</u> Handle <u>OK</u> Dry Gas Holder <u>OK</u> Feet <u>OK</u> Keyboard/Plug <u>OK</u> Back/Plugs <u>OK</u> Screws tight <u>OK</u> Breath Hose Other Equipment: ☐ Power cord ☐ Printer Cable ☒ Other <u>ANTI STATIC BAG</u>		Quality Checks Performed By <u>DELL</u> ☒ Breath Tube Screen ☒ Replace O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>186</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP101</u> 32mm <u>128</u> (.139 - .169) 36mm <u>148</u> (.156 - .190) 53mm <u>218</u> (.228 - .278) 103mm <u>496</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>28663</u> ☒ Stability Checks		Flow Calibration Performed By <u>DELL</u> ☐ Flow Calibration N/A ☒ Flow Calibration Complete Flow Column # <u>ATP104</u> ☒ 5L/min - 17mm ☒ 15L/min - 53mm ☒ 30L/min - 103mm ☒ R-Value <u>181</u> ☒ Post Calibration Verification (L/s) Flow Column # <u>ATP101</u> 32mm <u>148</u> (.139 - .169) 36mm <u>167</u> (.156 - .190) 53mm <u>238</u> (.228 - .278) 103mm <u>500</u> (.447 - .547)																
Notes: _____ _____ _____		<table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.05</td> <td>SD3967</td> <td>201507A 07/14/2017</td> </tr> <tr> <td>0.08</td> <td>SD3968</td> <td>201601F 01/26/2018</td> </tr> <tr> <td>0.20</td> <td>SD3969</td> <td>201604C 04/05/2018</td> </tr> <tr> <td>0.08 DGS</td> <td>N/A</td> <td>AG605301 02/22/2018</td> </tr> </tbody> </table>		Simulator	Serial #	Lot #/Exp	0.05	SD3967	201507A 07/14/2017	0.08	SD3968	201601F 01/26/2018	0.20	SD3969	201604C 04/05/2018	0.08 DGS	N/A	AG605301 02/22/2018	Maintenance Performed By _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____ Suggested Service _____ _____	
Simulator	Serial #	Lot #/Exp																		
0.05	SD3967	201507A 07/14/2017																		
0.08	SD3968	201601F 01/26/2018																		
0.20	SD3969	201604C 04/05/2018																		
0.08 DGS	N/A	AG605301 02/22/2018																		

RECEIVED

JAN 18 2017

FDLE

Alcohol Testing Program

Optical Bench Calibration Performed By DELL
☒ Optical Bench Calibration N/A
☒ Optical Bench Calibration Complete
 Barometric Pressure Gauge 1030 ID # 68639

Simulator	Serial Number	Lot Number	Expiration
0.000	2235	N/A	N/A
0.040	2236	15108	08/18/2017
0.100	2237	15001	05/20/2017
0.200	2238	15104	05/27/2017
0.400	2239	15105	06/10/2017
0.080 DGS	N/A	03415080A1	03/05/2017

☒ Post Calibration Stability Checks

Simulator	Serial Number	Lot Number	Expiration
0.05	SD3967	201507A	07/14/2017
0.08	SD3968	201601F	01/26/2018
0.20	SD3969	201604C	04/05/2018
0.08 DGS	N/A	AG605301	02/22/2018

Department Inspection Performed By DELL
☒ Barometric Pressure 1030 Gauge
 ID # 28663 1030 Instrument

 Mouth Alcohol Solution Lot # 2016 A
 Acetone Stock Solution Lot # 2016 B

Simulator	Serial Number
0.00	SD3965
Interferent	SD3966
0.05	SD3967
0.08	SD3968
0.20	SD3969

Attachments
☒ Form 41
☒ Pre-Stability Tests
☒ Flow Calibration
☒ Optical Bench Cal
☒ Post-Stability Tests
☐ Other _____

Notes: E-MAILED 1/9/2017 DELL APPROVED
Recalibrated to bring values closer to nominal
QA/QC OK QSM 1/12/17
Brett Whiteland
 Quality Control Review
☒ Instrument Complies with Chapter 11D-8, FAC☐ Instrument Does Not Comply with Chapter 11D-8, FAC☒ Return to/Place Into Evidentiary Use☐ Remain Out of Evidentiary Use☒ Conduct an Agency Inspection Before Evidentiary Use
1/18/17
 Date

TYPE OF TEST	SERIAL NUMBER	AGENCY	DATE	PERFORMED BY
Post Stabilities	80-000844	Miami Dade Police Department	1/9/2017	<i>[Signature]</i>

0.05g/210L 0.047 to 0.053 ☒	0.08g/210L 0.077 to 0.083 ☒	0.20g/210L 0.194 to 0.206 ☒	DGS 0.08g/210L 0.077 to 0.083 ☒
MIAMI-DADE PD Intoxilyzer - Alcotest Analyzer Model 8000 01/09/2017 Software: 8100.27 Test g/210L Time Air Blank 0.000 18:44 Control Test 0.050 18:45 Air Blank 0.000 18:46 Control Test 0.050 18:46 Air Blank 0.000 18:47 Control Test 0.050 18:48 Air Blank 0.000 18:48 Control Test Stats Average 0.0500 Std Dev 0.0000 Rel Std Dev(%) 0.0000 Operator's Signature <i>[Signature]</i>	MIAMI-DADE PD Intoxilyzer - Alcotest Analyzer Model 8000 01/09/2017 Software: 8100.27 Test g/210L Time Air Blank 0.000 18:50 Control Test 0.079 18:50 Air Blank 0.000 18:51 Control Test 0.080 18:52 Air Blank 0.000 18:52 Control Test 0.080 18:53 Air Blank 0.000 18:53 Control Test Stats Average 0.0797 Std Dev 0.0006 Rel Std Dev(%) 0.7247 Operator's Signature <i>[Signature]</i>	MIAMI-DADE PD Intoxilyzer - Alcotest Analyzer Model 8000 01/09/2017 Software: 8100.27 Test g/210L Time Air Blank 0.000 18:54 Control Test 0.198 18:55 Air Blank 0.000 18:56 Control Test 0.199 18:56 Air Blank 0.000 18:57 Control Test 0.199 18:58 Air Blank 0.000 18:58 Control Test Stats Average 0.1987 Std Dev 0.0006 Rel Std Dev(%) 0.2906 Operator's Signature <i>[Signature]</i>	MIAMI-DADE PD Intoxilyzer - Alcotest Analyzer Model 8000 01/09/2017 Software: 8100.27 Test g/210L Time Air Blank 0.000 18:59 Control Test 0.080 18:59 Air Blank 0.000 19:00 Control Test 0.080 19:00 Air Blank 0.000 19:01 Control Test 0.080 19:01 Air Blank 0.000 19:02 Control Test Stats Average 0.0800 Std Dev 0.0000 Rel Std Dev(%) 0.0000 Operator's Signature <i>[Signature]</i>

Open
AK

734

TYPE OF TEST	SERIAL NUMBER	AGENCY	DATE	PERFORMED BY
Flow calibration	80-000884	Miami Dade Police Department	01/09/2017	<i>[Signature]</i>

MIAMI-DADE PD
 Intoxilyzer - Alcohol Analyzer
 Model 8000 SN 80-000884
 01/09/2017
 Software: 8100.27

 Flow Rate Calibration*****
 1: Rate (Liters/min) = 5
 SRT(Diff)) = 7.070
 2: Rate (Liters/min) = 15
 SRT(Diff)) = 11.789
 3: Rate (Liters/min) = 30
 SRT(Diff)) = 20.632
 Dependent Data Scale Factor = 100000 L/min
 Independent Data Scale Factor = 256
 Rounded Slope = 701
 Rounded Intercept = -706966
 Correlation = 0.99792

Egon

BK

TYPE OF TEST	SERIAL NUMBER	AGENCY	DATE	PERFORMED BY
Stabilities	80-000884	Miami Dade Police Department	01/09/2017	<i>HL</i>

0.05g/210L

0.047 to 0.053 ☒

0.08g/210L

0.077 to 0.083 ☒

0.20g/210L

0.194 to 0.206 ☒

DGS 0.08g/210L

0.077 to 0.083 ☒

MIAMI-DADE PD
Intoxilyzer - Alcotest Analyzer
Model 8000
01/09/2017
SN 80-000884
Software: 8100.27

Test g/210L Time

Air Blank 0.000 11:09
Control Test 0.048 11:10
Air Blank 0.000 11:10
Control Test 0.048 11:11
Air Blank 0.000 11:11
Control Test 0.049 11:12
Air Blank 0.000 11:13
Control Test Status
Average 0.0463
Std Dev 0.0006
Rel Std Dev(%) 1.1945

MIAMI-DADE PD
Intoxilyzer - Alcotest Analyzer
Model 8000
01/09/2017
SN 80-000884
Software: 8100.27

Test g/210L Time

Air Blank 0.000 11:14
Control Test 0.077 11:15
Air Blank 0.000 11:15
Control Test 0.078 11:16
Air Blank 0.000 11:17
Control Test 0.078 11:18
Air Blank 0.000 11:18
Control Test Status
Average 0.0777
Std Dev 0.0006
Rel Std Dev(%) 0.7434

MIAMI-DADE PD
Intoxilyzer - Alcotest Analyzer
Model 8000
01/09/2017
SN 80-000884
Software: 8100.27

Test g/210L Time

Air Blank 0.000 11:20
Control Test 0.195 11:21
Air Blank 0.000 11:21
Control Test 0.196 11:22
Air Blank 0.000 11:22
Control Test 0.196 11:23
Air Blank 0.000 11:23
Control Test Status
Average 0.1957
Std Dev 0.0006
Rel Std Dev(%) 0.2951

MIAMI-DADE PD
Intoxilyzer - Alcotest Analyzer
Model 8000
01/09/2017
SN 80-000884
Software: 8100.27

Test g/210L Time

Air Blank 0.000 11:23
Control Test 0.084 11:29
Air Blank 0.000 11:30
Control Test 0.084 11:30
Air Blank 0.000 11:31
Control Test 0.084 11:31
Air Blank 0.000 11:32
Control Test Status
Average 0.0840
Std Dev 0.0000
Rel Std Dev(%) 0.0000

Operator's Signature *HL*

Operator's Signature *HL*

Operator's Signature *HL*

Operator's Signature *HL*

HL

HL