

INSTRUMENT PROCESSING SHEET

Agency Jacksonville SO S/N 80-001278
 Date In 10/4/17 Date Out 10/25/17 Ship P/U H/D CMI EE

Intake Performed By [Signature]

Registration
 Annual
 Return from CMI
 Return from Enforcement Electronics
 Other _____

Visual Inspection:
OK Case OK Handle
OK Dry Gas Holder OK Feet
OK Keyboard/Plug OK Back/Plugs
OK Screws tight OK Breath Hose

Other Equipment:
 Power cord
 Printer Cable
 Other Static Bag

Notes: _____

Quality Checks Performed By [Signature]

Lab Temp °C 22.1
 Breath Tube Screen
 Replace External O-Rings
 Instrument Set Up Verified
 R-Value 23
 Flow Verification (L/s)
 Flow Column # ATP103
 32mm 142 (.139 - .169)
 36mm 165 (.156 - .190)
 53mm 234 (.228 - .278)
 103mm 502 (.447 - .547)

Barometric Pressure Check
 Gauge ID # 28427

Stability Checks

Simulator	Serial #	Lot #/Exp
0.05	<u>G2835</u>	<u>201707D</u> <u>7/25/19</u>
0.08	<u>DR1279</u>	<u>201707E</u> <u>7/25/19</u>
0.20	<u>SD1025</u>	<u>201707C</u> <u>7/24/19</u>
0.08 DGS	N/A	<u>AG626605</u> <u>9/22/18</u>

Flow Calibration Performed By _____

Flow Calibration N/A
 Flow Calibration Complete
 Flow Column # _____
 5L/min - 170mm
 15L/min - 53mm
 30L/min - 103mm
 R-Value _____
 Post Calibration Verification (L/s)
 Flow Column # _____
 32mm _____ (.139 - .169)
 36mm _____ (.156 - .190)
 53mm _____ (.228 - .278)
 103mm _____ (.447 - .547)

Maintenance Performed By _____

Battery Replacement
 Dry Gas Regulator Replacement
 Breath Tube Replacement
 Other _____

Quality Checks Cont. Performed By [Signature]

Simulator Temperatures °C
 External Digital Therm. ID#: 300504
 34°C +/- .2 Serial #: G2835
 34°C +/- .2 Serial #: DR1279
 34°C +/- .2 Serial #: SD1025

Calibration Adjustment Performed By _____

Calibration Adjustment N/A
 Calibration Adjustment Complete

Barometric Pressure Gauge _____ ID # _____

Simulator	Serial Number	Lot Number	Expiration
0.000		N/A	N/A
0.040			
0.100			
0.200			
0.300			
0.080 DGS	N/A		

Post Calibration Adjustment Stability Checks

Simulator	Serial Number	Lot Number	Expiration
0.05			
0.08			
0.20			
0.08 DGS	N/A		

Department Inspection Performed By [Signature]

Barometric Pressure 1014 Gauge
 ID# 28427 1014 Instrument

Mouth Alcohol Solution Lot # 2016-C
 Acetone Stock Solution Lot # 2017-A

Simulator	Serial Number
0.00	<u>G2880</u>
Interferent	<u>G2840</u>
0.05	<u>G2835</u>
0.08	<u>DR1279</u>
0.20	<u>SD1025</u>

Attachments

Form 41
 Pre-Stability Tests
 Flow Calibration
 Calibration Adjustment
 Post-Stability Tests
 Other _____

Notes/Suggested Service:
OK/AC OK GPM 10/25/2017

[Signature] 10/25/17
 Quality Control Review Date

Instrument Complies with Chapter 11D-8, FAC
 Instrument Does Not Comply with Chapter 11D-8, FAC

Return to/Place into Evidentiary Use
 Remain Out of Evidentiary Use
 Conduct an Agency Inspection Before Evidentiary Use

80-001278
 Stability Checks
 10/25/17

INTOXILYZER 8000
 Instrument Initialization
 06:52 10/25/2017

JACKSONVILLE SO
 Intoxilyzer - Alcohol Analyzer
 Model 8000 SN 80-001278
 10/25/2017
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	07:32
Control Test	0.202	07:33
Air Blank	0.000	07:33
Control Test	0.201	07:34
Air Blank	0.000	07:35
Control Test	0.201	07:35
Air Blank	0.000	07:36
Control Test Stats		
Average	0.2013	
Std Dev	0.0006	
Rel Std Dev(%)	0.2868	

Operator's Signature

JACKSONVILLE SO
 Intoxilyzer - Alcohol Analyzer
 Model 8000 SN 80-001278
 10/25/2017
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	07:27
Control Test	0.081	07:27
Air Blank	0.000	07:27
Control Test	0.081	07:28
Air Blank	0.000	07:28
Control Test	0.081	07:29
Air Blank	0.000	07:29
Control Test Stats		
Average	0.0810	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

DSS

Operator's Signature

10/25/17

JACKSONVILLE SO
 Intoxilyzer - Alcohol Analyzer
 Model 8000 SN 80-001278
 10/25/2017
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	07:37
Control Test	0.079	07:38
Air Blank	0.000	07:38
Control Test	0.079	07:39
Air Blank	0.000	07:39
Control Test	0.079	07:40
Air Blank	0.000	07:41
Control Test Stats		
Average	0.0790	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

JACKSONVILLE SO
 Intoxilyzer - Alcohol Analyzer
 Model 8000 SN 80-001278
 10/25/2017
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	07:42
Control Test	0.050	07:42
Air Blank	0.000	07:43
Control Test	0.049	07:44
Air Blank	0.000	07:44
Control Test	0.049	07:45
Air Blank	0.000	07:46
Control Test Stats		
Average	0.0493	
Std Dev	0.0006	
Rel Std Dev(%)	1.1703	

JGM

Operator's Signature