



INSTRUMENT PROCESSING SHEET

Agency Apopka PDS/N 80-000967

Florida Department of Law Enforcement

Date In 11/21/17DI Completion Date 12/4/17 Ship P/U H/D CMI EE

Intake Performed By <u>SP</u> <input checked="" type="checkbox"/> Annual <input type="checkbox"/> Registration <input checked="" type="checkbox"/> Return from CMI / <u>EE</u> Visual Inspection: <input checked="" type="checkbox"/> Case <input checked="" type="checkbox"/> Handle <input checked="" type="checkbox"/> Keyboard <input checked="" type="checkbox"/> Dry Gas Shelf <input checked="" type="checkbox"/> Feet <input checked="" type="checkbox"/> Breath Tube <input checked="" type="checkbox"/> Ports <input checked="" type="checkbox"/> Screws Tight Other Equipment/ Accessories: <input type="checkbox"/> Power cord <input type="checkbox"/> Printer Cable <input type="checkbox"/> Static Bag <input type="checkbox"/> 12V DC Cable Notes: _____ _____ _____	Quality Checks Performed By <u>SP</u> <input checked="" type="checkbox"/> Breath Tube Screen <input checked="" type="checkbox"/> Replace External O-Rings <input checked="" type="checkbox"/> Instrument Set Up Verified <input checked="" type="checkbox"/> R-Value <u>173</u> <input checked="" type="checkbox"/> Flow Verification (L/s) Flow Column # <u>ATP105</u> 32 mm <u>160</u> (.139 - .169) 36 mm <u>179</u> (.156 - .190) 53 mm <u>242</u> (.228 - .278) 103 mm <u>515</u> (.447 - .547) <input checked="" type="checkbox"/> Barometric Pressure Check Gauge ID # <u>28427</u> <input checked="" type="checkbox"/> Stability Checks <table border="1" style="width:100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td><u>G2835</u></td> <td><u>201707D</u> <u>7/25/19</u></td> </tr> <tr> <td>0.080</td> <td><u>DR1279</u></td> <td><u>201707E</u> <u>7/25/19</u></td> </tr> <tr> <td>0.200</td> <td><u>SD1025</u></td> <td><u>201707C</u> <u>7/24/19</u></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td><u>AG620605</u> <u>9/22/18</u></td> </tr> </tbody> </table>	Simulator	Serial #	Lot #/Exp	0.050	<u>G2835</u>	<u>201707D</u> <u>7/25/19</u>	0.080	<u>DR1279</u>	<u>201707E</u> <u>7/25/19</u>	0.200	<u>SD1025</u>	<u>201707C</u> <u>7/24/19</u>	0.080 DGS	N/A	<u>AG620605</u> <u>9/22/18</u>	Flow Calibration Performed By _____ Flow Column # _____ <input type="checkbox"/> 5L/min - 17mm <input type="checkbox"/> 15L/min - 53mm <input type="checkbox"/> 30L/min - 103mm <input type="checkbox"/> R-Value _____ <input type="checkbox"/> Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																												
Simulator	Serial #	Lot #/Exp																																																											
0.050	<u>G2835</u>	<u>201707D</u> <u>7/25/19</u>																																																											
0.080	<u>DR1279</u>	<u>201707E</u> <u>7/25/19</u>																																																											
0.200	<u>SD1025</u>	<u>201707C</u> <u>7/24/19</u>																																																											
0.080 DGS	N/A	<u>AG620605</u> <u>9/22/18</u>																																																											
Final Release Date <u>FDLE</u> <u>DEC 05 2017</u> Alcohol Testing Program	Maintenance Performed By _____ <input type="checkbox"/> Battery Replacement <input type="checkbox"/> Dry Gas Regulator Replacement <input type="checkbox"/> Breath Tube Replacement <input type="checkbox"/> Other _____	Temperature Checks Performed By <u>SP</u> <input checked="" type="checkbox"/> Lab Temp °C <u>22.2</u> External Digital Therm. ID#: <u>300504</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>G2835</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>DR1279</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>SD1025</u>																																																											
Calibration Adjustment Performed By _____ Barometric Pressure Gauge _____ ID # _____ <table border="1" style="width:100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> <th>Lot Number</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> <input type="checkbox"/> Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> <th>Lot Number</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>	Simulator	Serial Number	Lot Number	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial Number	Lot Number	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Department Inspection Performed By <u>SP</u> Barometric Pressure ID# <u>28427</u> Gauge <u>1020</u> Instrument <u>1021</u> Mouth Alcohol Solution Lot # <u>2016-C</u> Acetone Stock Solution Lot # <u>2016-B</u> <table border="1" style="width:100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td><u>G2880</u></td> </tr> <tr> <td>Interferent</td> <td><u>G2890</u></td> </tr> <tr> <td>0.050</td> <td><u>G2835</u></td> </tr> <tr> <td>0.080</td> <td><u>DR1279</u></td> </tr> <tr> <td>0.200</td> <td><u>SD1025</u></td> </tr> </tbody> </table>	Simulator	Serial Number	0.000	<u>G2880</u>	Interferent	<u>G2890</u>	0.050	<u>G2835</u>	0.080	<u>DR1279</u>	0.200	<u>SD1025</u>
Simulator	Serial Number	Lot Number	Expiration																																																										
0.000		N/A	N/A																																																										
0.040																																																													
0.100																																																													
0.200																																																													
0.300																																																													
0.080 DGS	N/A																																																												
Simulator	Serial Number	Lot Number	Expiration																																																										
0.050																																																													
0.080																																																													
0.200																																																													
0.080 DGS	N/A																																																												
Simulator	Serial Number																																																												
0.000	<u>G2880</u>																																																												
Interferent	<u>G2890</u>																																																												
0.050	<u>G2835</u>																																																												
0.080	<u>DR1279</u>																																																												
0.200	<u>SD1025</u>																																																												
Notes/Suggested Service: _____ _____ _____ _____ _____	<input checked="" type="checkbox"/> Instrument Complies with Chapter 11D-8, FAC <input type="checkbox"/> Instrument Does Not Comply with Chapter 11D-8, FAC <input checked="" type="checkbox"/> Return to/Place into Evidentiary Use <input type="checkbox"/> Remain Out of Evidentiary Use <input checked="" type="checkbox"/> Conduct an Agency Inspection Before Evidentiary Use <u>SPM 12/4/17</u> <u>JJ Debra</u> <u>12/5/17</u> Tech Review / Date Admin Review / Date																																																												

80-000967
 Stability Checks
 12/4/17

INTOXILYZER 8000
 Instrument Initialization
 08:31 12/04/2017

APOPKA P.D.
 Intoxilyzer - Alcohol Analyzer
 Model 8000 SN 80-000967
 12/04/2017
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:03
Control Test	0.077	09:04
Air Blank	0.000	09:05
Control Test	0.077	09:05
Air Blank	0.000	09:06
Control Test	0.077	09:07
Air Blank	0.000	09:07
Control Test Stats		
Average	0.0770	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

APOPKA P.D.
 Intoxilyzer - Alcohol Analyzer
 Model 8000 SN 80-000967
 12/04/2017
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:08
Control Test	0.194	09:09
Air Blank	0.000	09:10
Control Test	0.196	09:10
Air Blank	0.000	09:11
Control Test	0.196	09:12
Air Blank	0.000	09:12
Control Test Stats		
Average	0.1953	
Std Dev	0.0012	
Rel Std Dev(%)	0.5911	

Operator's Signature

APOPKA P.D.
 Intoxilyzer - Alcohol Analyzer
 Model 8000 SN 80-000967
 12/04/2017
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:14
Control Test	0.048	09:14
Air Blank	0.000	09:15
Control Test	0.048	09:15
Air Blank	0.000	09:16
Control Test	0.049	09:17
Air Blank	0.000	09:17
Control Test Stats		
Average	0.0483	
Std Dev	0.0006	
Rel Std Dev(%)	1.1945	

CPM

Operator's Signature

APOPKA P.D.
 Intoxilyzer - Alcohol Analyzer
 Model 8000 SN 80-000967
 12/04/2017
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	08:59
Control Test	0.079	09:00
Air Blank	0.000	09:00
Control Test	0.079	09:01
Air Blank	0.000	09:01
Control Test	0.078	09:01
Air Blank	0.000	09:02
Control Test Stats		
Average	0.0787	
Std Dev	0.0006	
Rel Std Dev(%)	0.7339	

DGS

Operator's Signature

12/5/17
 CP