

INSTRUMENT PROCESSING SHEET

Agency Dade City PD S/N 80-001073
 Date In 5/18/17 Date Out 5/25/17 Ship P/U H/D CMI EE

Intake Performed By <u>AP</u> <input type="checkbox"/> Registration <input checked="" type="checkbox"/> Annual <input type="checkbox"/> Return from CMI <input type="checkbox"/> Return from Enforcement Electronics <input type="checkbox"/> Other _____ Visual Inspection: <u>OK</u> Case <u>OK</u> Handle <u>OK</u> Dry Gas Holder <u>OK</u> Feet <u>OK</u> Keyboard/Plug <u>OK</u> Back/Plugs <u>OK</u> Screws tight <u>OK</u> Breath Hose Other Equipment: <input checked="" type="checkbox"/> Power cord <input type="checkbox"/> Printer Cable <input checked="" type="checkbox"/> Other <u>Static Bag</u> Notes: _____ _____ _____	Quality Checks Performed By <u>QWS</u> <input checked="" type="checkbox"/> Lab Temp °C <u>21.0</u> <input checked="" type="checkbox"/> Breath Tube Screen <input checked="" type="checkbox"/> Replace External O-Rings <input checked="" type="checkbox"/> Instrument Set Up Verified <input checked="" type="checkbox"/> R-Value <u>216</u> <input checked="" type="checkbox"/> Flow Verification (L/s) Flow Column # <u>ATP105</u> 32mm <u>0.164</u> (.139 - .169) 36mm <u>0.175</u> (.156 - .190) 53mm <u>0.246</u> (.228 - .278) 103mm <u>0.519</u> (.447 - .547) <input checked="" type="checkbox"/> Barometric Pressure Check Gauge ID # <u>28421</u> <input checked="" type="checkbox"/> Stability Checks <table border="1" style="width:100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.05</td> <td><u>SD3962</u></td> <td><u>201603D</u> <u>3/8/18</u></td> </tr> <tr> <td>0.08</td> <td><u>DR1279</u></td> <td><u>201611B</u> <u>11/15/18</u></td> </tr> <tr> <td>0.20</td> <td><u>DR3856</u></td> <td><u>201604C</u> <u>4/5/18</u></td> </tr> <tr> <td>0.08 DGS</td> <td>N/A</td> <td><u>AG626604</u> <u>9/22/18</u></td> </tr> </tbody> </table>	Simulator	Serial #	Lot #/Exp	0.05	<u>SD3962</u>	<u>201603D</u> <u>3/8/18</u>	0.08	<u>DR1279</u>	<u>201611B</u> <u>11/15/18</u>	0.20	<u>DR3856</u>	<u>201604C</u> <u>4/5/18</u>	0.08 DGS	N/A	<u>AG626604</u> <u>9/22/18</u>	Flow Calibration Performed By _____ <input checked="" type="checkbox"/> Flow Calibration N/A <input type="checkbox"/> Flow Calibration Complete Flow Column # _____ <input type="checkbox"/> 5L/min - 17mm <input type="checkbox"/> 15L/min - 53mm <input type="checkbox"/> 30L/min - 103mm <input type="checkbox"/> R-Value _____ <input type="checkbox"/> Post Calibration Verification Flow Column # _____ 32mm _____ (.139 - .169) 36mm _____ (.156 - .190) 53mm _____ (.228 - .278) 103mm _____ (.447 - .547) Maintenance Performed By _____ <input type="checkbox"/> Battery Replacement <input type="checkbox"/> Dry Gas Regulator Replacement <input type="checkbox"/> Breath Tube Replacement <input type="checkbox"/> Other _____ Quality Checks Cont. Performed By <u>SP</u> Simulator Temperatures °C External Digital Therm. ID#: <u>300505</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>SD3962</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>DR1279</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>DR3856</u>
Simulator	Serial #	Lot #/Exp															
0.05	<u>SD3962</u>	<u>201603D</u> <u>3/8/18</u>															
0.08	<u>DR1279</u>	<u>201611B</u> <u>11/15/18</u>															
0.20	<u>DR3856</u>	<u>201604C</u> <u>4/5/18</u>															
0.08 DGS	N/A	<u>AG626604</u> <u>9/22/18</u>															

RECEIVED
 MAY 30 2017
 FDLE
 Alcohol Testing Program

Calibration Adjustment Performed By _____ <input checked="" type="checkbox"/> Calibration Adjustment N/A <input type="checkbox"/> Calibration Adjustment Complete Barometric Pressure Gauge _____ ID # _____ <table border="1" style="width:100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> <th>Lot Number</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> <input type="checkbox"/> Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> <th>Lot Number</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.05</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.08</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.20</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.08 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>	Simulator	Serial Number	Lot Number	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial Number	Lot Number	Expiration	0.05				0.08				0.20				0.08 DGS	N/A			Department Inspection Performed By <u>QWS</u> <input checked="" type="checkbox"/> Barometric Pressure <u>1008</u> Gauge ID# <u>28421</u> <u>1007</u> Instrument Mouth Alcohol Solution Lot # <u>2016-C</u> Acetone Stock Solution Lot # <u>2017-A</u> <table border="1" style="width:100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.00</td> <td><u>G2880</u></td> </tr> <tr> <td>Interferent</td> <td><u>G2834</u></td> </tr> <tr> <td>0.05</td> <td><u>SD3962</u></td> </tr> <tr> <td>0.08</td> <td><u>DR1279</u></td> </tr> <tr> <td>0.20</td> <td><u>DR3856</u></td> </tr> </tbody> </table> Attachments <input checked="" type="checkbox"/> Form 41 <input checked="" type="checkbox"/> Pre-Stability Tests <input type="checkbox"/> Flow Calibration <input type="checkbox"/> Calibration Adjustment <input type="checkbox"/> Post-Stability Tests <input type="checkbox"/> Other _____	Simulator	Serial Number	0.00	<u>G2880</u>	Interferent	<u>G2834</u>	0.05	<u>SD3962</u>	0.08	<u>DR1279</u>	0.20	<u>DR3856</u>
Simulator	Serial Number	Lot Number	Expiration																																																										
0.000		N/A	N/A																																																										
0.040																																																													
0.100																																																													
0.200																																																													
0.300																																																													
0.080 DGS	N/A																																																												
Simulator	Serial Number	Lot Number	Expiration																																																										
0.05																																																													
0.08																																																													
0.20																																																													
0.08 DGS	N/A																																																												
Simulator	Serial Number																																																												
0.00	<u>G2880</u>																																																												
Interferent	<u>G2834</u>																																																												
0.05	<u>SD3962</u>																																																												
0.08	<u>DR1279</u>																																																												
0.20	<u>DR3856</u>																																																												

Notes/Suggested Service:
Please change level 2 menu password to something unique. QWS
LOC @ 5/25/17
J. Deham
 Date 5/24/17

Instrument Complies with Chapter 11D-8, FAC
 Instrument Does Not Comply with Chapter 11D-8, FAC
 Return to/Place into Evidentiary Use
 Remain Out of Evidentiary Use
 Conduct an Agency Inspection Before Evidentiary Use

Stability Checks # 80-001073 Dade City P.D. 5/25/17 *RMS*

RMS

DADE CITY PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001073
05/25/2017
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:30
Control Test	0.049	10:31
Air Blank	0.000	10:31
Control Test	0.049	10:32
Air Blank	0.000	10:32
Control Test	0.049	10:33
Air Blank	0.000	10:33
Control Test Stats		
Average	0.0490	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

RMS

Operator's Signature

JD

DADE CITY PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001073
05/25/2017
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:35
Control Test	0.077	10:35
Air Blank	0.000	10:36
Control Test	0.077	10:37
Air Blank	0.000	10:37
Control Test	0.078	10:38
Air Blank	0.000	10:38
Control Test Stats		
Average	0.0773	
Std Dev	0.0006	
Rel Std Dev(%)	0.7466	

RMS

Operator's Signature

DADE CITY PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001073
05/25/2017
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:40
Control Test	0.195	10:41
Air Blank	0.000	10:41
Control Test	0.194	10:42
Air Blank	0.000	10:43
Control Test	0.195	10:43
Air Blank	0.000	10:44
Control Test Stats		
Average	0.1947	
Std Dev	0.0006	
Rel Std Dev(%)	0.2956	

RMS

Operator's Signature

DADE CITY PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001073
05/25/2017
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:45
Control Test	0.079	10:46
Air Blank	0.000	10:46
Control Test	0.080	10:46
Air Blank	0.000	10:47
Control Test	0.079	10:47
Air Blank	0.000	10:48
Control Test Stats		
Average	0.0793	
Std Dev	0.0006	
Rel Std Dev(%)	0.7277	

RMS

Operator's Signature