



INSTRUMENT PROCESSING SHEET

Agency Nassau County SOS/N 80-001053

Florida Department of Law Enforcement

Date In 01/25/2019 DI Completion Date 1/31/19 Ship P/U H/D CMI EE

Intake Performed By <u>JA</u> <input checked="" type="checkbox"/> Annual <input type="checkbox"/> Registration <input type="checkbox"/> Return from CMI / EE Visual Inspection: <input checked="" type="checkbox"/> Case <input checked="" type="checkbox"/> Handle <input checked="" type="checkbox"/> Keyboard <input checked="" type="checkbox"/> Dry Gas Shelf <input checked="" type="checkbox"/> Feet <input checked="" type="checkbox"/> Breath Tube <input checked="" type="checkbox"/> Ports <input checked="" type="checkbox"/> Screws Tight Other Equipment/ Accessories: <input type="checkbox"/> Power cord <input type="checkbox"/> Printer Cable <input checked="" type="checkbox"/> Static Bag <input type="checkbox"/> 12V DC Cable Notes: <u>See note</u>	Quality Checks Performed By <u>TBK</u> <input checked="" type="checkbox"/> Breath Tube Screen <input checked="" type="checkbox"/> Replace External O-Rings <input checked="" type="checkbox"/> Instrument Set Up Verified <input checked="" type="checkbox"/> R-Value <u>190</u> <input checked="" type="checkbox"/> Flow Verification (L/s) Flow Column # <u>ATP102</u> 32 mm <u>.160</u> (.139 - .169) 36 mm <u>.171</u> (.156 - .190) 53 mm <u>.238</u> (.228 - .278) 103 mm <u>.488</u> (.447 - .547) <input checked="" type="checkbox"/> Barometric Pressure Check Gauge ID # <u>30793</u> <input checked="" type="checkbox"/> Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td><u>SD1021</u></td> <td><u>261707D</u> <u>7/25/19</u></td> </tr> <tr> <td>0.080</td> <td><u>DR1275</u></td> <td><u>201707E</u> <u>7/25/19</u></td> </tr> <tr> <td>0.200</td> <td><u>SD1013</u></td> <td><u>261707C</u> <u>7/24/19</u></td> </tr> <tr> <td>0.080 DGS</td> <td><u>N/A</u></td> <td><u>AG805701</u> <u>2/26/20</u></td> </tr> </tbody> </table>	Simulator	Serial #	Lot #/Exp	0.050	<u>SD1021</u>	<u>261707D</u> <u>7/25/19</u>	0.080	<u>DR1275</u>	<u>201707E</u> <u>7/25/19</u>	0.200	<u>SD1013</u>	<u>261707C</u> <u>7/24/19</u>	0.080 DGS	<u>N/A</u>	<u>AG805701</u> <u>2/26/20</u>	Flow Calibration Performed By _____ Flow Column # _____ <input type="checkbox"/> 5L/min - 17mm <input type="checkbox"/> 15L/min - 53mm <input type="checkbox"/> 30L/min - 103mm <input type="checkbox"/> R-Value _____ <input type="checkbox"/> Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																												
Simulator	Serial #	Lot #/Exp																																																											
0.050	<u>SD1021</u>	<u>261707D</u> <u>7/25/19</u>																																																											
0.080	<u>DR1275</u>	<u>201707E</u> <u>7/25/19</u>																																																											
0.200	<u>SD1013</u>	<u>261707C</u> <u>7/24/19</u>																																																											
0.080 DGS	<u>N/A</u>	<u>AG805701</u> <u>2/26/20</u>																																																											
Final Release Date <div style="text-align: center; font-weight: bold; font-size: 1.2em;">FDLE</div> <div style="text-align: center; font-weight: bold; font-size: 1.2em;">FEB 01 2019</div> <div style="text-align: center; font-weight: bold;">Alcohol Testing Program</div>	Maintenance Performed By _____ <input type="checkbox"/> Battery Replacement <input type="checkbox"/> Dry Gas Regulator Replacement <input type="checkbox"/> Breath Tube Replacement <input type="checkbox"/> Other _____	Temperature Checks Performed By <u>TBK</u> <input checked="" type="checkbox"/> Lab Temp °C <u>21.9</u> External Digital Therm. ID#: <u>300503</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>SD1021</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>DR1275</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>SD1013</u>																																																											
Calibration Adjustment Performed By _____ Barometric Pressure Gauge _____ ID # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> <th>Lot Number</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> <input type="checkbox"/> Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> <th>Lot Number</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>	Simulator	Serial Number	Lot Number	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial Number	Lot Number	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Department Inspection Performed By <u>TBK</u> Barometric Pressure ID# <u>28421</u> Gauge <u>1026</u> Instrument <u>1017</u> Mouth Alcohol Solution Lot # <u>2018-B</u> Acetone Stock Solution Lot # <u>2018-A</u> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td><u>011621</u></td> </tr> <tr> <td>Interferent</td> <td><u>DR3855</u></td> </tr> <tr> <td>0.050</td> <td><u>SD1021</u></td> </tr> <tr> <td>0.080</td> <td><u>DR1275</u></td> </tr> <tr> <td>0.200</td> <td><u>SD1013</u></td> </tr> </tbody> </table>	Simulator	Serial Number	0.000	<u>011621</u>	Interferent	<u>DR3855</u>	0.050	<u>SD1021</u>	0.080	<u>DR1275</u>	0.200	<u>SD1013</u>
Simulator	Serial Number	Lot Number	Expiration																																																										
0.000		N/A	N/A																																																										
0.040																																																													
0.100																																																													
0.200																																																													
0.300																																																													
0.080 DGS	N/A																																																												
Simulator	Serial Number	Lot Number	Expiration																																																										
0.050																																																													
0.080																																																													
0.200																																																													
0.080 DGS	N/A																																																												
Simulator	Serial Number																																																												
0.000	<u>011621</u>																																																												
Interferent	<u>DR3855</u>																																																												
0.050	<u>SD1021</u>																																																												
0.080	<u>DR1275</u>																																																												
0.200	<u>SD1013</u>																																																												
Notes/Suggested Service: <u>All diagnostic checks passed.</u>	<input checked="" type="checkbox"/> Instrument Complies with Chapter 11D-8, FAC <input type="checkbox"/> Instrument Does Not Comply with Chapter 11D-8, FAC <input checked="" type="checkbox"/> Return to/Place into Evidentiary Use <input type="checkbox"/> Remain Out of Evidentiary Use <input checked="" type="checkbox"/> Conduct an Agency Inspection Before Evidentiary Use																																																												
	<u>SP 1/31/19</u> Tech Review / Date	<u>J. P. [Signature]</u> <u>2/1/19</u> Admin Review / Date																																																											

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: NASSAU CO SO
Time of Inspection: 12:53

Date of Inspection: 01/31/2019

Serial Number: 80-001053
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:201707D Exp: 07/25/2019	0.08g/210L Test (g/210L) Lot#:201707E Exp: 07/25/2019	0.20g/210L Test (g/210L) Lot#:201707C Exp: 07/24/2019	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG805701 Exp: 02/26/2020
0.000	0.050	0.081	0.199	0.081
0.000	0.049	0.081	0.200	0.081
0.000	0.049	0.081	0.200	0.080
0.000	0.049	0.081	0.201	0.080
0.000	0.049	0.081	0.200	0.081
0.000	0.049	0.081	0.200	0.080
0.000	0.050	0.082	0.201	0.081
0.000	0.051	0.081	0.201	0.081
0.000	0.050	0.081	0.201	0.080
0.000	0.050	0.082	0.200	0.080

Standard Deviations	0.0006	0.0004	0.0006	0.0005
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0005 Number of Simulators Used: 5

Remarks:

SP

The above instrument complies () does not comply () with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Brett Kirkland

BRETT H KIRKLAND

Signature and Printed Name

01/31/2019
Date

2/1/19
JO

NASSAU CO SO
 Intoxilyzer - Alconol Analyzer
 Model: 8000 SN 80-001053
 01/31/2019
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:06
Control Test	0.080	11:06
Air Blank	0.000	11:07
Control Test	0.081	11:07
Air Blank	0.000	11:08
Control Test	0.081	11:08
Air Blank	0.000	11:08
Control Test Stats		11:08
Average	0.0807	
Std Dev	0.0006	
Rel. Std Dev(%)	0.7157	

NASSAU CO SO
 Intoxilyzer - Alconol Analyzer
 Model: 8000 SN 80-001053
 01/31/2019
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:01
Control Test	0.198	11:02
Air Blank	0.000	11:02
Control Test	0.199	11:03
Air Blank	0.000	11:04
Control Test	0.199	11:04
Air Blank	0.000	11:05
Control Test Stats		11:05
Average	0.1987	
Std Dev	0.0006	
Rel. Std Dev(%)	0.2906	

NASSAU CO SO
 Intoxilyzer - Alconol Analyzer
 Model: 8000 SN 80-001053
 01/31/2019
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:56
Control Test	0.081	10:57
Air Blank	0.000	10:58
Control Test	0.081	10:58
Air Blank	0.000	10:59
Control Test	0.081	10:59
Air Blank	0.000	11:00
Control Test Stats		11:00
Average	0.0810	
Std Dev	0.0000	
Rel. Std Dev(%)	0.0000	

NASSAU CO SO
 Intoxilyzer - Alconol Analyzer
 Model: 8000 SN 80-001053
 01/31/2019
 Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:51
Control Test	0.050	10:52
Air Blank	0.000	10:52
Control Test	0.050	10:53
Air Blank	0.000	10:54
Control Test	0.050	10:54
Air Blank	0.000	10:55
Control Test Stats		10:55
Average	0.0500	
Std Dev	0.0000	
Rel. Std Dev(%)	0.0000	

Brett Kirkland
 Operator's Signature

Brett Kirkland
 Operator's Signature

Brett Kirkland
 Operator's Signature

Brett Kirkland
 Operator's Signature

DGS

SP

90-001053
 Stabilities
 BK
 1/31/19

2/1/19
 JA



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2729 Fort Knox Blvd.
Bldg. 2, Suite 1300
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-001053, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-001053</u>	UNCERTAINTY* ±	
Owning Agency:	<u>NASSAU CO SO</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>01/31/2019</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>12:53</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.
Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.
*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence (k=3).

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.
Simulator temperatures are traceable to NIST. Thermometer temperatures are checked with NIST traceable Eutechnics 4400 digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the uses of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

01/31/2019 Date
Brett Kirkland
BRETT H KIRKLAND,
Department Inspector

FDLE/ATP Form 69 July 2018
Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

2/1/19

8

80-001053

Rec'd

1/25/19

JQ

DSP
Fail.
DM

SP

2/1/19
JQ