



# INSTRUMENT PROCESSING SHEET

Agency Auburndale PDS/N 80-001231Florida Department of  
Law EnforcementDate In 04/18/2019 DI Completion Date 04/19/2019 Ship  P/U  H/D  CMI  EE

<b>Intake</b> Performed By <u>DP</u> <input checked="" type="checkbox"/> Annual <input type="checkbox"/> Registration <input type="checkbox"/> Return from CMI / EE Visual Inspection: <input checked="" type="checkbox"/> Case <input checked="" type="checkbox"/> Handle <input checked="" type="checkbox"/> Keyboard <input checked="" type="checkbox"/> Dry Gas Shelf <input checked="" type="checkbox"/> Feet <input checked="" type="checkbox"/> Breath Tube <input checked="" type="checkbox"/> Ports <input checked="" type="checkbox"/> Screws Tight Other Equipment/ Accessories: <input checked="" type="checkbox"/> Power cord <input type="checkbox"/> Printer Cable <input type="checkbox"/> Static Bag <input type="checkbox"/> 12V DC Cable Notes: _____ _____ _____	<b>Quality Checks</b> Performed By <u>JD</u> <input checked="" type="checkbox"/> Breath Tube Screen <input checked="" type="checkbox"/> Replace External O-Rings <input checked="" type="checkbox"/> Instrument Set Up Verified <input checked="" type="checkbox"/> R-Value <u>121</u> <input checked="" type="checkbox"/> Flow Verification (L/s) Flow Column # <u>ATP-103</u> 32 mm <u>.140</u> (.139 - .169) 36 mm <u>.156</u> (.156 - .190) 53 mm <u>.230</u> (.228 - .278) 103 mm <u>.500</u> (.447 - .547) <input checked="" type="checkbox"/> Barometric Pressure Check Gauge ID # <u>28421</u> <input checked="" type="checkbox"/> Stability Checks	<b>Flow Calibration</b> Performed By _____ Flow Column # _____ <input type="checkbox"/> 5L/min - 17mm <input type="checkbox"/> 15L/min - 53mm <input type="checkbox"/> 30L/min - 103mm <input type="checkbox"/> R-Value _____ <input type="checkbox"/> Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																																											
<b>Final Release Date</b>  <div style="text-align: center;"> <b>FDLE</b>   <b>APR 22 2019</b>   <b>Alcohol Testing Program</b> </div>	<table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>SD1012</td> <td>201707D 07/25/2019</td> </tr> <tr> <td>0.080</td> <td>DR1279</td> <td>201707E 07/25/2019</td> </tr> <tr> <td>0.200</td> <td>SD1013</td> <td>201707C 07/24/2019</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG831804 11/14/2020</td> </tr> </tbody> </table>	Simulator	Serial #	Lot #/Exp	0.050	SD1012	201707D 07/25/2019	0.080	DR1279	201707E 07/25/2019	0.200	SD1013	201707C 07/24/2019	0.080 DGS	N/A	AG831804 11/14/2020	<b>Maintenance</b> Performed By _____ <input type="checkbox"/> Battery Replacement <input type="checkbox"/> Dry Gas Regulator Replacement <input type="checkbox"/> Breath Tube Replacement <input type="checkbox"/> Other _____ <b>Temperature Checks</b> Performed By <u>JD</u> <input checked="" type="checkbox"/> Lab Temp °C <u>22.0</u> External Digital Therm. ID#: <u>300503</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>SD1012</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>DR1279</u> <input checked="" type="checkbox"/> 34°C +/- .2 Serial #: <u>SD1013</u>																																												
Simulator	Serial #	Lot #/Exp																																																											
0.050	SD1012	201707D 07/25/2019																																																											
0.080	DR1279	201707E 07/25/2019																																																											
0.200	SD1013	201707C 07/24/2019																																																											
0.080 DGS	N/A	AG831804 11/14/2020																																																											
<b>Calibration Adjustment</b> Performed By _____ Barometric Pressure Gauge _____ ID # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> <th>Lot Number</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> <input type="checkbox"/> Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> <th>Lot Number</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>	Simulator	Serial Number	Lot Number	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial Number	Lot Number	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			<b>Department Inspection</b> Performed By <u>JD</u> Barometric Pressure ID# <u>28427</u> Gauge <u>1001</u> Instrument <u>1000</u> Mouth Alcohol Solution Lot # <u>2018-B</u> Acetone Stock Solution Lot # <u>2018-A</u> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td>G2408</td> </tr> <tr> <td>Interferent</td> <td>G2882</td> </tr> <tr> <td>0.050</td> <td>SD1012</td> </tr> <tr> <td>0.080</td> <td>DR1279</td> </tr> <tr> <td>0.200</td> <td>SD1013</td> </tr> </tbody> </table>	Simulator	Serial Number	0.000	G2408	Interferent	G2882	0.050	SD1012	0.080	DR1279	0.200	SD1013
Simulator	Serial Number	Lot Number	Expiration																																																										
0.000		N/A	N/A																																																										
0.040																																																													
0.100																																																													
0.200																																																													
0.300																																																													
0.080 DGS	N/A																																																												
Simulator	Serial Number	Lot Number	Expiration																																																										
0.050																																																													
0.080																																																													
0.200																																																													
0.080 DGS	N/A																																																												
Simulator	Serial Number																																																												
0.000	G2408																																																												
Interferent	G2882																																																												
0.050	SD1012																																																												
0.080	DR1279																																																												
0.200	SD1013																																																												
Notes/Suggested Service: <u>Please change the level 2 password to something unique. JD</u> _____ _____ _____ _____	<input checked="" type="checkbox"/> Instrument Complies with Chapter 11D-8, FAC <input type="checkbox"/> Instrument Does Not Comply with Chapter 11D-8, FAC <input checked="" type="checkbox"/> Return to/Place into Evidentiary Use <input type="checkbox"/> Remain Out of Evidentiary Use <input checked="" type="checkbox"/> Conduct an Agency Inspection Before Evidentiary Use  <u>Pran 4/22/19</u> <u>Booth Kurland 4/22/19</u> Tech Review / Date Admin Review / Date																																																												

# Florida Department of Law Enforcement Alcohol Testing Program

## DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: AUBURNDALE PD  
Time of Inspection: 12:56

Date of Inspection: 04/19/2019

Serial Number: 80-001231  
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:201707D Exp: 07/25/2019	0.08g/210L Test (g/210L) Lot#:201707E Exp: 07/25/2019	0.20g/210L Test (g/210L) Lot#:201707C Exp: 07/24/2019	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG831804 Exp: 11/14/2020
0.000	0.050	0.081	0.200	0.079
0.000	0.050	0.081	0.201	0.079
0.000	0.050	0.081	0.201	0.080
0.000	0.050	0.080	0.201	0.080
0.000	0.050	0.081	0.201	0.080
0.000	0.050	0.081	0.201	0.080
0.000	0.050	0.080	0.201	0.080
0.000	0.050	0.080	0.201	0.080
0.000	0.050	0.081	0.201	0.079
0.000	0.050	0.080	0.201	0.080

Standard Deviations	0.0000	0.0005	0.0003	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0003 Number of Simulators Used: 5

Remarks:

*JJM*  
*BK*  
*4/22/19*

The above instrument complies (  ) does not comply (  ) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

*Thomas J. Graham*

THOMAS J GRAHAM  
Signature and Printed Name

04/19/2019  
Date

80-001231

4/19/19  
JD

AUBURNDALE PD  
Intoxilyzer - Alcohol Analyzer  
Model 8000 SN 80-001231  
04/19/2019  
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	08:22
Control Test	0.051	08:23
Air Blank	0.000	08:23
Control Test	0.050	08:24
Air Blank	0.000	08:25
Control Test	0.050	08:25
Air Blank	0.000	08:26
Control Test Stats		
Average	0.0503	
Std Dev	0.0006	
Rel Std Dev(%)	1.1471	

989M

98K

4/22/19  
JD

Operator's Signature

AUBURNDALE PD  
Intoxilyzer - Alcohol Analyzer  
Model 8000 SN 80-001231  
04/19/2019  
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	08:27
Control Test	0.081	08:28
Air Blank	0.000	08:28
Control Test	0.081	08:29
Air Blank	0.000	08:30
Control Test	0.080	08:30
Air Blank	0.000	08:31
Control Test Stats		
Average	0.0807	
Std Dev	0.0006	
Rel Std Dev(%)	0.7157	

JD

Operator's Signature

AUBURNDALE PD  
Intoxilyzer - Alcohol Analyzer  
Model 8000 SN 80-001231  
04/19/2019  
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	08:32
Control Test	0.199	08:33
Air Blank	0.000	08:34
Control Test	0.199	08:34
Air Blank	0.000	08:35
Control Test	0.199	08:36
Air Blank	0.000	08:36
Control Test Stats		
Average	0.1990	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

JD

Operator's Signature

AUBURNDALE PD  
Intoxilyzer - Alcohol Analyzer  
Model 8000 SN 80-001231  
04/19/2019  
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	08:40
Control Test	0.079	08:41
Air Blank	0.000	08:41
Control Test	0.080	08:41
Air Blank	0.000	08:42
Control Test	0.080	08:42
Air Blank	0.000	08:43
Control Test Stats		
Average	0.0797	
Std Dev	0.0006	
Rel Std Dev(%)	0.7247	

DGS

JD

Operator's Signature



# Calibration Certificate

Florida Department of Law Enforcement  
Alcohol Testing Program  
2729 Fort Knox Blvd.  
Bldg. 2, Suite 1300  
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-001231, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-001231</u>	UNCERTAINTY* ±	
Owning Agency:	<u>AUBURNDALE PD</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>04/19/2019</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>12:56</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.  
\*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence (k=3).

### TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Thermometer temperatures are checked with NIST traceable Eutechnics 4400 digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the uses of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

04/19/2019

Date

  
**THOMAS J GRAHAM,**  
Department Inspector

FDLE/ATP Form 69 July 2018

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

*QJM*  
*BK*  
*4/22/19*