



Agency FDLE

S/N 80-000219

Date In 12/11/2020 DI Completion Date 2/19/2021

☐ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake	By RAW	Quality Checks	By RAW Date 02/18/2021																																																												
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>223</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP105</u> 32 mm <u>.152</u> (.139 - .169) 36 mm <u>.171</u> (.156 - .190) 53 mm <u>.250</u> (.228 - .278) 103 mm <u>.535</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>30793</u> ☒ Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>MP5088</td> <td>202010A 10-05-2022</td> </tr> <tr> <td>0.080</td> <td>MP5091</td> <td>202010B 10-05-2022</td> </tr> <tr> <td>0.200</td> <td>MP5090</td> <td>202010D 10-06-2022</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG011102 04-20-2022</td> </tr> </tbody> </table>	Simulator	Serial #	Lot #/Exp	0.050	MP5088	202010A 10-05-2022	0.080	MP5091	202010B 10-05-2022	0.200	MP5090	202010D 10-06-2022	0.080 DGS	N/A	AG011102 04-20-2022																																														
Simulator	Serial #	Lot #/Exp																																																													
0.050	MP5088	202010A 10-05-2022																																																													
0.080	MP5091	202010B 10-05-2022																																																													
0.200	MP5090	202010D 10-06-2022																																																													
0.080 DGS	N/A	AG011102 04-20-2022																																																													
Calibration Adjustment By _____		Flow Calibration By _____ Date _____ Flow Column # _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547) Maintenance By _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____ DI Temp. Checks By IS ☒ Lab Temp °C <u>20.73</u> External Digital Therm. ID#: <u>300505</u> ☒ 34°C +/- .2 Serial #: <u>MP5088</u> ☒ 34°C +/- .2 Serial #: <u>MP5091</u> ☒ 34°C +/- .2 Serial #: <u>MP5090</u>																																																													
Calibration Adjustment By _____ Barometric Pressure Gauge _____ ID # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr> <tr><td>0.040</td><td></td><td></td><td></td></tr> <tr><td>0.100</td><td></td><td></td><td></td></tr> <tr><td>0.200</td><td></td><td></td><td></td></tr> <tr><td>0.300</td><td></td><td></td><td></td></tr> <tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr> </tbody> </table> ☐ Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr><td>0.050</td><td></td><td></td><td></td></tr> <tr><td>0.080</td><td></td><td></td><td></td></tr> <tr><td>0.200</td><td></td><td></td><td></td></tr> <tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr> </tbody> </table>		Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Department Inspection By IS Barometric Pressure ID# <u>30793</u> Gauge <u>1018</u> Instrument <u>1017</u> Mouth Alcohol Solution Lot # <u>2020-A</u> Acetone Stock Solution Lot # <u>2020-A</u> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr><td>0.000</td><td>G11621</td></tr> <tr><td>Interferent</td><td>MP5087</td></tr> <tr><td>0.050</td><td>MP5088</td></tr> <tr><td>0.080</td><td>MP5091</td></tr> <tr><td>0.200</td><td>MP5090</td></tr> </tbody> </table> Attachments ☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment ☐ Post-Stability Checks ☐ Flow Calibration ☒ Form 40 ☐ Other _____		Simulator	Serial Number	0.000	G11621	Interferent	MP5087	0.050	MP5088	0.080	MP5091	0.200	MP5090
Simulator	Serial #	Lot #	Expiration																																																												
0.000		N/A	N/A																																																												
0.040																																																															
0.100																																																															
0.200																																																															
0.300																																																															
0.080 DGS	N/A																																																														
Simulator	Serial #	Lot #	Expiration																																																												
0.050																																																															
0.080																																																															
0.200																																																															
0.080 DGS	N/A																																																														
Simulator	Serial Number																																																														
0.000	G11621																																																														
Interferent	MP5087																																																														
0.050	MP5088																																																														
0.080	MP5091																																																														
0.200	MP5090																																																														
Notes/Suggested Service: <u>Form 40 uploaded before printing, reprinted from database. IS</u> <u>Instrument returned 12-11-2020, performing Department Inspection for 2021. IS</u> _____ _____ _____		☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use 2021.02.22 <u>Michael D. Haughey</u> 12:46:31 -05'00' 2021.03.0 <u>[Signature]</u> 11:07:22 -05'00' Tech Review / Date Admin Review / Date																																																													

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: FDLE

Time of Inspection: 10:41

Date of Inspection: 02/19/2021

Serial Number: 80-000219

Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test:			Diagnostic Check		
Interferent Detect	Yes		(Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202010A Exp: 10/05/2022	0.08g/210L Test (g/210L) Lot#:202010B Exp: 10/05/2022	0.20g/210L Test (g/210L) Lot#:202010D Exp: 10/06/2022	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG011102 Exp: 04/20/2022
0.000	0.049	0.079	0.200	0.078
0.000	0.049	0.079	0.201	0.078
0.000	0.049	0.080	0.200	0.078
0.000	0.049	0.080	0.201	0.078
0.000	0.049	0.080	0.201	0.078
0.000	0.049	0.080	0.201	0.078
0.000	0.049	0.080	0.200	0.078
0.000	0.049	0.080	0.201	0.078
0.000	0.050	0.080	0.201	0.078
0.000	0.049	0.080	0.201	0.078

Standard Deviations	0.0003	0.0004	0.0004	0.0000
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0002 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



ISRAEL SOTO

Signature and Printed Name

02/19/2021
Date

Stability Checks

JAE
 Model: 800
 12/18/2021
 Software: 800.07

Model: 800
 12/18/2021
 Software: 800.07

Model: 800
 12/18/2021
 Software: 800.07

Model: 800
 12/18/2021
 Software: 800.07

Test 3/210L Time
 Air Blank 0.007 14:39
 Control Test 0.078 14:40
 Air Blank 0.000 14:40
 Control Test 0.079 14:40
 Air Blank 0.000 14:41
 Control Test 0.079 14:41
 Air Blank 0.000 14:42
 Control Test 0.079 14:42
 Control Test Stats
 Average 0.0787
 Std Dev 0.0006
 Rel Std Dev(%) 0.75339

0.08 DGS

RAW

Operator's Signature

Test 3/210L Time
 Air Blank 0.000 14:40
 Control Test 0.078 14:40
 Air Blank 0.000 14:40
 Control Test 0.079 14:40
 Air Blank 0.000 14:41
 Control Test 0.079 14:41
 Air Blank 0.000 14:42
 Control Test 0.079 14:42
 Control Test Stats
 Average 0.0787
 Std Dev 0.0006
 Rel Std Dev(%) 0.75339

0.05

RAW

Operator's Signature

Test 3/210L Time
 Air Blank 0.000 14:40
 Control Test 0.078 14:40
 Air Blank 0.000 14:40
 Control Test 0.079 14:40
 Air Blank 0.000 14:41
 Control Test 0.079 14:41
 Air Blank 0.000 14:42
 Control Test 0.079 14:42
 Control Test Stats
 Average 0.0787
 Std Dev 0.0006
 Rel Std Dev(%) 0.75339

0.08 wet

RAW

Operator's Signature

Test 3/210L Time
 Air Blank 0.000 14:40
 Control Test 0.078 14:40
 Air Blank 0.000 14:40
 Control Test 0.079 14:40
 Air Blank 0.000 14:41
 Control Test 0.079 14:41
 Air Blank 0.000 14:42
 Control Test 0.079 14:42
 Control Test Stats
 Average 0.0787
 Std Dev 0.0006
 Rel Std Dev(%) 0.75339

0.20

RAW

Operator's Signature



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2729 Fort Knox Blvd.
Bldg. 2, Suite 1300
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000219, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000219</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>FDLE</u>	0.050 g/ 210 L	0.005
Calibration Date:	<u>02/19/2021</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>10:41</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Thermometer temperatures are checked with NIST traceable Eutechnics 4400 digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the uses of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Israel Soto
Digitally signed by Israel Soto
Date: 2021.02.22 09:27:01 -05'00'

02/19/2021

Date

ISRAEL SOTO,

Department Inspector

FDLE/ATP Form 69 January 2021

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

Florida Department of Law Enforcement Alcohol Testing Program

AGENCY INSPECTION REPORT - INTOXILYZER 8000

Agency: FDLE

Serial Number: 80-000219

Time of Inspection: 14:37

Date of Inspection: 02/18/2021

Software: 8100.27

Check or Test	YES	NO
Date and/or Time Adjusted		No
Diagnostic Check (Pre-Inspection): OK		No
Alcohol Free Subject Test: 0.000		No
Mouth Alcohol Test: Slope Not Met		No
Interferent Detect Test: Interferent Detect		No
Diagnostic Check (Post-Inspection): OK		No

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#: Exp:	0.08g/210L Test (g/210L) Lot#: Exp:	0.20g/210L Test (g/210L) Lot#: Exp:	0.08 g/210L Dry Gas Std Test (g/210L) Lot #: Exp:

Number of Simulators Used: _____

Remarks:

Not a compliance check

The above instrument complies (X) does not comply () with Chapter 11D-8, FAC.

I certify that I hold a valid Florida Department of Law Enforcement Agency Inspector Permit and that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



RICHARD A WILLIAMS

Signature and Printed Name

02/18/2021

Date

Return Material Authorization

Ship to:



CMI, Inc.



Enforcement Electronics

Shipment to repair facility authorized by: TJ Graham on 12/16/2021

Items Returned: Instrument ☒ Supplies ☐ Other ☐ Describe: _____

Instrument Model: Intoxilyzer 8000 Serial Number: 80-000219

Bill To Address:

Florida Department of Law Enforcement

Ship to Address:

Florida Department of Law Enforcement

Fort Myers Regional Operations Center

Attn: Alcohol Testing Program

4700 Terminal Drive, Suite 1

Fort Myers, FL 33907

Reason for Return:

Display screen will not illuminate. Instrument was having issues recognizing the agency codes but Becky from CMI was able to successfully re-load the forms on 12/16/2021.

Please choose one of the following options:

☐ 1. I _____, authorize all repairs.

☐ 2. I _____, authorize repairs up to \$_____.

☒ 3. I require an estimate **BEFORE** any repairs will be authorized and/ or conducted.

Please contact: Name: TJ Graham

Phone #: 850-631-1351

Email: ThomasGraham@fdle.state.fl.us

ATP Contact Name: Taylor Gutschow

ATP Email: Taylor Gutschow@fdle.state.fl.us



INSTRUMENT PROCESSING SHEET

Agency FDLE

S/N 80-000219

Florida Department of
Law Enforcement

Date In 12/15/2021

DI Completion Date _____

☒ Ship ☐ P/U ☐ H/D ☒ CMI ☐ EE

Intake	By	TDG	Quality Checks	By	Date	Flow Calibration	By	Date																		
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: <u>AI McCullough reported the instrument doesn't recognize their agency code</u> _____ _____ _____ _____ _____ _____			☐ Breath Tube Screen ☐ Replace External O-Rings ☐ Instrument Set Up Verified ☐ R-Value _____ ☐ Flow Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547) ☐ Barometric Pressure Check Gauge ID # _____ ☐ Stability Checks			Flow Column # _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																				
			<table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> </tr> </tbody> </table>			Simulator	Serial #	Lot #/Exp	0.050			0.080			0.200			0.080 DGS	N/A		Maintenance By <u>TDG</u> ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☒ Other <u>Reload forms</u>			DI Temp. Checks By _____ ☐ Lab Temp °C _____ External Digital Therm. ID#: _____ ☐ 34°C +/- .2 Serial #: _____ ☐ 34°C +/- .2 Serial #: _____ ☐ 34°C +/- .2 Serial #: _____		
Simulator	Serial #	Lot #/Exp																								
0.050																										
0.080																										
0.200																										
0.080 DGS	N/A																									

Calibration Adjustment	By	TDG	Department Inspection	By																																																												
Barometric Pressure Gauge _____ ID # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> ☐ Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>	Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A					Barometric Pressure ID# _____ Gauge _____ Instrument _____ Mouth Alcohol Solution Lot # _____ Acetone Stock Solution Lot # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> </tr> <tr> <td>Interferent</td> <td></td> </tr> <tr> <td>0.050</td> <td></td> </tr> <tr> <td>0.080</td> <td></td> </tr> <tr> <td>0.200</td> <td></td> </tr> </tbody> </table>	Simulator	Serial Number	0.000		Interferent		0.050		0.080		0.200		
Simulator	Serial #	Lot #	Expiration																																																													
0.000		N/A	N/A																																																													
0.040																																																																
0.100																																																																
0.200																																																																
0.300																																																																
0.080 DGS	N/A																																																															
Simulator	Serial #	Lot #	Expiration																																																													
0.050																																																																
0.080																																																																
0.200																																																																
0.080 DGS	N/A																																																															
Simulator	Serial Number																																																															
0.000																																																																
Interferent																																																																
0.050																																																																
0.080																																																																
0.200																																																																
Notes/Suggested Service: <u>Becky from CMI re-loaded the forms on 12/16/2021. The fluorescent display screen would not illuminate. Will send to CMI for repair (TDG)</u> _____ _____ _____ _____ _____			Attachments ☐ Form 41 ☐ Post-Stability Checks ☐ Stability Checks ☐ Flow Calibration ☐ Calibration Certificate ☐ Form 40 ☐ Calibration Adjustment ☒ Other <u>Form 51</u> ☐ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☐ Return to/Place into Evidentiary Use ☒ Remain Out of Evidentiary Use ☐ Conduct an Agency Inspection Before Evidentiary Use Tech Review / Date _____ Admin Review / Date _____																																																													