



Agency Liberty County Sheriff's Office

S/N 80-000960

Date In 5/3/2021

DI Completion Date 5/5/2021

☐ Ship ☒ P/U ☐ H/D ☐ CMI ☐ EE

Intake ☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____	Quality Checks By <u>IS</u> Date <u>05-03-2021</u> ☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>206</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP-105</u> 32 mm <u>0.167</u> (.139 - .169) 36 mm <u>0.187</u> (.156 - .190) 53 mm <u>0.261</u> (.228 - .278) 103 mm <u>0.542</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>28427</u> ☒ Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> <tr> <td>0.050</td> <td>MP5088</td> <td>202010A 10-05-2022</td> </tr> <tr> <td>0.080</td> <td>MP5089</td> <td>202010B 10-05-2022</td> </tr> <tr> <td>0.200</td> <td>MP5090</td> <td>202010D 10-06-2022</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG011102 04-20-2022</td> </tr> </table>	Simulator	Serial #	Lot #/Exp	0.050	MP5088	202010A 10-05-2022	0.080	MP5089	202010B 10-05-2022	0.200	MP5090	202010D 10-06-2022	0.080 DGS	N/A	AG011102 04-20-2022	Flow Calibration By _____ Date _____ Flow Column # _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547) Maintenance By <u>IS</u> ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☒ Other <u>Tank Sensor Tare</u> DI Temp. Checks By <u>IS</u> ☒ Lab Temp °C <u>21.68</u> External Digital Therm. ID#: <u>300505</u> ☒ 34°C +/- .2 Serial #: <u>MP5088</u> ☒ 34°C +/- .2 Serial #: <u>MP5089</u> ☒ 34°C +/- .2 Serial #: <u>MP5090</u>																																														
Simulator	Serial #	Lot #/Exp																																																													
0.050	MP5088	202010A 10-05-2022																																																													
0.080	MP5089	202010B 10-05-2022																																																													
0.200	MP5090	202010D 10-06-2022																																																													
0.080 DGS	N/A	AG011102 04-20-2022																																																													
Calibration Adjustment By _____ Barometric Pressure Gauge _____ ID # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </table> ☐ Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </table>		Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Department Inspection By <u>IS</u> Barometric Pressure ID# <u>26932</u> Gauge <u>1014</u> Instrument <u>1013</u> Mouth Alcohol Solution Lot # <u>2021-A</u> Acetone Stock Solution Lot # <u>2020-A</u> <table border="1" style="width:100%; border-collapse: collapse;"> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> <tr> <td>0.000</td> <td>MP5086</td> </tr> <tr> <td>Interferent</td> <td>MP5087</td> </tr> <tr> <td>0.050</td> <td>MP5088</td> </tr> <tr> <td>0.080</td> <td>MP5089</td> </tr> <tr> <td>0.200</td> <td>MP5090</td> </tr> </table> Attachments ☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment ☐ Post-Stability Checks ☐ Flow Calibration ☐ Form 40 ☐ Other _____		Simulator	Serial Number	0.000	MP5086	Interferent	MP5087	0.050	MP5088	0.080	MP5089	0.200	MP5090
Simulator	Serial #	Lot #	Expiration																																																												
0.000		N/A	N/A																																																												
0.040																																																															
0.100																																																															
0.200																																																															
0.300																																																															
0.080 DGS	N/A																																																														
Simulator	Serial #	Lot #	Expiration																																																												
0.050																																																															
0.080																																																															
0.200																																																															
0.080 DGS	N/A																																																														
Simulator	Serial Number																																																														
0.000	MP5086																																																														
Interferent	MP5087																																																														
0.050	MP5088																																																														
0.080	MP5089																																																														
0.200	MP5090																																																														
Notes/Suggested Service: _____ <u>Stability Checks done 5-5-2021. IS</u> _____ _____ _____ _____ _____ _____ _____		☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use David Eliezer Reyes-Rivera Digitally signed by David Eliezer Reyes-Rivera Date: 2021.05.06 13:36:14 -04'00' 2021.05.06 22:11:09 -04'00' Tech Review / Date _____ Admin Review / Date _____																																																													

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: LIBERTY COUNTY SO
Time of Inspection: 12:14

Date of Inspection: 05/05/2021

Serial Number: 80-000960
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202010A Exp: 10/05/2022	0.08g/210L Test (g/210L) Lot#:202010B Exp: 10/05/2022	0.20g/210L Test (g/210L) Lot#:202010D Exp: 10/06/2022	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG011102 Exp: 04/20/2022
0.000	0.050	0.080	0.201 / 0.201	0.080
0.000	0.051	0.080	0.199 / 0.202	0.080
0.000	0.051	0.080	0.198 / 0.202	0.079
0.000	0.050	0.081	0.196 / 0.201	0.079
0.000	0.051	0.080	0.194 / 0.202	0.078
0.000	0.051	0.080	0.192 / 0.202	0.079
0.000	0.051	0.080	0.191 / 0.202	0.079
0.000	0.051	0.081	0.189 / 0.201	0.079
0.000	0.051	0.080	0.187 / 0.202	0.078
0.000	0.051	0.081	0.186 / 0.202	0.079

Standard Deviations	0.0004	0.0004	0.0051 / 0.0004	0.0006
---------------------	--------	--------	-----------------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0004 Number of Simulators Used: 5

Remarks:

20: Control Outside Tolerance SIM PWR CABLE CAME LOOSE.

Tightened power cable, allowed simulator to reheat and repeated 0.200 test

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Israel Soto

ISRAEL SOTO

Signature and Printed Name

05/05/2021
Date

Stability checks

LIBERTY COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000960
05/05/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:25
Control Test	0.050	09:26
Air Blank	0.000	09:26
Control Test	0.050	09:27
Air Blank	0.000	09:28
Control Test	0.050	09:28
Air Blank	0.000	09:29
Control Test Stats		
Average	0.0500	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

LIBERTY COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000960
05/05/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:32
Control Test	0.080	09:33
Air Blank	0.000	09:33
Control Test	0.079	09:34
Air Blank	0.000	09:34
Control Test	0.079	09:35
Air Blank	0.000	09:36
Control Test Stats		
Average	0.0793	
Std Dev	0.0006	
Rel Std Dev(%)	0.7277	

wet

Operator's Signature

LIBERTY COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000960
05/05/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:37
Control Test	0.203	09:37
Air Blank	0.000	09:38
Control Test	0.201	09:39
Air Blank	0.000	09:39
Control Test	0.201	09:40
Air Blank	0.000	09:41
Control Test Stats		
Average	0.2017	
Std Dev	0.0012	
Rel Std Dev(%)	0.5726	

Operator's Signature

LIBERTY COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000960
05/05/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:43
Control Test	0.080	09:43
Air Blank	0.000	09:44
Control Test	0.081	09:44
Air Blank	0.000	09:45
Control Test	0.080	09:45
Air Blank	0.000	09:45
Control Test Stats		
Average	0.0803	
Std Dev	0.0006	
Rel Std Dev(%)	0.7187	

Dry

Operator's Signature



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2729 Fort Knox Blvd.
Bldg. 2, Suite 1300
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000960, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000960</u>	UNCERTAINTY* $\pm$
Owning Agency:	<u>LIBERTY COUNTY SO</u>	0.050 g/ 210 L 0.005
Calibration Date:	<u>05/05/2021</u>	0.080 g/ 210 L 0.004
Calibration Time:	<u>12:14</u>	0.200 g/ 210 L 0.007
		0.080 g/ 210 L Dry Gas Control 0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.
*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Thermometer temperatures are checked with NIST traceable Eutechnics 4400 digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the uses of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.
This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Digitally signed by Israel Soto
Date: 2021.05.05 15:01:30
-04'00'

Israel Soto

05/05/2021

Date

ISRAEL SOTO,

Department Inspector

FDLE/ATP Form 69 January 2021

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

Return Material Authorization

Ship to: ☒ CMI, Inc.

☐ Enforcement Electronics

Shipment to repair facility authorized by: Fred Hening on 06-16-2021

Items Returned: Instrument ☒ Supplies ☐ Other ☐ Describe: _____

Instrument Model: Intoxilyzer 8000 Serial Number: 80-000960

Bill To Address:
Liberty County Sheriff's Office

Ship to Address:
Alcohol Testing Program - FDLE
Tallahassee Florida

Reason for Return:

Modem port on back of instrument broke off into instrument, cannot plug in phone line for uploads.

Please choose one of the following options:

- ☐ 1. I _____, authorize all repairs.
- ☐ 2. I _____, authorize repairs up to \$_____.
- ☒ 3. I require an estimate **BEFORE** any repairs will be authorized and/ or conducted.

Please contact: Name: Fred Hening

Phone #: 850-445-8001 Email: fredrickhening@flhsmv.gov

ATP Contact Name: Israel Soto ATP Email: israelsoto@fdle.state.fl.us



INSTRUMENT PROCESSING SHEET

Agency Liberty County Sheriff's OfficeS/N 80-000960Florida Department of
Law EnforcementDate In 6/16/2021

DI Completion Date _____

☐ Ship☐ P/U☐ H/D☒ CMI☐ EE

Intake	By <u>IS</u>	Quality Checks	By _____	Date _____	Flow Calibration	By _____	Date _____																																								
☐ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes: <u>Modem port on back of instrument broke off inside the instrument, phone line is unable to plug into instrument. Sending to CMI for repair.</u>		☐ Breath Tube Screen ☐ Replace External O-Rings ☐ Instrument Set Up Verified ☐ R-Value _____ ☐ Flow Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547) ☐ Barometric Pressure Check Gauge ID # _____ ☐ Stability Checks			Flow Column # _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																										
		<table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr><td>0.050</td><td></td><td></td></tr> <tr><td>0.080</td><td></td><td></td></tr> <tr><td>0.200</td><td></td><td></td></tr> <tr><td>0.080 DGS</td><td>N/A</td><td></td></tr> </tbody> </table>			Simulator	Serial #	Lot #/Exp	0.050			0.080			0.200			0.080 DGS	N/A		Maintenance By _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____																											
Simulator	Serial #	Lot #/Exp																																													
0.050																																															
0.080																																															
0.200																																															
0.080 DGS	N/A																																														
		DI Temp. Checks By _____ ☐ Lab Temp °C _____ External Digital Therm. ID#: _____ ☐ 34°C +/- .2 Serial #: _____ ☐ 34°C +/- .2 Serial #: _____ ☐ 34°C +/- .2 Serial #: _____																																													
Calibration Adjustment By _____				Department Inspection By _____																																											
Barometric Pressure Gauge _____ ID # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr> <tr><td>0.040</td><td></td><td></td><td></td></tr> <tr><td>0.100</td><td></td><td></td><td></td></tr> <tr><td>0.200</td><td></td><td></td><td></td></tr> <tr><td>0.300</td><td></td><td></td><td></td></tr> <tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr> </tbody> </table>				Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Barometric Pressure ID# _____ Gauge _____ Instrument _____ Mouth Alcohol Solution Lot # _____ Acetone Stock Solution Lot # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr><td>0.000</td><td></td></tr> <tr><td>Interferent</td><td></td></tr> <tr><td>0.050</td><td></td></tr> <tr><td>0.080</td><td></td></tr> <tr><td>0.200</td><td></td></tr> </tbody> </table>				Simulator	Serial Number	0.000		Interferent		0.050		0.080		0.200	
Simulator	Serial #	Lot #	Expiration																																												
0.000		N/A	N/A																																												
0.040																																															
0.100																																															
0.200																																															
0.300																																															
0.080 DGS	N/A																																														
Simulator	Serial Number																																														
0.000																																															
Interferent																																															
0.050																																															
0.080																																															
0.200																																															
☐ Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr><td>0.050</td><td></td><td></td><td></td></tr> <tr><td>0.080</td><td></td><td></td><td></td></tr> <tr><td>0.200</td><td></td><td></td><td></td></tr> <tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr> </tbody> </table>				Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Attachments ☐ Form 41 ☐ Stability Checks ☐ Calibration Certificate ☐ Calibration Adjustment ☐ Post-Stability Checks ☐ Flow Calibration ☐ Form 40 ☐ Other _____																							
Simulator	Serial #	Lot #	Expiration																																												
0.050																																															
0.080																																															
0.200																																															
0.080 DGS	N/A																																														
Notes/Suggested Service: _____ <u>Compliance with Chapter 11D-8 FAC not determined, sending instrument to repair for modem port. IS</u>				☐ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☐ Return to/Place into Evidentiary Use ☒ Remain Out of Evidentiary Use ☐ Conduct an Agency Inspection Before Evidentiary Use																																											
Tech Review / Date _____				Admin Review / Date _____																																											