



INSTRUMENT PROCESSING SHEET

Agency FHP Panama CityS/N 80-001118Florida Department of
Law EnforcementDate In 01/19/2021DI Completion Date 01-20-2021☐ Ship ☒ P/U ☐ H/D ☐ CMI ☐ EE

Intake Performed By <u>RAW</u> ☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ Final Release Date FDLE Alcohol Testing Program	Quality Checks Performed By <u>RAW</u> ☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>233</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP105</u> 32 mm <u>.160</u> (.139 - .169) 36 mm <u>.175</u> (.156 - .190) 53 mm <u>.238</u> (.228 - .278) 103 mm <u>.523</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>30793</u> ☒ Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>MP5088</td> <td>202010A 10-05-2022</td> </tr> <tr> <td>0.080</td> <td>MP5086</td> <td>202010B 10-05-2022</td> </tr> <tr> <td>0.200</td> <td>MP5090</td> <td>202010D 10-06-2022</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG011102 04-20-2022</td> </tr> </tbody> </table>	Simulator	Serial #	Lot #/Exp	0.050	MP5088	202010A 10-05-2022	0.080	MP5086	202010B 10-05-2022	0.200	MP5090	202010D 10-06-2022	0.080 DGS	N/A	AG011102 04-20-2022	Flow Calibration Performed By _____ Flow Column # _____ ☐ 5L/min - 17mm ☐ 15L/min - 53mm ☐ 30L/min - 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547) Maintenance Performed By _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____ Temperature Checks Performed By <u>IS</u> ☒ Lab Temp °C <u>21.48</u> External Digital Therm. ID#: <u>300505</u> ☒ 34°C +/-2 Serial #: <u>MP5088</u> ☒ 34°C +/-2 Serial #: <u>MP5086</u> ☒ 34°C +/-2 Serial #: <u>MP5090</u>																																												
Simulator	Serial #	Lot #/Exp																																																											
0.050	MP5088	202010A 10-05-2022																																																											
0.080	MP5086	202010B 10-05-2022																																																											
0.200	MP5090	202010D 10-06-2022																																																											
0.080 DGS	N/A	AG011102 04-20-2022																																																											
Calibration Adjustment Performed By _____ Barometric Pressure Gauge _____ ID # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> <th>Lot Number</th> <th>Expiration</th> </tr> </thead> <tbody> <tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr> <tr><td>0.040</td><td></td><td></td><td></td></tr> <tr><td>0.100</td><td></td><td></td><td></td></tr> <tr><td>0.200</td><td></td><td></td><td></td></tr> <tr><td>0.300</td><td></td><td></td><td></td></tr> <tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr> </tbody> </table> ☐ Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> <th>Lot Number</th> <th>Expiration</th> </tr> </thead> <tbody> <tr><td>0.050</td><td></td><td></td><td></td></tr> <tr><td>0.080</td><td></td><td></td><td></td></tr> <tr><td>0.200</td><td></td><td></td><td></td></tr> <tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr> </tbody> </table>	Simulator	Serial Number	Lot Number	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial Number	Lot Number	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Department Inspection Performed By <u>IS</u> Barometric Pressure ID# <u>30793</u> Gauge <u>1025</u> Instrument <u>1026</u> Mouth Alcohol Solution Lot # <u>2020-A</u> Acetone Stock Solution Lot # <u>2020-A</u> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr><td>0.000</td><td>G11621</td></tr> <tr><td>Interferent</td><td>MP5087</td></tr> <tr><td>0.050</td><td>MP5088</td></tr> <tr><td>0.080</td><td>MP5086</td></tr> <tr><td>0.200</td><td>MP5090</td></tr> </tbody> </table> Attachments ☒ Form 41 ☐ Post-Stability Checks ☒ Stability Checks ☐ Flow Calibration ☒ Calibration Certificate ☐ Form 40 ☐ Calibration Adjustment ☒ Other <u>Extra stabilities</u>	Simulator	Serial Number	0.000	G11621	Interferent	MP5087	0.050	MP5088	0.080	MP5086	0.200	MP5090
Simulator	Serial Number	Lot Number	Expiration																																																										
0.000		N/A	N/A																																																										
0.040																																																													
0.100																																																													
0.200																																																													
0.300																																																													
0.080 DGS	N/A																																																												
Simulator	Serial Number	Lot Number	Expiration																																																										
0.050																																																													
0.080																																																													
0.200																																																													
0.080 DGS	N/A																																																												
Simulator	Serial Number																																																												
0.000	G11621																																																												
Interferent	MP5087																																																												
0.050	MP5088																																																												
0.080	MP5086																																																												
0.200	MP5090																																																												
Notes/Suggested Service: <u>Instrument had interferent detect on water free test during department inspection, ran extra stability tests with water.</u> <u>[Signature]</u> _____ _____ _____	☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use 2021.01.22 <u>Michael D. Haughney</u> 11:47:24 -05'00' Tech Review / Date 2021.01.25 <u>[Signature]</u> 13:24:12 Admin Review / Date																																																												

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: FL HIGHWAY PATROL
Time of Inspection: 11:22

Date of Inspection: 01/20/2021

Serial Number: 80-001118
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202010A Exp: 10/05/2022	0.08g/210L Test (g/210L) Lot#:202010B Exp: 10/05/2022	0.20g/210L Test (g/210L) Lot#:202010D Exp: 10/06/2022	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG011102 Exp: 04/20/2022
0.000 / 0.000	0.049	0.080	0.199	0.079
0.000 / 0.000	0.049	0.080	0.200	0.080
0.000 / 0.000	0.049	0.080	0.199	0.080
0.000 / 0.000	0.049	0.080	0.199	0.079
0.000 / 0.000	0.049	0.080	0.199	0.080
INT / 0.000	0.050	0.081	0.200	0.080
/ 0.000	0.049	0.080	0.199	0.080
/ 0.000	0.049	0.080	0.200	0.080
/ 0.000	0.049	0.081	0.200	0.080
/ 0.000	0.050	0.081	0.200	0.080

Standard Deviations	0.0004	0.0004	0.0005	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0004 Number of Simulators Used: 5

Remarks:

00: Interferent Detect DOUBLE CHECKED SIMULATOR, SEAL, TEMP.

will run extra stability tests with H₂O

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Israel Soto

ISRAEL SOTO

Signature and Printed Name

01/20/2021
Date

MX
CR
2021.0
1.25
13:23:3
5
-05'00'

Stability Checks

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001118
01/19/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:03
Control Test	0.049	11:04
Air Blank	0.000	11:04
Control Test	0.049	11:05
Air Blank	0.000	11:05
Control Test	0.049	11:06
Air Blank	0.000	11:07
Control Test Stats		
Average	0.0490	
Std Dev	0.0020	
Rel Std Dev(%)	0.0000	

0.05g/210L

BAW

Operator's Signature

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001118
01/19/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:09
Control Test	0.080	11:10
Air Blank	0.000	11:10
Control Test	0.078	11:11
Air Blank	0.000	11:12
Control Test	0.079	11:12
Air Blank	0.000	11:13
Control Test Stats		
Average	0.0790	
Std Dev	0.0010	
Rel Std Dev(%)	1.2658	

0.08g/210L
wet

BAW

Operator's Signature

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001118
01/19/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:14
Control Test	0.198	11:15
Air Blank	0.000	11:16
Control Test	0.198	11:16
Air Blank	0.000	11:17
Control Test	0.199	11:17
Air Blank	0.000	11:18
Control Test Stats		
Average	0.1983	
Std Dev	0.0006	
Rel Std Dev(%)	0.2911	

0.20g/210L

BAW

Operator's Signature

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001118
01/19/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:23
Control Test	0.079	11:23
Air Blank	0.000	11:24
Control Test	0.080	11:24
Air Blank	0.000	11:24
Control Test	0.080	11:25
Air Blank	0.000	11:25
Control Test Stats		
Average	0.0797	
Std Dev	0.0006	
Rel Std Dev(%)	0.7247	

0.08g/210L
DGS

BAW

Operator's Signature

MX

2021.01.
25
13:23:19
-05'00"



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2729 Fort Knox Blvd.
Bldg. 2, Suite 1300
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-001118, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-001118</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>FL HIGHWAY PATROL</u>	0.050 g/ 210 L	0.005
Calibration Date:	<u>01/20/2021</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>11:22</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.
*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Thermometer temperatures are checked with NIST traceable Eutechnics 4400 digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the uses of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.
This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

01/20/2021

Date

Israel Soto

ISRAEL SOTO,
Department Inspector

FDLE/ATP Form 69 January 2021
Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

Page 1 of 1

2021.01.25
13:23:04 -05'00'

Extra stability Tests

DI H₂O

FL HIGHWAY PATROL

Intoxilyzer - Alcohol Analyzer

Model 8000

SN 80-001118

01/20/2021

Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:25
Control Test	0.000	11:26
Air Blank	0.000	11:26
Control Test	0.000	11:27
Air Blank	0.000	11:27
Control Test	0.000	11:28
Air Blank	0.000	11:28
Control Test	0.000	11:29
Air Blank	0.000	11:30
Control Test	0.000	11:30
Air Blank	0.000	11:31
Control Test	0.000	11:31
Air Blank	0.000	11:32
Control Test	0.000	11:33
Air Blank	0.000	11:33
Control Test	0.000	11:34
Air Blank	0.000	11:34
Control Test	0.000	11:35
Air Blank	0.000	11:35
Control Test	0.000	11:36
Air Blank	0.000	11:37
Control Test	0.000	11:37
Air Blank	0.000	11:38
Control Test	0.000	11:38
Air Blank	0.000	11:39
Control Test	0.000	11:40
Air Blank	0.000	11:40
Control Test	0.000	11:41
Air Blank	0.000	11:41
Control Test	0.000	11:42
Air Blank	0.000	11:42
Control Test	0.000	11:43
Air Blank	0.000	11:43
Control Test	0.000	11:44
Air Blank	0.000	11:45
Control Test	0.000	11:45
Air Blank	0.000	11:46
Control Test	0.000	11:46
Air Blank	0.000	11:47
Control Test	0.000	11:48
Air Blank	0.000	11:48
Control Test Stats		
Average	0.0000	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

MX

2021.0
1.25
13:22:47
-05'00'



INSTRUMENT PROCESSING SHEET

Agency Florida Highway Patrol

S/N 80-001118

Florida Department of
Law Enforcement

Date In 9/8/2021

DI Completion Date 9/8/2021

☐ Ship ☐ P/U ☐ H/D ☒ CMI ☐ EE

Intake By <u>IS</u> ☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes: Instrument was in <u>Disabled Mode after uploading</u> <u>Agency Inspection.</u>	Quality Checks By <u>IS</u> Date <u>09-14-2021</u> ☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>231</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP-105</u> 32 mm <u>0.152</u> (.139 - .169) 36 mm <u>0.171</u> (.156 - .190) 53 mm <u>0.246</u> (.228 - .278) 103 mm <u>0.515</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>28427</u> ☒ Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>MP5088</td> <td>202010A 10-05-2022</td> </tr> <tr> <td>0.080</td> <td>MP5089</td> <td>202010B 10-05-2022</td> </tr> <tr> <td>0.200</td> <td>MP5090</td> <td>202010D 10-06-2022</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG011102 04-20-2022</td> </tr> </tbody> </table>	Simulator	Serial #	Lot #/Exp	0.050	MP5088	202010A 10-05-2022	0.080	MP5089	202010B 10-05-2022	0.200	MP5090	202010D 10-06-2022	0.080 DGS	N/A	AG011102 04-20-2022	Flow Calibration By <u>IS</u> Date <u>09-14-2021</u> Flow Column # <u>ATP-105</u> ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value <u>231</u> ☐ Post Calibration Verification (L/s) Flow Column # <u>ATP-105</u> 32 mm <u>0.152</u> (.139 - .169) 36 mm <u>0.171</u> (.156 - .190) 53 mm <u>0.246</u> (.228 - .278) 103 mm <u>0.515</u> (.447 - .547) Maintenance By <u>IS</u> ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other <u> </u> DI Temp. Checks By <u>IS</u> ☒ Lab Temp °C <u>21.07</u> External Digital Therm. ID#: <u>381189</u> ☒ 34°C +/-2 Serial #: <u>MP5088</u> ☒ 34°C +/-2 Serial #: <u>MP5089</u> ☒ 34°C +/-2 Serial #: <u>MP5090</u>																																												
Simulator	Serial #	Lot #/Exp																																																											
0.050	MP5088	202010A 10-05-2022																																																											
0.080	MP5089	202010B 10-05-2022																																																											
0.200	MP5090	202010D 10-06-2022																																																											
0.080 DGS	N/A	AG011102 04-20-2022																																																											
Calibration Adjustment By <u>IS</u> Barometric Pressure Gauge <u>28427</u> ID # <u> </u> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td> </td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td> </td> <td> </td> <td> </td> </tr> <tr> <td>0.100</td> <td> </td> <td> </td> <td> </td> </tr> <tr> <td>0.200</td> <td> </td> <td> </td> <td> </td> </tr> <tr> <td>0.300</td> <td> </td> <td> </td> <td> </td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td> </td> <td> </td> </tr> </tbody> </table> ☐ Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td> </td> <td> </td> <td> </td> </tr> <tr> <td>0.080</td> <td> </td> <td> </td> <td> </td> </tr> <tr> <td>0.200</td> <td> </td> <td> </td> <td> </td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td> </td> <td> </td> </tr> </tbody> </table> Notes/Suggested Service: <u>Bypassed Agency Inspection</u> <u>and uploaded before printing. After uploading bypassed</u> <u>Agency Inspection instrument exited Disabled Mode.</u> <u>Performed Department Inspection to ensure</u> <u>instrument was operating correctly, instrument lost</u> <u>Form 41. During form upload instrument began</u> <u>displaying "Error 016: Contact CMI". Sending to</u> <u>CMI. IS 09-16-2021</u>	Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Department Inspection By <u>IS</u> Barometric Pressure ID# <u>28427</u> Gauge <u>1017</u> Instrument <u>1018</u> Mouth Alcohol Solution Lot # <u>2021-B</u> Acetone Stock Solution Lot # <u>2021-C</u> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td>MP5086</td> </tr> <tr> <td>Interferent</td> <td>MP5087</td> </tr> <tr> <td>0.050</td> <td>MP5088</td> </tr> <tr> <td>0.080</td> <td>MP5089</td> </tr> <tr> <td>0.200</td> <td>MP5090</td> </tr> </tbody> </table> Attachments ☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment ☐ Post-Stability Checks ☐ Flow Calibration ☒ Form 40 ☐ Other <u> </u> ☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☐ Return to/Place into Evidentiary Use ☒ Remain Out of Evidentiary Use ☐ Conduct an Agency Inspection Before Evidentiary Use <u>2022-01</u> Richard A Williams Digitally signed by Richard A Williams Date: 2022.01.18 15:55:04 -0500 <u>25</u> <u>13:36:02</u> Admin Review Date Tech Review / Date <u>09/08/2021</u>	Simulator	Serial Number	0.000	MP5086	Interferent	MP5087	0.050	MP5088	0.080	MP5089	0.200	MP5090
Simulator	Serial #	Lot #	Expiration																																																										
0.000		N/A	N/A																																																										
0.040																																																													
0.100																																																													
0.200																																																													
0.300																																																													
0.080 DGS	N/A																																																												
Simulator	Serial #	Lot #	Expiration																																																										
0.050																																																													
0.080																																																													
0.200																																																													
0.080 DGS	N/A																																																												
Simulator	Serial Number																																																												
0.000	MP5086																																																												
Interferent	MP5087																																																												
0.050	MP5088																																																												
0.080	MP5089																																																												
0.200	MP5090																																																												

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: FL HIGHWAY PATROL

Serial Number: 80-001118

Time of Inspection: 11:59

Date of Inspection: 09/14/2021

Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#: 202010A Exp: 10/05/2022	0.08g/210L Test (g/210L) Lot#: 202010B Exp: 10/05/2022	0.20g/210L Test (g/210L) Lot#: 202010D Exp: 10/06/2022	0.08 g/210L Dry Gas Std Test (g/210L) Lot#: AG011102 Exp: 04/20/2022
0.000	0.048	0.077	0.198	0.079
0.000	0.048	0.078	0.198	0.079
0.000	0.048	0.078	0.198	0.079
0.000	0.048	0.078	0.198	0.079
0.000	0.048	0.078	0.198	0.079
0.000	0.048	0.078	0.198	0.079
0.000	0.048	0.078	0.198	0.079
0.000	0.049	0.078	0.197	0.079
0.000	0.048	0.078	0.198	0.079
0.000	0.049	0.078	0.198	0.079
0.000	0.049	0.079	0.198	0.079

Standard Deviations	0.0004	0.0004	0.0003	0.0000
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0002 Number of Simulators Used: 5

Remarks:

Instrument lost Form 41, reprinted from database

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.


 ISRAEL SOTO
 Signature and Printed Name
09/14/2021
 Date

Stability Checks

SH PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001118
09/14/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:54
Control Test	0.049	09:55
Air Blank	0.000	09:56
Control Test	0.048	09:56
Air Blank	0.000	09:57
Control Test	0.048	09:58
Air Blank	0.000	09:58
Control Test Stats		
Average	0.0483	
Std Dev	0.0006	
Rel Std Dev(%)	1.1945	

Operator's Signature

HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001118
09/14/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:59
Control Test	0.078	10:00
Air Blank	0.000	10:00
Control Test	0.078	10:01
Air Blank	0.000	10:01
Control Test	0.077	10:02
Air Blank	0.000	10:03
Control Test Stats		
Average	0.0777	
Std Dev	0.0006	
Rel Std Dev(%)	0.7434	

wet

Operator's Signature

HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001118
09/14/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:03
Control Test	0.197	10:04
Air Blank	0.000	10:05
Control Test	0.197	10:05
Air Blank	0.000	10:06
Control Test	0.197	10:07
Air Blank	0.000	10:07
Control Test Stats		
Average	0.1970	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001118
09/14/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:08
Control Test	0.079	10:09
Air Blank	0.000	10:09
Control Test	0.079	10:10
Air Blank	0.000	10:10
Control Test	0.079	10:10
Air Blank	0.000	10:11
Control Test Stats		
Average	0.0790	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Dry

Operator's Signature

Florida Department of Law Enforcement Alcohol Testing Program

AGENCY INSPECTION REPORT - INTOXILYZER 8000

Agency: FL HIGHWAY PATROL

Serial Number: 80-001118

Time of Inspection: 08:28

Date of Inspection: 09/14/2021

Software: 8100.27

Check or Test	YES	NO
Date and/or Time Adjusted		No
Diagnostic Check (Pre-Inspection): OK		No
Alcohol Free Subject Test: 0.000		No
Mouth Alcohol Test: Slope Not Met		No
Interferent Detect Test: Interferent Detect		No
Diagnostic Check (Post-Inspection): OK		No

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#: Exp:	0.08g/210L Test (g/210L) Lot#: Exp:	0.20g/210L Test (g/210L) Lot#: Exp:	0.08 g/210L Dry Gas Std Test (g/210L) Lot #: Exp:

Number of Simulators Used: _____

Remarks:

NOT COMPLIANCE CHECK, CHECKING UPLOAD

uploaded before printing, reprinted from database

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I hold a valid Florida Department of Law Enforcement Agency Inspector Permit and that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Israel Soto

ISRAEL SOTO

Signature and Printed Name

09/14/2021

Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2729 Fort Knox Blvd.
Bldg. 2, Suite 1300
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-001118, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-001118</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>FL HIGHWAY PATROL</u>	0.050 g/ 210 L	0.005
Calibration Date:	<u>09/14/2021</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>11:59</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.
*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Thermometer temperatures are checked with NIST traceable Eutechnics 4400 digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the uses of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.
This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Digitally signed by Israel Soto
Date: 2021.09.21 10:51:04
-04'00'

Israel Soto

09/14/2021

Date

ISRAEL SOTO,

Department Inspector

FDLE/ATP Form 69 January 2021

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

Return Material Authorization

Ship to: ☒ CMI, Inc.

☐ Enforcement Electronics

Shipment to repair facility authorized by: Susan Barge on 09-21-2021

Items Returned: Instrument ☒ Supplies ☐ Other ☐ Describe: _____

Instrument Model: Intoxilyzer 8000 Serial Number: 80-001118

Bill To Address:

Florida Highway Patrol

Ship to Address:

Alcohol Testing Program - FDLE

Tallahassee, Florida

Reason for Return:

Instrument lost Form 41, when trying to upload forms an error was shown on Cobra V3 and
the instrument entered Disabled Mode showing "Error 016: Contact CMI".

Records on instrument have already been downloaded and instrument is cleared.

Please choose one of the following options:

☐ 1. I _____, authorize all repairs.

☐ 2. I _____, authorize repairs up to \$_____.

☒ 3. I require an estimate **BEFORE** any repairs will be authorized and/ or conducted.

Please contact: Name: Susan Barge

Phone #: 352-620-4701

Email: susanbarge@flhsmv.gov

ATP Contact Name: Israel Soto

ATP Email: israelsoto@fdle.state.fl.us