



INSTRUMENT PROCESSING SHEET

Agency Miami-Dade Police Department

S/N 80-001277

Florida Department of
Law Enforcement

Date In 6/24/2021

DI Completion Date 6/24/2021

☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake	By DERR	Quality Checks	By DER	Date 6/24/2021	Flow Calibration	By	Date																																																										
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>234</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP104</u> 32 mm <u>0.148</u> (.139 - .169) 36 mm <u>0.167</u> (.156 - .190) 53 mm <u>0.238</u> (.228 - .278) 103 mm <u>0.515</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>28663</u> ☒ Stability Checks			Flow Column # _____ ☐ 5L/min - 17mm ☐ 15L/min - 53mm ☐ 30L/min - 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																																												
		<table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>MP5092</td> <td>202010A 10/05/2022</td> </tr> <tr> <td>0.080</td> <td>MP5093</td> <td>202010B 10/05/2022</td> </tr> <tr> <td>0.200</td> <td>MP5094</td> <td>202010D 10/06/2022</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG026705 09/23/2022</td> </tr> </tbody> </table>		Simulator	Serial #	Lot #/Exp	0.050	MP5092	202010A 10/05/2022	0.080	MP5093	202010B 10/05/2022	0.200	MP5094	202010D 10/06/2022	0.080 DGS	N/A	AG026705 09/23/2022	Maintenance By _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____ DI Temp. Checks By DERR ☒ Lab Temp °C <u>21.95C</u> External Digital Therm. ID#: <u>300503</u> ☒ 34°C +/- .2 Serial #: <u>SD3967 MP5092</u> ☒ 34°C +/- .2 Serial #: <u>SD3968 MP5093</u> ☒ 34°C +/- .2 Serial #: <u>SD3969 MP5094</u> <i>DEER 6/24/21</i>																																														
Simulator	Serial #	Lot #/Exp																																																															
0.050	MP5092	202010A 10/05/2022																																																															
0.080	MP5093	202010B 10/05/2022																																																															
0.200	MP5094	202010D 10/06/2022																																																															
0.080 DGS	N/A	AG026705 09/23/2022																																																															
Calibration Adjustment By _____ Barometric Pressure Gauge _____ ID # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> ☐ Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>		Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Department Inspection By DERR Barometric Pressure ID# <u>28199</u> Gauge <u>1019</u> Instrument <u>1016</u> Mouth Alcohol Solution Lot # <u>2021-A</u> Acetone Stock Solution Lot # <u>2020-A</u> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td>SD3963</td> </tr> <tr> <td>Interferent</td> <td>SD1017</td> </tr> <tr> <td>0.050</td> <td>MP5092</td> </tr> <tr> <td>0.080</td> <td>MP5093</td> </tr> <tr> <td>0.200</td> <td>MP5094</td> </tr> </tbody> </table>		Simulator	Serial Number	0.000	SD3963	Interferent	SD1017	0.050	MP5092	0.080	MP5093	0.200	MP5094		
Simulator	Serial #	Lot #	Expiration																																																														
0.000		N/A	N/A																																																														
0.040																																																																	
0.100																																																																	
0.200																																																																	
0.300																																																																	
0.080 DGS	N/A																																																																
Simulator	Serial #	Lot #	Expiration																																																														
0.050																																																																	
0.080																																																																	
0.200																																																																	
0.080 DGS	N/A																																																																
Simulator	Serial Number																																																																
0.000	SD3963																																																																
Interferent	SD1017																																																																
0.050	MP5092																																																																
0.080	MP5093																																																																
0.200	MP5094																																																																
Notes/Suggested Service: <u>Technical Review</u> <u>identified wrong simulator numbers under</u> <u>the DI Temp checks DEER 6/24/21</u> _____ _____ _____ _____ _____		Attachments ☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment ☐ Post-Stability Checks ☐ Flow Calibration ☐ Form 40 ☐ Other _____		☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use 2021.06. 25 Taylor Gutschow Digitally signed by Taylor Gutschow Date: 2021.06.24 15:31:59 -04'00' Tech Review / Date		Admin Review / Date 14:09:24 04'00'																																																											



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-001277, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-001277</u>	UNCERTAINTY* $\pm$
Owning Agency:	<u>MIAMI-DADE PD</u>	0.050 g/ 210 L 0.005
Calibration Date:	<u>06/24/2021</u>	0.080 g/ 210 L 0.004
Calibration Time:	<u>14:32</u>	0.200 g/ 210 L 0.007
		0.080 g/ 210 L Dry Gas Control 0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.
*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Thermometer temperatures are checked with NIST traceable Eutechnics 4400 digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the uses of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.
This document shall not be reproduced except in full,
without written approval of the Florida Department of
Law Enforcement Alcohol Testing Program.

06/24/2021

Date


DAVID E REYES-RIVERA,

Department Inspector

FDLE/ATP Form 69 January 2021
Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: MIAMI-DADE PD

Time of Inspection: 14:32

Date of Inspection: 06/24/2021

Serial Number: 80-001277

Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202010A Exp: 10/05/2022	0.08g/210L Test (g/210L) Lot#:202010B Exp: 10/05/2022	0.20g/210L Test (g/210L) Lot#:202010D Exp: 10/06/2022	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG026705 Exp: 09/23/2022
0.000	0.051	0.080	0.201	0.079
0.000	0.051	0.081	0.201	0.079
0.000	0.050	0.080	0.201	0.079
0.000	0.051	0.080	0.201	0.079
0.000	0.051	0.080	0.202	0.079
0.000	0.051	0.081	0.201	0.079
0.000	0.051	0.080	0.201	0.079
0.000	0.052	0.080	0.202	0.079
0.000	0.051	0.080	0.201	0.079
0.000	0.051	0.080	0.201	0.079

Standard Deviations	0.0004	0.0004	0.0004	0.0000
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0003 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

David E Reyes-Rivera

DAVID E REYES-RIVERA

Signature and Printed Name

06/24/2021
Date

Type of Test	Serial Number	Agency	Date	Performed By
Stabilities	80-001277	Miami-Dade Police Department	6/24/2021	DERR <i>[Signature]</i>

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L
0.047 to 0.053	0.077 to 0.083	0.194 to 0.206	0.077 to 0.083
MIAMI-DADE PD Intoxilyzer - Alconol Analyzer Model: 8000 SN 80-001277 06/24/2021 Software: 8100.27 Test Time Air Blank 0.000 12:32 Control Test 0.052 12:33 Air Blank 0.000 12:33 Control Test 0.051 12:34 Air Blank 0.000 12:34 Control Test 0.052 12:35 Air Blank 0.000 12:36 Control Test Stats Average 0.0517 Std Dev 0.0005 Rel Std Dev(%) 1.1175	MIAMI-DADE PD Intoxilyzer - Alconol Analyzer Model: 8000 SN 80-001277 06/24/2021 Software: 8100.27 Test Time Air Blank 0.000 12:32 Control Test 0.061 12:33 Air Blank 0.000 12:33 Control Test 0.080 12:34 Air Blank 0.000 12:34 Control Test 0.081 12:35 Air Blank 0.000 12:36 Control Test Stats Average 0.0807 Std Dev 0.0006 Rel Std Dev(%) 0.7157	MIAMI-DADE PD Intoxilyzer - Alconol Analyzer Model: 8000 SN 80-001277 06/24/2021 Software: 8100.27 Test Time Air Blank 0.000 12:42 Control Test 0.202 12:43 Air Blank 0.000 12:43 Control Test 0.202 12:44 Air Blank 0.000 12:45 Control Test 0.201 12:46 Air Blank 0.000 12:46 Control Test Stats Average 0.2017 Std Dev 0.0006 Rel Std Dev(%) 0.2653	MIAMI-DADE PD Intoxilyzer - Alconol Analyzer Model: 8000 SN 80-001277 06/24/2021 Software: 8100.27 Test Time Air Blank 0.000 12:47 Control Test 0.079 12:48 Air Blank 0.000 12:48 Control Test 0.079 12:48 Air Blank 0.000 12:49 Control Test 0.080 12:49 Air Blank 0.000 12:50 Control Test Stats Average 0.0793 Std Dev 0.0005 Rel Std Dev(%) 0.7277
<i>[Signature]</i> Operator's Signature	<i>[Signature]</i> Operator's Signature	<i>[Signature]</i> Operator's Signature	<i>[Signature]</i> Operator's Signature