



INSTRUMENT PROCESSING SHEET

Agency Manatee County SO

S/N 80-006694

Florida Department of
Law Enforcement

Date In 7/26/2021 DI Completion Date 7/28/2021

☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake	By MH	Quality Checks	By MH	Date 07/28/2021	Flow Calibration	By	Date																																								
☒ Annual ☐ Registration ☒ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>215</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP 106</u> 32 mm <u>0.160</u> (.139 - .169) 36 mm <u>0.179</u> (.156 - .190) 53 mm <u>0.242</u> (.228 - .278) 103 mm <u>0.500</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>28199</u> ☒ Stability Checks			Flow Column # _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																										
					Maintenance By _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____																																										
					DI Temp. Checks By MH _____ ☒ Lab Temp °C <u>21.48</u> External Digital Therm. ID#: <u>300503</u> ☒ 34°C +/- .2 Serial #: <u>MP5092</u> ☒ 34°C +/- .2 Serial #: <u>MP5093</u> ☒ 34°C +/- .2 Serial #: <u>MP5097</u>																																										
Calibration Adjustment By _____ Barometric Pressure Gauge _____ ID # _____				Department Inspection By MH _____ Barometric Pressure ID# <u>68639</u> Gauge <u>1016</u> Instrument <u>1018</u> Mouth Alcohol Solution Lot # <u>2021-B</u> Acetone Stock Solution Lot # <u>2020-A</u>																																											
<table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr> <tr><td>0.040</td><td></td><td></td><td></td></tr> <tr><td>0.100</td><td></td><td></td><td></td></tr> <tr><td>0.200</td><td></td><td></td><td></td></tr> <tr><td>0.300</td><td></td><td></td><td></td></tr> <tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr> </tbody> </table>				Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			<table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr><td>0.000</td><td>SD1014</td></tr> <tr><td>Interferent</td><td>SD1015</td></tr> <tr><td>0.050</td><td>MP5092</td></tr> <tr><td>0.080</td><td>MP5093</td></tr> <tr><td>0.200</td><td>MP5097</td></tr> </tbody> </table>				Simulator	Serial Number	0.000	SD1014	Interferent	SD1015	0.050	MP5092	0.080	MP5093	0.200	MP5097
Simulator	Serial #	Lot #	Expiration																																												
0.000		N/A	N/A																																												
0.040																																															
0.100																																															
0.200																																															
0.300																																															
0.080 DGS	N/A																																														
Simulator	Serial Number																																														
0.000	SD1014																																														
Interferent	SD1015																																														
0.050	MP5092																																														
0.080	MP5093																																														
0.200	MP5097																																														
☐ Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr><td>0.050</td><td></td><td></td><td></td></tr> <tr><td>0.080</td><td></td><td></td><td></td></tr> <tr><td>0.200</td><td></td><td></td><td></td></tr> <tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr> </tbody> </table>				Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Attachments ☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment ☐ Post-Stability Checks ☐ Flow Calibration ☐ Form 40 ☐ Other _____																							
Simulator	Serial #	Lot #	Expiration																																												
0.050																																															
0.080																																															
0.200																																															
0.080 DGS	N/A																																														
Notes/Suggested Service: _____ Temp Checks Post Inspection. _____ _____ _____ _____ _____ _____ _____				☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use																																											
David Eliezer Reyes-Rivera Digitally signed by David Eliezer Reyes-Rivera Date: 2021.08.04 10:21:31 -0400				Tech Review / Date _____ Admin Review / Date _____																																											

Florida Department of Law Enforcement

Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: MANATEE COUNTY SO
Time of Inspection: 14:37

Date of Inspection: 07/28/2021

Serial Number: 80-006694
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202010A Exp: 10/05/2022	0.08g/210L Test (g/210L) Lot#:202010B Exp: 10/05/2022	0.20g/210L Test (g/210L) Lot#:202010D Exp: 10/06/2022	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG026705 Exp: 09/23/2022
0.000	0.049	0.078	0.197	0.079
0.000	0.049	0.079	0.197	0.080
0.000	0.049	0.079	0.198	0.080
0.000	0.049	0.079	0.197	0.079
0.000	0.049	0.079	0.197	0.079
0.000	0.050	0.079	0.197	0.079
0.000	0.050	0.079	0.197	0.079
0.000	0.049	0.079	0.197	0.079
0.000	0.049	0.079	0.197	0.079
0.000	0.050	0.080	0.197	0.079


Standard Deviations	0.0004	0.0004	0.0003	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0003 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



MICHAEL D HAUGHEY

Signature and Printed Name

07/28/2021
Date

TYPE OF TEST	SERIAL NUMBER	AGENCY	DATE	PERFORMED BY
Stabilities	80-006694	Manatee County SO	07/28/21	MX

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L
0.047 to 0.053 ☒	0.077 to 0.083 ☒	0.194 to 0.206 ☒	0.077 to 0.083 ☒

MANATEE COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006694
07/28/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:28
Control Test	0.050	09:29
Air Blank	0.000	09:29
Control Test	0.048	09:30
Air Blank	0.000	09:31
Control Test	0.048	09:31
Air Blank	0.000	09:32
Control Test Stats		
Average	0.0487	
Std Dev	0.0012	
Rel Std Dev(%)	2.3727	

MX
Operator's Signature

MANATEE COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006694
07/28/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:33
Control Test	0.078	09:34
Air Blank	0.000	09:35
Control Test	0.079	09:35
Air Blank	0.000	09:36
Control Test	0.079	09:37
Air Blank	0.000	09:37
Control Test Stats		
Average	0.0787	
Std Dev	0.0006	
Rel Std Dev(%)	0.7339	

MX
Operator's Signature

MANATEE COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006694
07/28/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:40
Control Test	0.198	09:41
Air Blank	0.000	09:41
Control Test	0.196	09:42
Air Blank	0.000	09:43
Control Test	0.197	09:43
Air Blank	0.000	09:44
Control Test Stats		
Average	0.1970	
Std Dev	0.0010	
Rel Std Dev(%)	0.5076	

MX
Operator's Signature

MANATEE COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006694
07/28/2021
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	09:46
Control Test	0.078	09:46
Air Blank	0.000	09:46
Control Test	0.079	09:47
Air Blank	0.000	09:47
Control Test	0.079	09:48
Air Blank	0.000	09:48
Control Test Stats		
Average	0.0787	
Std Dev	0.0006	
Rel Std Dev(%)	0.7339	

MX
Operator's Signature



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-006694, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-006694</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>MANATEE COUNTY SO</u>	0.050 g/210 L	0.005
Calibration Date:	<u>07/28/2021</u>	0.080 g/210 L	0.004
Calibration Time:	<u>14:37</u>	0.200 g/210 L	0.007
		0.080 g/210 L Dry Gas Control	0.005

All results are reported in g/210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Thermometer temperatures are checked with NIST traceable Eutechnics 4400 digital thermometers calibrated by Precision Metrology in accordance with ISO/IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the uses of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/IEC 17025 standards. This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

FDLE/ATP Form 69 January 2021
Issuing Authority: Alcohol Testing Program

07/28/2021

Date

MICHAEL D HAUGHEY,

Department Inspector

Service • Integrity • Respect • Quality