



INSTRUMENT PROCESSING SHEET

Agency Florida Department of Law Enforcement S/N 80-000227

Florida Department of Law Enforcement

Date In 03-14-2022 DI Completion Date 03-24-2022 Ship P/U H/D CMI EE

Intake	By IS	Quality Checks	By IS	Date	03-24-2022	Flow Calibration	By	Date																			
<input checked="" type="checkbox"/> Annual <input type="checkbox"/> Registration <input type="checkbox"/> Return from CMI / EE Visual Inspection: <input checked="" type="checkbox"/> Case <input checked="" type="checkbox"/> Handle <input checked="" type="checkbox"/> Keyboard <input checked="" type="checkbox"/> Dry Gas Shelf <input checked="" type="checkbox"/> Feet <input checked="" type="checkbox"/> Breath Tube <input checked="" type="checkbox"/> Ports <input checked="" type="checkbox"/> Screws Tight Other Equipment/ Accessories: <input type="checkbox"/> Power cord <input type="checkbox"/> Printer Cable <input type="checkbox"/> Static Bag <input type="checkbox"/> 12V DC Cable Notes: _____ _____ _____ _____ _____ _____		<input checked="" type="checkbox"/> Breath Tube Screen <input checked="" type="checkbox"/> Replace External O-Rings <input checked="" type="checkbox"/> Instrument Set Up Verified <input checked="" type="checkbox"/> R-Value <u>233</u> <input checked="" type="checkbox"/> Flow Verification (L/s) Flow Column # <u>ATP-102</u> 32 mm <u>0.148</u> (.139 - .169) 36 mm <u>0.160</u> (.156 - .190) 53 mm <u>0.234</u> (.228 - .278) 103 mm <u>0.488</u> (.447 - .547) <input checked="" type="checkbox"/> Barometric Pressure Check Gauge ID # <u>30793</u> <input checked="" type="checkbox"/> Stability Checks				Flow Column # _____ <input type="checkbox"/> 5L/min – 17mm <input type="checkbox"/> 15L/min – 53mm <input type="checkbox"/> 30L/min – 103mm <input type="checkbox"/> R-Value _____ <input type="checkbox"/> Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																					
		<table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>MP6291</td> <td>202201C 01-11-2024</td> </tr> <tr> <td>0.080</td> <td>MP6292</td> <td>202201D 01-18-2024</td> </tr> <tr> <td>0.200</td> <td>MP6293</td> <td>202201E 01-18-2024</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG113403 05-14-2023</td> </tr> </tbody> </table>			Simulator	Serial #	Lot #/Exp	0.050	MP6291	202201C 01-11-2024	0.080	MP6292	202201D 01-18-2024	0.200	MP6293	202201E 01-18-2024	0.080 DGS	N/A	AG113403 05-14-2023	<table border="1"> <thead> <tr> <th>Maintenance</th> <th>By</th> </tr> </thead> <tbody> <tr> <td> <input type="checkbox"/> Battery Replacement <input type="checkbox"/> Dry Gas Regulator Replacement <input type="checkbox"/> Breath Tube Replacement <input type="checkbox"/> Other _____ </td> <td>_____</td> </tr> </tbody> </table>				Maintenance	By	<input type="checkbox"/> Battery Replacement <input type="checkbox"/> Dry Gas Regulator Replacement <input type="checkbox"/> Breath Tube Replacement <input type="checkbox"/> Other _____	_____
Simulator	Serial #	Lot #/Exp																									
0.050	MP6291	202201C 01-11-2024																									
0.080	MP6292	202201D 01-18-2024																									
0.200	MP6293	202201E 01-18-2024																									
0.080 DGS	N/A	AG113403 05-14-2023																									
Maintenance	By																										
<input type="checkbox"/> Battery Replacement <input type="checkbox"/> Dry Gas Regulator Replacement <input type="checkbox"/> Breath Tube Replacement <input type="checkbox"/> Other _____	_____																										

Calibration Adjustment	By	Department Inspection	By IS																																																												
Barometric Pressure Gauge _____ ID # _____ <table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> <input type="checkbox"/> Post Calibration Adjustment Stability Checks <table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>	Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A				Barometric Pressure ID# <u>26932</u> Gauge <u>1011</u> Instrument <u>1009</u> Mouth Alcohol Solution Lot # <u>2021-D</u> Acetone Stock Solution Lot # <u>2021-C</u> <table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td>MP6289</td> </tr> <tr> <td>Interferent</td> <td>MP6290</td> </tr> <tr> <td>0.050</td> <td>MP6291</td> </tr> <tr> <td>0.080</td> <td>MP6292</td> </tr> <tr> <td>0.200</td> <td>MP6293</td> </tr> </tbody> </table>	Simulator	Serial Number	0.000	MP6289	Interferent	MP6290	0.050	MP6291	0.080	MP6292	0.200	MP6293	
Simulator	Serial #	Lot #	Expiration																																																												
0.000		N/A	N/A																																																												
0.040																																																															
0.100																																																															
0.200																																																															
0.300																																																															
0.080 DGS	N/A																																																														
Simulator	Serial #	Lot #	Expiration																																																												
0.050																																																															
0.080																																																															
0.200																																																															
0.080 DGS	N/A																																																														
Simulator	Serial Number																																																														
0.000	MP6289																																																														
Interferent	MP6290																																																														
0.050	MP6291																																																														
0.080	MP6292																																																														
0.200	MP6293																																																														
		<table border="1"> <thead> <tr> <th>Attachments</th> </tr> </thead> <tbody> <tr> <td> <input checked="" type="checkbox"/> Form 41 <input checked="" type="checkbox"/> Stability Checks <input checked="" type="checkbox"/> Calibration Certificate <input type="checkbox"/> Calibration Adjustment <input type="checkbox"/> Post-Stability Checks <input type="checkbox"/> Flow Calibration <input type="checkbox"/> Form 40 <input type="checkbox"/> Other _____ </td> </tr> </tbody> </table>		Attachments	<input checked="" type="checkbox"/> Form 41 <input checked="" type="checkbox"/> Stability Checks <input checked="" type="checkbox"/> Calibration Certificate <input type="checkbox"/> Calibration Adjustment <input type="checkbox"/> Post-Stability Checks <input type="checkbox"/> Flow Calibration <input type="checkbox"/> Form 40 <input type="checkbox"/> Other _____																																																										
Attachments																																																															
<input checked="" type="checkbox"/> Form 41 <input checked="" type="checkbox"/> Stability Checks <input checked="" type="checkbox"/> Calibration Certificate <input type="checkbox"/> Calibration Adjustment <input type="checkbox"/> Post-Stability Checks <input type="checkbox"/> Flow Calibration <input type="checkbox"/> Form 40 <input type="checkbox"/> Other _____																																																															

Notes/Suggested Service: <u>0.050 g/210L Stability Check results not nominal, double checked simulator for leaks and tightened simulator, repeated test with nominal results. Instrument is an FDLE loaner, will return to evidential use when it is sent to an agency. IS</u> _____ _____	<input checked="" type="checkbox"/> Instrument Complies with Chapter 11D-8, FAC <input type="checkbox"/> Instrument Does Not Comply with Chapter 11D-8, FAC <input type="checkbox"/> Return to/Place into Evidentiary Use <input type="checkbox"/> Remain Out of Evidentiary Use <input checked="" type="checkbox"/> Conduct an Agency Inspection Before Evidentiary Use
Taylor Gutschow Tech Review / Date _____	Digitally signed by Taylor Gutschow Date: 2022.03.24 14:40:05 -0400 25 10:27:46 Admin Review / Date _____

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: FDLE

Time of Inspection: 14:16

Date of Inspection: 03/24/2022

Serial Number: 80-000227

Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202201C Exp: 01/11/2024	0.08g/210L Test (g/210L) Lot#:202201D Exp: 01/18/2024	0.20g/210L Test (g/210L) Lot#:202201E Exp: 01/18/2024,	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG113403 Exp: 05/14/2023
0.000	0.050	0.079	0.199	0.080
0.000	0.049	0.080	0.199	0.080
0.000	0.049	0.080	0.199	0.080
0.000	0.049	0.081	0.199	0.080
0.000	0.049	0.080	0.199	0.080
0.000	0.050	0.081	0.200	0.079
0.000	0.050	0.081	0.199	0.079
0.000	0.050	0.080	0.199	0.079
0.000	0.050	0.080	0.200	0.079
0.000	0.049	0.081	0.199	0.079

Standard Deviations	0.0005	0.0006	0.0004	0.0005
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0005 Number of Simulators Used: 5

Remarks:

The above instrument complies () does not comply () with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Israel Soto

ISRAEL SOTO

Signature and Printed Name

03/24/2022
Date

Stability Checks

FDLE
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000227
03/24/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:21
Control Test	0.049	11:22
Air Blank	0.000	11:22
Control Test	0.049	11:23
Air Blank	0.000	11:23
Control Test	0.046	11:24
Air Blank	0.000	11:25
Control Test Stats		
Average	0.0480	
Std Dev	0.0017	
Rel Std Dev(%)	3.6384	


Operator's Signature

FDLE
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000227
03/24/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	12:26
Control Test	0.049	12:26
Air Blank	0.000	12:27
Control Test	0.048	12:28
Air Blank	0.000	12:28
Control Test	0.048	12:29
Air Blank	0.000	12:29
Control Test Stats		
Average	0.0483	
Std Dev	0.0016	
Rel Std Dev(%)	1.1945	

Checked for leak,
tightened simulator


Operator's Signature

FDLE
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000227
03/24/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	12:31
Control Test	0.078	12:31
Air Blank	0.000	12:32
Control Test	0.080	12:33
Air Blank	0.000	12:33
Control Test	0.079	12:34
Air Blank	0.000	12:34
Control Test Stats		
Average	0.0790	
Std Dev	0.0010	
Rel Std Dev(%)	1.2658	

wet


Operator's Signature

FDLE
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000227
03/24/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	12:36
Control Test	0.199	12:36
Air Blank	0.000	12:37
Control Test	0.201	12:38
Air Blank	0.000	12:38
Control Test	0.199	12:39
Air Blank	0.000	12:39
Control Test Stats		
Average	0.1997	
Std Dev	0.0012	
Rel Std Dev(%)	0.5783	


Operator's Signature

FDLE
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000227
03/24/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	12:42
Control Test	0.079	12:42
Air Blank	0.000	12:43
Control Test	0.079	12:43
Air Blank	0.000	12:43
Control Test	0.079	12:44
Air Blank	0.000	12:44
Control Test Stats		
Average	0.0790	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Dry


Operator's Signature



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road.
Suite B1032
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000227, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000227</u>	UNCERTAINTY* ±	
Owning Agency:	<u>FDLE</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>03/24/2022</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>14:16</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence (k=3).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Israel Soto
Soto
Digitally signed by Israel Soto
Date: 2022.03.24 14:32:29 -04'00'

03/24/2022

Date

ISRAEL SOTO,

Department Inspector

FDLE/ATP Form 69 March 2022

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality



INSTRUMENT PROCESSING SHEET

Agency FDLES/N 80-000227Florida Department of
Law EnforcementDate In 7/1/2022

DI Completion Date _____

 Ship P/U H/D CMI EE

Intake	By TDG	Quality Checks	By TDG	Date <u>7/5/2022</u>	Flow Calibration	By	Date															
<input checked="" type="checkbox"/> Annual <input type="checkbox"/> Registration <input type="checkbox"/> Return from CMI / EE Visual Inspection: <input checked="" type="checkbox"/> Case <input checked="" type="checkbox"/> Handle <input checked="" type="checkbox"/> Keyboard <input checked="" type="checkbox"/> Dry Gas Shelf <input checked="" type="checkbox"/> Feet <input checked="" type="checkbox"/> Breath Tube <input checked="" type="checkbox"/> Ports <input checked="" type="checkbox"/> Screws Tight Other Equipment/ Accessories: <input checked="" type="checkbox"/> Power cord <input type="checkbox"/> Printer Cable <input checked="" type="checkbox"/> Static Bag <input type="checkbox"/> 12V DC Cable Notes: <u>FDLE Loaner. AI reported inappropriate Purge Fails and Interferent Detects.</u>		<input checked="" type="checkbox"/> Breath Tube Screen <input checked="" type="checkbox"/> Replace External O-Rings <input checked="" type="checkbox"/> Instrument Set Up Verified <input checked="" type="checkbox"/> R-Value <u>230</u> <input checked="" type="checkbox"/> Flow Verification (L/s) Flow Column # <u>ATP104</u> 32 mm <u>0.160</u> (.139 - .169) 36 mm <u>0.171</u> (.156 - .190) 53 mm <u>0.238</u> (.228 - .278) 103 mm <u>0.503</u> (.447 - .547) <input checked="" type="checkbox"/> Barometric Pressure Check Gauge ID # <u>68639</u> <input checked="" type="checkbox"/> Stability Checks			Flow Column # _____ <input type="checkbox"/> 5L/min - 17mm <input type="checkbox"/> 15L/min - 53mm <input type="checkbox"/> 30L/min - 103mm <input type="checkbox"/> R-Value _____ <input type="checkbox"/> Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																	
				<table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>MP4863</td> <td>202201C 01/11/2024</td> </tr> <tr> <td>0.080</td> <td>MP4864</td> <td>202201D 01/18/2024</td> </tr> <tr> <td>0.200</td> <td>MP5097</td> <td>202201E 01/18/2024</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG115904 06/08/2023</td> </tr> </tbody> </table>	Simulator	Serial #	Lot #/Exp	0.050	MP4863	202201C 01/11/2024	0.080	MP4864	202201D 01/18/2024	0.200	MP5097	202201E 01/18/2024	0.080 DGS	N/A	AG115904 06/08/2023	Maintenance By _____ <input type="checkbox"/> Battery Replacement <input type="checkbox"/> Dry Gas Regulator Replacement <input type="checkbox"/> Breath Tube Replacement <input type="checkbox"/> Other _____		
Simulator	Serial #	Lot #/Exp																				
0.050	MP4863	202201C 01/11/2024																				
0.080	MP4864	202201D 01/18/2024																				
0.200	MP5097	202201E 01/18/2024																				
0.080 DGS	N/A	AG115904 06/08/2023																				

Calibration Adjustment	By _____	Department Inspection	By _____																																																												
Barometric Pressure Gauge _____ ID # _____ <table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> <input type="checkbox"/> Post Calibration Adjustment Stability Checks <table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>	Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A				Barometric Pressure ID# _____ Gauge _____ Instrument _____ Mouth Alcohol Solution Lot # _____ Acetone Stock Solution Lot # _____ <table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> </tr> <tr> <td>Interferent</td> <td></td> </tr> <tr> <td>0.050</td> <td></td> </tr> <tr> <td>0.080</td> <td></td> </tr> <tr> <td>0.200</td> <td></td> </tr> </tbody> </table>	Simulator	Serial Number	0.000		Interferent		0.050		0.080		0.200		
Simulator	Serial #	Lot #	Expiration																																																												
0.000		N/A	N/A																																																												
0.040																																																															
0.100																																																															
0.200																																																															
0.300																																																															
0.080 DGS	N/A																																																														
Simulator	Serial #	Lot #	Expiration																																																												
0.050																																																															
0.080																																																															
0.200																																																															
0.080 DGS	N/A																																																														
Simulator	Serial Number																																																														
0.000																																																															
Interferent																																																															
0.050																																																															
0.080																																																															
0.200																																																															
Attachments <input type="checkbox"/> Form 41 <input checked="" type="checkbox"/> Stability Checks <input type="checkbox"/> Calibration Certificate <input type="checkbox"/> Calibration Adjustment		<input type="checkbox"/> Post-Stability Checks <input type="checkbox"/> Flow Calibration <input type="checkbox"/> Form 40 <input checked="" type="checkbox"/> Other <u>Form 51</u>																																																													

Notes/Suggested Service: <u>Checked the DVM screen. The s-value for the 3 micron channel oscillates broadly and rapidly. Will send to repair. (TDG)</u>	<input type="checkbox"/> Instrument Complies with Chapter 11D-8, FAC <input type="checkbox"/> Instrument Does Not Comply with Chapter 11D-8, FAC <input type="checkbox"/> Return to/Place into Evidentiary Use <input checked="" type="checkbox"/> Remain Out of Evidentiary Use <input type="checkbox"/> Conduct an Agency Inspection Before Evidentiary Use
Tech Review / Date _____	Admin Review / Date _____

Type of Test	Serial Number	Agency	Date	Performed By
Stabilities	80-000227	FDLE	07/05/2022	TDG ML

0.05g/210L 0.047 to 0.053	0.08g/210L 0.077 to 0.083	0.20g/210L 0.194 to 0.206	DGS 0.08g/210L 0.077 to 0.083 ≤0.003 of Wet																																																																		
<p>FDLE Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-000227 07/05/2022 Software: 8100.27</p> <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr> <td>Air Blank</td> <td>0.000</td> <td>11:37</td> </tr> <tr> <td>Control Test</td> <td>INT*</td> <td>11:38</td> </tr> <tr> <td>Air Blank</td> <td>AMB**</td> <td>11:38</td> </tr> <tr> <td>Air Blank</td> <td>AMB**</td> <td>11:39</td> </tr> </tbody> </table> <p>*Interferent Detect **Ambient Fail</p> <p>ML Operator's Signature</p>	Test	g/210L	Time	Air Blank	0.000	11:37	Control Test	INT*	11:38	Air Blank	AMB**	11:38	Air Blank	AMB**	11:39	<p>FDLE Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-000227 07/05/2022 Software: 8100.27</p> <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr> <td>Air Blank</td> <td>0.000</td> <td>11:44</td> </tr> <tr> <td>Control Test</td> <td>INT*</td> <td>11:45</td> </tr> <tr> <td>Air Blank</td> <td>0.000</td> <td>11:46</td> </tr> <tr> <td>Control Test</td> <td>INT*</td> <td>11:46</td> </tr> <tr> <td>Air Blank</td> <td>AMB**</td> <td>11:47</td> </tr> <tr> <td>Air Blank</td> <td>AMB**</td> <td>11:47</td> </tr> </tbody> </table> <p>*Interferent Detect **Ambient Fail</p> <p>ML Operator's Signature</p>	Test	g/210L	Time	Air Blank	0.000	11:44	Control Test	INT*	11:45	Air Blank	0.000	11:46	Control Test	INT*	11:46	Air Blank	AMB**	11:47	Air Blank	AMB**	11:47	<p>FDLE Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-000227 07/05/2022 Software: 8100.27</p> <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr> <td>Air Blank</td> <td>0.000</td> <td>11:56</td> </tr> <tr> <td>Control Test</td> <td>INT*</td> <td>11:57</td> </tr> <tr> <td>Air Blank</td> <td>AMB**</td> <td>11:58</td> </tr> <tr> <td>Air Blank</td> <td>0.000</td> <td>11:58</td> </tr> </tbody> </table> <p>*Interferent Detect **Ambient Fail</p> <p>ML Operator's Signature</p>	Test	g/210L	Time	Air Blank	0.000	11:56	Control Test	INT*	11:57	Air Blank	AMB**	11:58	Air Blank	0.000	11:58	<p style="text-align: center;">DGS</p> <p>FDLE Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-000227 07/05/2022 Software: 8100.27</p> <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr> <td>Air Blank</td> <td>0.000</td> <td>11:50</td> </tr> <tr> <td>Control Test</td> <td>INT*</td> <td>11:50</td> </tr> <tr> <td>Air Blank</td> <td>AMB**</td> <td>11:50</td> </tr> <tr> <td>Air Blank</td> <td>AMB**</td> <td>11:51</td> </tr> </tbody> </table> <p>*Interferent Detect **Ambient Fail</p> <p>ML Operator's Signature</p>	Test	g/210L	Time	Air Blank	0.000	11:50	Control Test	INT*	11:50	Air Blank	AMB**	11:50	Air Blank	AMB**	11:51
Test	g/210L	Time																																																																			
Air Blank	0.000	11:37																																																																			
Control Test	INT*	11:38																																																																			
Air Blank	AMB**	11:38																																																																			
Air Blank	AMB**	11:39																																																																			
Test	g/210L	Time																																																																			
Air Blank	0.000	11:44																																																																			
Control Test	INT*	11:45																																																																			
Air Blank	0.000	11:46																																																																			
Control Test	INT*	11:46																																																																			
Air Blank	AMB**	11:47																																																																			
Air Blank	AMB**	11:47																																																																			
Test	g/210L	Time																																																																			
Air Blank	0.000	11:56																																																																			
Control Test	INT*	11:57																																																																			
Air Blank	AMB**	11:58																																																																			
Air Blank	0.000	11:58																																																																			
Test	g/210L	Time																																																																			
Air Blank	0.000	11:50																																																																			
Control Test	INT*	11:50																																																																			
Air Blank	AMB**	11:50																																																																			
Air Blank	AMB**	11:51																																																																			

Comments:

Return Material Authorization

Ship to: CMI, Inc.

Enforcement Electronics

Shipment to repair facility authorized by: TJ Graham on 7/5/2022

Items Returned: Instrument Supplies Other Describe: _____

Instrument Model: Intoxilyzer 8000 Serial Number: 80-000227

Bill To Address:
Florida Department of Law Enforcement
Attn: TJ Graham

Ship to Address:
Florida Department of Law Enforcement
Fort Myers Regional Operations Center
Attn: Alcohol Testing Program
4700 Terminal Drive, Suite 1
Fort Myers, FL 33907

Reason for Return:

On the DVM screen, the s-value for the 3 micron channel oscillates broadly and rapidly. Keeps giving inappropriate Int Detect, Purge Fail, and Ambient Fail messages.

Please choose one of the following options:

- 1. I _____, authorize all repairs.
- 2. I _____, authorize repairs up to \$ _____.
- 3. I require an estimate **BEFORE** any repairs will be authorized and/ or conducted.

Please contact: Name: TJ Graham

Phone #: 850-631-1351 Email: ThomasGraham@fdle.state.fl.us

ATP Contact Name: Taylor Gutschow ATP Email: TaylorGutschow@fdle.state.fl.us