



INSTRUMENT PROCESSING SHEET

Agency Calhoun County Sheriff's OfficeS/N 80-000875Florida Department of
Law EnforcementDate In 1/3/2022DI Completion Date 1/4/2022☐ Ship ☒ P/U ☐ H/D ☐ CMI ☐ EE

Intake	By IS	Quality Checks	By IS	Date <u>01-03-2022</u>	Flow Calibration	By	Date																																																											
☒ Annual ☐ Registration ☒ Return from CMI / EE Visual Inspection: ☒ Case ☐ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>223</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP-102</u> 32 mm <u>0.164</u> (.139 - .169) 36 mm <u>0.179</u> (.156 - .190) 53 mm <u>0.246</u> (.228 - .278) 103 mm <u>0.511</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>30793</u> ☒ Stability Checks			Flow Column # _____ ☐ 5L/min - 17mm ☐ 15L/min - 53mm ☐ 30L/min - 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																																													
		<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP5088</td><td>202010A 10-05-2022</td></tr><tr><td>0.080</td><td>MP5089</td><td>202010B 10-05-2022</td></tr><tr><td>0.200</td><td>MP5090</td><td>202010D 10-06-2022</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG113403 05-14-2023</td></tr></tbody></table>			Simulator	Serial #	Lot #/Exp	0.050	MP5088	202010A 10-05-2022	0.080	MP5089	202010B 10-05-2022	0.200	MP5090	202010D 10-06-2022	0.080 DGS	N/A	AG113403 05-14-2023	Maintenance By _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____																																														
Simulator	Serial #	Lot #/Exp																																																																
0.050	MP5088	202010A 10-05-2022																																																																
0.080	MP5089	202010B 10-05-2022																																																																
0.200	MP5090	202010D 10-06-2022																																																																
0.080 DGS	N/A	AG113403 05-14-2023																																																																
		DI Temp. Checks By IS ☒ Lab Temp °C <u>21.88</u> External Digital Therm. ID#: <u>381189</u> ☒ 34°C +/-2 Serial #: <u>MP5088</u> ☒ 34°C +/-2 Serial #: <u>MP5089</u> ☒ 34°C +/-2 Serial #: <u>MP5090</u>																																																																
Calibration Adjustment By _____ Barometric Pressure Gauge _____ ID # _____ <table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td></td><td></td><td></td></tr><tr><td>0.100</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.300</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table> ☐ Post Calibration Adjustment Stability Checks <table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td></td><td></td><td></td></tr><tr><td>0.080</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Department Inspection By IS Barometric Pressure ID# <u>28421</u> Gauge <u>1025</u> Instrument <u>1023</u> Mouth Alcohol Solution Lot # <u>2021-B</u> Acetone Stock Solution Lot # <u>2021-C</u> <table border="1"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td>MP5086</td></tr><tr><td>Interferent</td><td>MP5087</td></tr><tr><td>0.050</td><td>MP5088</td></tr><tr><td>0.080</td><td>MP5089</td></tr><tr><td>0.200</td><td>MP5090</td></tr></tbody></table> Attachments <table border="1"><tbody><tr><td>☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment</td><td>☐ Post-Stability Checks ☐ Flow Calibration ☒ Form 40 ☒ Other <u>Form 51</u></td></tr></tbody></table>			Simulator	Serial Number	0.000	MP5086	Interferent	MP5087	0.050	MP5088	0.080	MP5089	0.200	MP5090	☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment	☐ Post-Stability Checks ☐ Flow Calibration ☒ Form 40 ☒ Other <u>Form 51</u>
Simulator	Serial #	Lot #	Expiration																																																															
0.000		N/A	N/A																																																															
0.040																																																																		
0.100																																																																		
0.200																																																																		
0.300																																																																		
0.080 DGS	N/A																																																																	
Simulator	Serial #	Lot #	Expiration																																																															
0.050																																																																		
0.080																																																																		
0.200																																																																		
0.080 DGS	N/A																																																																	
Simulator	Serial Number																																																																	
0.000	MP5086																																																																	
Interferent	MP5087																																																																	
0.050	MP5088																																																																	
0.080	MP5089																																																																	
0.200	MP5090																																																																	
☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment	☐ Post-Stability Checks ☐ Flow Calibration ☒ Form 40 ☒ Other <u>Form 51</u>																																																																	
Notes/Suggested Service: _____ _____ _____ _____ _____ _____ _____ _____ _____		☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use 2022.01.05 15:05:11 Richard A Williams Digitally signed by Richard A Williams Date: 2022.01.04 16:07:05 -0500 Tech Review / Date _____ Admin Review / Date _____																																																																

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: CALHOUN COUNTY SO
Time of Inspection: 09:26

Date of Inspection: 01/04/2022

Serial Number: 80-000875
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202010A Exp: 10/05/2022	0.08g/210L Test (g/210L) Lot#:202010B Exp: 10/05/2022	0.20g/210L Test (g/210L) Lot#:202010D Exp: 10/06/2022	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG113403 Exp: 05/14/2023
0.000	0.051	0.082	0.203	0.080
0.000	0.051	0.081	0.202	0.079
0.000	0.052	0.081	0.203	0.080
0.000	0.051	0.081	0.202	0.079
0.000	0.052	0.082	0.202	0.080
0.000	0.051	0.081	0.202	0.079
0.000	0.051	0.081	0.203	0.079
0.000	0.051	0.082	0.202	0.079
0.000	0.052	0.081	0.202	0.080
0.000	0.051	0.082	0.202	0.079

Standard Deviations	0.0004	0.0005	0.0004	0.0005
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0004 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



ISRAEL SOTO

Signature and Printed Name

01/04/2022
Date

stability checks

CALHOUN COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000875
01/03/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	15:46
Control Test	0.049	15:47
Air Blank	0.000	15:47
Control Test	0.048	15:48
Air Blank	0.000	15:49
Control Test	0.049	15:49
Air Blank	0.000	15:50
Control Test Stats		
Average	0.0487	
Std Dev	0.0006	
Rel Std Dev(%)	1.1863	

Operator's Signature

CALHOUN COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000875
01/03/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	15:51
Control Test	0.080	15:51
Air Blank	0.000	15:52
Control Test	0.079	15:53
Air Blank	0.000	15:53
Control Test	0.079	15:54
Air Blank	0.000	15:55
Control Test Stats		
Average	0.0793	
Std Dev	0.0006	
Rel Std Dev(%)	0.7277	

wet

Operator's Signature

CALHOUN COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000875
01/03/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	15:55
Control Test	0.201	15:56
Air Blank	0.000	15:57
Control Test	0.199	15:57
Air Blank	0.000	15:58
Control Test	0.198	15:59
Air Blank	0.000	15:59
Control Test Stats		
Average	0.1993	
Std Dev	0.0015	
Rel Std Dev(%)	0.7663	

Operator's Signature

CALHOUN COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000875
01/03/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	16:00
Control Test	0.080	16:01
Air Blank	0.000	16:01
Control Test	0.080	16:01
Air Blank	0.000	16:02
Control Test	0.080	16:02
Air Blank	0.000	16:03
Control Test Stats		
Average	0.0800	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Dry

Operator's Signature



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2729 Fort Knox Blvd.
Bldg. 2, Suite 1300
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000875, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000875</u>	UNCERTAINTY* $\pm$
Owning Agency:	<u>CALHOUN COUNTY SO</u>	0.050 g/ 210 L 0.005
Calibration Date:	<u>01/04/2022</u>	0.080 g/ 210 L 0.004
Calibration Time:	<u>09:26</u>	0.200 g/ 210 L 0.007
		0.080 g/ 210 L Dry Gas Control 0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.
This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Israel Soto
Soto
Digitally signed by Israel Soto
Date: 2022.01.04 10:29:26 -05'00'

01/04/2022

Date

ISRAEL SOTO,

Department Inspector

FDLE/ATP Form 69 December 2021

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

Florida Department of Law Enforcement Alcohol Testing Program

AGENCY INSPECTION REPORT - INTOXILYZER 8000

Agency: CALHOUN COUNTY SO
Time of Inspection: 15:06

Date of Inspection: 01/03/2022

Serial Number: 80-000875
Software: 8100.27

Check or Test	YES	NO
Date and/or Time Adjusted		No
Diagnostic Check (Pre-Inspection): OK		No
Alcohol Free Subject Test: 0.000		No
Mouth Alcohol Test: Slope Not Met		No
Interferent Detect Test: Interferent Detect		No
Diagnostic Check (Post-Inspection): OK		No

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#: _____ Exp: _____	0.08g/210L Test (g/210L) Lot#: _____ Exp: _____	0.20g/210L Test (g/210L) Lot#: _____ Exp: _____	0.08 g/210L Dry Gas Std Test (g/210L) Lot#: _____ Exp: _____

Number of Simulators Used: _____

Remarks:

BYPASSED AI TO OPERATE INSTRUMENT

N/A Compliance not determined

The above instrument complies (☒) does not comply () with Chapter 11D-8, FAC.

I certify that I hold a valid Florida Department of Law Enforcement Agency Inspector Permit and that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Israel Soto

ISRAEL SOTO

Signature and Printed Name

01/03/2022
Date

Return Material Authorization

Ship to:



CMI, Inc.



Enforcement Electronics

Shipment to repair facility authorized by: Sue Barge on 10/7/2021

Items Returned: Instrument ☒ Supplies ☐ Other ☐ Describe: _____

Instrument Model: Intoxilyzer 8000 Serial Number: 80-000875

Bill To Address:
Calhoun County SO

Ship to Address:

FDLE/ATP

813B Lake Bradford Road

Tallahassee, FL 32304

Reason for Return:

Modem jack is pushed into the unit. Data was cleared at FDLE prior to shipping.

Please choose one of the following options:

- ☐ 1. I _____, authorize all repairs.
- ☐ 2. I _____, authorize repairs up to \$_____.
- ☒ 3. I require an estimate **BEFORE** any repairs will be authorized and/ or conducted.

Please contact: Name: Sue Barge

Phone #: 352-620-4701 Email: SusanBarge@flhsmv.gov

ATP Contact Name: Israel Soto ATP Email: IsraelSoto@fdle.state.fl.us



INSTRUMENT PROCESSING SHEET

Agency Calhoun County Sheriff's Office

S/N 80-000875

Florida Department of
Law Enforcement

Date In 10/7/2021

DI Completion Date _____

☐ Ship

☐ P/U

☐ H/D

☒ CMI

☐ EE

Intake	By	IS	Quality Checks	By	Date	Flow Calibration	By	Date																																																												
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes: Modem port is pushed into case, cannot connect phone line cable for uploads.			☐ Breath Tube Screen ☐ Replace External O-Rings ☐ Instrument Set Up Verified ☐ R-Value _____ ☐ Flow Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547) ☐ Barometric Pressure Check Gauge ID # _____ ☐ Stability Checks			Flow Column # _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																																														
			<table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> </tr> </tbody> </table>			Simulator	Serial #	Lot #/Exp	0.050			0.080			0.200			0.080 DGS	N/A		Maintenance By _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____			DI Temp. Checks By _____ ☐ Lab Temp °C _____ External Digital Therm. ID#: _____ ☐ 34°C +/- .2 Serial #: _____ ☐ 34°C +/- .2 Serial #: _____ ☐ 34°C +/- .2 Serial #: _____																																												
Simulator	Serial #	Lot #/Exp																																																																		
0.050																																																																				
0.080																																																																				
0.200																																																																				
0.080 DGS	N/A																																																																			
Calibration Adjustment By _____			Department Inspection By _____																																																																	
Barometric Pressure Gauge _____ ID # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> ☐ Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>			Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Barometric Pressure ID# _____ Gauge _____ Instrument _____ Mouth Alcohol Solution Lot # _____ Acetone Stock Solution Lot # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> </tr> <tr> <td>Interferent</td> <td></td> </tr> <tr> <td>0.050</td> <td></td> </tr> <tr> <td>0.080</td> <td></td> </tr> <tr> <td>0.200</td> <td></td> </tr> </tbody> </table>						Simulator	Serial Number	0.000		Interferent		0.050		0.080		0.200	
Simulator	Serial #	Lot #	Expiration																																																																	
0.000		N/A	N/A																																																																	
0.040																																																																				
0.100																																																																				
0.200																																																																				
0.300																																																																				
0.080 DGS	N/A																																																																			
Simulator	Serial #	Lot #	Expiration																																																																	
0.050																																																																				
0.080																																																																				
0.200																																																																				
0.080 DGS	N/A																																																																			
Simulator	Serial Number																																																																			
0.000																																																																				
Interferent																																																																				
0.050																																																																				
0.080																																																																				
0.200																																																																				
Notes/Suggested Service: <u>Shipping instrument to fix the pushed in modem port.</u> <u>Instrument uploaded through direct connect prior to shipping.</u> <u>Compliance with 11D-8 FAC was not checked on this day. IS 10-07-2021</u>			Attachments ☐ Form 41 ☐ Stability Checks ☐ Calibration Certificate ☐ Calibration Adjustment ☐ Post-Stability Checks ☐ Flow Calibration ☐ Form 40 ☐ Other _____ ☐ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☐ Return to/Place into Evidentiary Use ☒ Remain Out of Evidentiary Use ☐ Conduct an Agency Inspection Before Evidentiary Use Tech Review / Date _____ Admin Review / Date _____																																																																	