

Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-001000 , manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-001000</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>COCO A PD</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>07/25/2022</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>14:20</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.
*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.
This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

07/25/2022

Date

DAVID E REYES-RIVERA,
Department Inspector

FDLE/ATP Form 69 December 2021

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: COCOA PD

Time of Inspection: 14:20

Date of Inspection: 07/25/2022

Serial Number: 80-001000

Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202201C Exp: 01/11/2024	0.08g/210L Test (g/210L) Lot#:202201D Exp: 01/18/2024	0.20g/210L Test (g/210L) Lot#:202201E Exp: 01/18/2024	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG115904 Exp: 06/08/2023
0.000	0.049	0.078	0.199	0.079
0.000	0.049	0.079	0.199	0.078
0.000	0.049	0.079	0.200	0.079
0.000	0.049	0.079	0.199	0.078
0.000	0.049	0.079	0.199	0.078
0.000	0.049	0.079	0.199	0.079
0.000	0.049	0.079	0.199	0.078
0.000	0.049	0.079	0.199	0.078
0.000	0.049	0.079	0.199	0.078
0.000	0.049	0.078	0.199	0.078


Standard Deviations	0.0000	0.0004	0.0003	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0002 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



DAVID E REYES-RIVERA
Signature and Printed Name

07/25/2022
Date

Type of Test	Serial Number	Agency	Date	Performed By
Stabilities Continued	80-001000	Cocoa Police Department	7/25/2022	DERR <i>[Signature]</i>

☐	☐	☒	0.077 to 0.083 ☐																																				
COCOA PC Intoxilyzer - Alcohol Analyzer Model: 8000 07/25/2022 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>10:24</td></tr> <tr><td>Control Test</td><td>0.200</td><td>10:24</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:25</td></tr> <tr><td>Control Test</td><td>0.199</td><td>10:25</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:26</td></tr> <tr><td>Control Test</td><td>0.199</td><td>10:27</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:27</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.1993</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel Std Dev(2)</td><td>0.2896</td><td></td></tr> </tbody> </table> Operator's Signature <i>[Signature]</i>				Test	g/210L	Time	Air Blank	0.000	10:24	Control Test	0.200	10:24	Air Blank	0.000	10:25	Control Test	0.199	10:25	Air Blank	0.000	10:26	Control Test	0.199	10:27	Air Blank	0.000	10:27	Control Test Stats			Average	0.1993		Std Dev	0.0006		Rel Std Dev(2)	0.2896	
Test	g/210L	Time																																					
Air Blank	0.000	10:24																																					
Control Test	0.200	10:24																																					
Air Blank	0.000	10:25																																					
Control Test	0.199	10:25																																					
Air Blank	0.000	10:26																																					
Control Test	0.199	10:27																																					
Air Blank	0.000	10:27																																					
Control Test Stats																																							
Average	0.1993																																						
Std Dev	0.0006																																						
Rel Std Dev(2)	0.2896																																						
X X X																																							
Simulator was changed to MP5094 there is a leak on SD3968. DERR 7/25/22 <i>[Signature]</i>																																							

Type of Test	Serial Number	Agency	Date	Performed By
Stabilities	80-001000	Cocoa Police Department	7/25/2022	DERR <i>ML</i>

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L
0.047 to 0.053 ☒	0.077 to 0.083 ☒	0.194 to 0.206 ☒	0.077 to 0.083 ☒
COCOA PD Intoxilyzer - Alcohol Analyzer Model 8000 07/25/2022 Software: 8100.27 Test g/210L Time Air Blank 0.000 09:26 Control Test 0.049 09:27 Air Blank 0.000 09:27 Control Test 0.049 09:28 Air Blank 0.000 09:28 Control Test 0.049 09:29 Air Blank 0.000 09:29 Control Test Stats Average 0.0490 Std Dev 0.0000 Rel Std Dev(%) 0.0000 Operator's Signature <i>ML</i>	COCOA PD Intoxilyzer - Alcohol Analyzer Model 8000 07/25/2022 Software: 8100.27 Test g/210L Time Air Blank 0.000 09:31 Control Test 0.078 09:31 Air Blank 0.000 09:32 Control Test 0.077 09:32 Air Blank 0.000 09:33 Control Test 0.078 09:33 Air Blank 0.000 09:34 Control Test Stats Average 0.0777 Std Dev 0.0006 Rel Std Dev(%) 0.7434 Operator's Signature <i>ML</i>	COCOA PD Intoxilyzer - Alcohol Analyzer Model 8000 07/25/2022 Software: 8100.27 Test g/210L Time Air Blank 0.000 09:36 Control Test 0.188 09:37 Air Blank 0.000 09:37 Control Test 0.190 09:38 Air Blank 0.000 09:39 Control Test 0.188 09:39 Air Blank 0.000 09:40 Control Test Stats Average 0.1887 Std Dev 0.0012 Rel Std Dev(%) 0.6120 Operator's Signature <i>ML</i>	COCOA PD Intoxilyzer - Alcohol Analyzer Model 8000 07/25/2022 Software: 8100.27 Test g/210L Time Air Blank 0.000 09:42 Control Test 0.079 09:42 Air Blank 0.000 09:42 Control Test 0.080 09:43 Air Blank 0.000 09:43 Control Test 0.079 09:43 Air Blank 0.000 09:44 Control Test Stats Average 0.0753 Std Dev 0.0006 Rel Std Dev(%) 0.7277 Operator's Signature <i>ML</i>