



INSTRUMENT PROCESSING SHEET

Agency Tarpon Springs Police Department

S/N 80-001065

Florida Department of
Law Enforcement

Date In 08-09-2022 IS 08-15-2022

DI Completion Date 08-12-2022

☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake	By IS	Quality Checks	By IS	Date <u>08-12-2022</u>	Flow Calibration	By	Date															
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: Instrument is displaying "Error 17 Contact CMI".		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>212</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP-105</u> 32 mm <u>0.156</u> (.139 - .169) 36 mm <u>0.171</u> (.156 - .190) 53 mm <u>0.242</u> (.228 - .278) 103 mm <u>0.523</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>28427</u> ☒ Stability Checks			Flow Column # _____ ☐ 5L/min - 17mm ☐ 15L/min - 53mm ☐ 30L/min - 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																	
		<table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>MP6291</td> <td>202201C 01-11-2024</td> </tr> <tr> <td>0.080</td> <td>MP6292</td> <td>202201D 01-18-2024</td> </tr> <tr> <td>0.200</td> <td>MP6293</td> <td>202201E 01-18-2024</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>08121080A1 05-05-2023</td> </tr> </tbody> </table>			Simulator	Serial #	Lot #/Exp	0.050	MP6291	202201C 01-11-2024	0.080	MP6292	202201D 01-18-2024	0.200	MP6293	202201E 01-18-2024	0.080 DGS	N/A	08121080A1 05-05-2023	Maintenance By IS _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☒ Other <u>CMI corrected Error 17</u> <u>remotely through phone line.</u>		
Simulator	Serial #	Lot #/Exp																				
0.050	MP6291	202201C 01-11-2024																				
0.080	MP6292	202201D 01-18-2024																				
0.200	MP6293	202201E 01-18-2024																				
0.080 DGS	N/A	08121080A1 05-05-2023																				

Calibration Adjustment	By	Department Inspection	By IS																																																												
Barometric Pressure Gauge _____ ID # _____ <table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> ☐ Post Calibration Adjustment Stability Checks <table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>		Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Barometric Pressure ID# <u>30793</u> Gauge <u>1015</u> Instrument <u>1012</u> Mouth Alcohol Solution Lot # <u>2022-A</u> Acetone Stock Solution Lot # <u>2022-B</u> <table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td>MP6289</td> </tr> <tr> <td>Interferent</td> <td>MP6290</td> </tr> <tr> <td>0.050</td> <td>MP6291</td> </tr> <tr> <td>0.080</td> <td>MP6292</td> </tr> <tr> <td>0.200</td> <td>MP6293</td> </tr> </tbody> </table>		Simulator	Serial Number	0.000	MP6289	Interferent	MP6290	0.050	MP6291	0.080	MP6292	0.200	MP6293
Simulator	Serial #	Lot #	Expiration																																																												
0.000		N/A	N/A																																																												
0.040																																																															
0.100																																																															
0.200																																																															
0.300																																																															
0.080 DGS	N/A																																																														
Simulator	Serial #	Lot #	Expiration																																																												
0.050																																																															
0.080																																																															
0.200																																																															
0.080 DGS	N/A																																																														
Simulator	Serial Number																																																														
0.000	MP6289																																																														
Interferent	MP6290																																																														
0.050	MP6291																																																														
0.080	MP6292																																																														
0.200	MP6293																																																														
Notes/Suggested Service: <u>Error 17 corrected by CMI</u> <u>prior to Quality Checks and Department Inspection. IS</u> Tech Review: Corrected instrument Date-In _____ Instrument was picked up from agency on 08-08-2022 and brought to ATP. IS 08-15-2022		Attachments ☒ Form 41 ☐ Post-Stability Checks ☒ Stability Checks ☐ Flow Calibration ☒ Calibration Certificate ☐ Form 40 ☐ Calibration Adjustment ☐ Other _____ ☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use <u>2022.08.</u>																																																													
Tech Review / Date _____		Admin Review / Date _____ Taylor Gutschow 16 09:59:23 Digitally signed by Taylor Gutschow Date: 2022.08.15 09:55:26 -0400																																																													

Florida Department of Law Enforcement

Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: TARPON SPRINGS PD
Time of Inspection: 12:35

Date of Inspection: 08/12/2022

Serial Number: 80-001065
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202201C Exp: 01/11/2024	0.08g/210L Test (g/210L) Lot#:202201D Exp: 01/18/2024	0.20g/210L Test (g/210L) Lot#:202201E Exp: 01/18/2024	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:08121080A1 Exp: 05/05/2023
0.000	0.050	0.080	0.203	0.079
0.000	0.049	0.080	0.203	0.080
0.000	0.049	0.080	0.203	0.080
0.000	0.050	0.080	0.203	0.080
0.000	0.049	0.080	0.203	0.079
0.000	0.049	0.079	0.203	0.080
0.000	0.050	0.079	0.204	0.081
0.000	0.050	0.080	0.203	0.080
0.000	0.049	0.080	0.203	0.080
0.000	0.050	0.079	0.203	0.080

Standard Deviations	0.0005	0.0004	0.0003	0.0005
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0004 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Israel Soto ISRAEL SOTO
Signature and Printed Name

08/12/2022
Date

stability checks

TARPON SPRINGS PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001065
08/12/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:43
Control Test	0.050	10:43
Air Blank	0.000	10:44
Control Test	0.050	10:45
Air Blank	0.000	10:45
Control Test	0.048	10:46
Air Blank	0.000	10:46
Control Test Stats		
Average	0.0493	
Std Dev	0.0012	
Rel Std Dev(%)	2.3406	


Operator's Signature

TARPON SPRINGS PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001065
08/12/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:48
Control Test	0.079	10:48
Air Blank	0.000	10:49
Control Test	0.079	10:50
Air Blank	0.000	10:50
Control Test	0.079	10:51
Air Blank	0.000	10:51
Control Test Stats		
Average	0.0790	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

wet


Operator's Signature

TARPON SPRINGS PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001065
08/12/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:53
Control Test	0.203	10:54
Air Blank	0.000	10:55
Control Test	0.201	10:55
Air Blank	0.000	10:56
Control Test	0.201	10:57
Air Blank	0.000	10:57
Control Test Stats		
Average	0.2017	
Std Dev	0.0012	
Rel Std Dev(%)	0.5726	


Operator's Signature

TARPON SPRINGS PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-001065
08/12/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:59
Control Test	0.080	11:00
Air Blank	0.000	11:00
Control Test	0.080	11:00
Air Blank	0.000	11:01
Control Test	0.081	11:01
Air Blank	0.000	11:02
Control Test Stats		
Average	0.0803	
Std Dev	0.0006	
Rel Std Dev(%)	0.7187	

Dry


Operator's Signature



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road.
Suite B1032
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-001065, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-001065</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>TARPON SPRINGS PD</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>08/12/2022</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>12:35</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Israel Soto
Soto
Digitally signed by Israel Soto
Date: 2022.08.12 13:02:07 -04'00'

08/12/2022

Date

ISRAEL SOTO,

Department Inspector

FDLE/ATP Form 69 March 2022

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality