



INSTRUMENT PROCESSING SHEET

Agency High Springs Police DepartmentS/N 80-001283Florida Department of
Law EnforcementDate In 12/28/2022 DI Completion Date 12/29/2022☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake	By PN	Quality Checks	By PN	Date <u>12/29/2022</u>	Flow Calibration	By	Date																																										
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>183</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP 105</u> 32 mm <u>.156</u> (.139 - .169) 36 mm <u>.164</u> (.156 - .190) 53 mm <u>.246</u> (.228 - .278) 103 mm <u>.527</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>28421</u> ☒ Stability Checks			Flow Column # _____ ☐ 5L/min - 17mm ☐ 15L/min - 53mm ☐ 30L/min - 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																												
		<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP5088</td><td>202201C 01/11/2024</td></tr><tr><td>0.080</td><td>MP5089</td><td>202201D 01/18/2024</td></tr><tr><td>0.200</td><td>MP5084</td><td>202201E 01/18/2024</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG229803 10/25/2024</td></tr></tbody></table>			Simulator	Serial #	Lot #/Exp	0.050	MP5088	202201C 01/11/2024	0.080	MP5089	202201D 01/18/2024	0.200	MP5084	202201E 01/18/2024	0.080 DGS	N/A	AG229803 10/25/2024	<table border="1"><thead><tr><th colspan="2">Maintenance</th><th>By</th></tr></thead><tbody><tr><td>☐ Battery Replacement</td><td></td><td></td></tr><tr><td>☐ Dry Gas Regulator Replacement</td><td></td><td></td></tr><tr><td>☐ Breath Tube Replacement</td><td></td><td></td></tr><tr><td>☐ Other _____</td><td></td><td></td></tr><tr><td>_____</td><td></td><td></td></tr><tr><td>_____</td><td></td><td></td></tr><tr><td>_____</td><td></td><td></td></tr><tr><td>_____</td><td></td><td></td></tr></tbody></table>			Maintenance		By	☐ Battery Replacement			☐ Dry Gas Regulator Replacement			☐ Breath Tube Replacement			☐ Other _____			_____			_____			_____			_____		
Simulator	Serial #	Lot #/Exp																																															
0.050	MP5088	202201C 01/11/2024																																															
0.080	MP5089	202201D 01/18/2024																																															
0.200	MP5084	202201E 01/18/2024																																															
0.080 DGS	N/A	AG229803 10/25/2024																																															
Maintenance		By																																															
☐ Battery Replacement																																																	
☐ Dry Gas Regulator Replacement																																																	
☐ Breath Tube Replacement																																																	
☐ Other _____																																																	

Calibration Adjustment		By _____			Department Inspection			By <u>PN</u> _____																																									
Barometric Pressure Gauge _____ ID # _____					Barometric Pressure ID# <u>28421</u>																																												
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td></td><td></td><td></td></tr><tr><td>0.100</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.300</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A						Gauge <u>1025</u> Instrument <u>1022</u>																
Simulator	Serial #	Lot #	Expiration																																														
0.000		N/A	N/A																																														
0.040																																																	
0.100																																																	
0.200																																																	
0.300																																																	
0.080 DGS	N/A																																																
					Mouth Alcohol Solution Lot # <u>2022-A</u>																																												
					Acetone Stock Solution Lot # <u>2022-B</u>																																												
					<table border="1"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td>MP5086</td></tr><tr><td>Interferent</td><td>MP5087</td></tr><tr><td>0.050</td><td>MP5088</td></tr><tr><td>0.080</td><td>MP5089</td></tr><tr><td>0.200</td><td>MP5084</td></tr></tbody></table>			Simulator	Serial Number	0.000	MP5086	Interferent	MP5087	0.050	MP5088	0.080	MP5089	0.200	MP5084																														
Simulator	Serial Number																																																
0.000	MP5086																																																
Interferent	MP5087																																																
0.050	MP5088																																																
0.080	MP5089																																																
0.200	MP5084																																																
☐ Post Calibration Adjustment Stability Checks					Attachments																																												
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td></td><td></td><td></td></tr><tr><td>0.080</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A						☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment			☐ Post-Stability Checks ☐ Flow Calibration ☒ Form 40 ☐ Other _____																					
Simulator	Serial #	Lot #	Expiration																																														
0.050																																																	
0.080																																																	
0.200																																																	
0.080 DGS	N/A																																																
Notes/Suggested Service: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____					☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use																																												
					David Eliezer Reyes-Rivera			12:26:21 05:00																																									
					Tech Review / Date			Admin Review / Date																																									

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: HIGH SPRINGS PD
Time of Inspection: 11:45

Date of Inspection: 12/29/2022

Serial Number: 80-001283
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202201C Exp: 01/11/2024	0.08g/210L Test (g/210L) Lot#:202201D Exp: 01/18/2024	0.20g/210L Test (g/210L) Lot#:202201E Exp: 01/18/2024	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG229803 Exp: 10/25/2024
0.000	0.050	0.079	0.202	0.080
0.000	0.051	0.080	0.202	0.080
0.000	0.051	0.080	0.202	0.080
0.000	0.051	0.079	0.202	0.080
0.000	0.051	0.079	0.203	0.080
0.000	0.051	0.078	0.203	0.080
0.000	0.051	0.078	0.202	0.080
0.000	0.051	0.078	0.202	0.080
0.000	0.051	0.079	0.202	0.080
0.000	0.051	0.079	0.203	0.080


Standard Deviations	0.0003	0.0007	0.0004	0.0000
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0003 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



PHIL NICODEMO

Signature and Printed Name

12/29/2022
Date

Type of Test	Serial Number	Agency	Date	Performed By
Stability Checks	80-001283	High Springs Police Department	12/29/2022	PN
0.05g/210L	0.047 to 0.053	0.08g/210L	0.20g/210L	DGS 0.08g/210L
0.047 to 0.053	0.077 to 0.083	0.194 to 0.206	0.077 to 0.083	≤0.003 of Wet
HIGH SPRINGS PD Intoxilyzer - Alcotest Analyzer Model 8000 12/29/2022 Software: 8100.27 Testg/210LTime Air Blank0.00009:32 Control Test0.05209:32 Air Blank0.00009:33 Control Test0.05009:34 Air Blank0.00009:34 Control Test0.05109:35 Air Blank0.00009:35 Control Test Stats Average0.0510 Std Dev0.0010 Rel Std Dev(%)1.9608 Operator's Signature	HIGH SPRINGS PD Intoxilyzer - Alcotest Analyzer Model 8000 12/29/2022 Software: 8100.27 Testg/210LTime Air Blank0.00009:36 Control Test0.08009:37 Air Blank0.00009:38 Control Test0.07909:39 Air Blank0.00009:40 Control Test0.08009:40 Air Blank0.00009:40 Control Test Stats Average0.0797 Std Dev0.0006 Rel Std Dev(%)0.7247 Operator's Signature	HIGH SPRINGS PD Intoxilyzer - Alcotest Analyzer Model 8000 12/29/2022 Software: 8100.27 Testg/210LTime Air Blank0.00009:41 Control Test0.20109:42 Air Blank0.00009:42 Control Test0.20109:43 Air Blank0.00009:44 Control Test0.20009:44 Air Blank0.00009:45 Control Test Stats Average0.2007 Std Dev0.0006 Rel Std Dev(%)0.2877 Operator's Signature	HIGH SPRINGS PD Intoxilyzer - Alcotest Analyzer Model 8000 12/29/2022 Software: 8100.27 Testg/210LTime Air Blank0.00009:46 Control Test0.08009:47 Air Blank0.00009:47 Control Test0.08009:47 Air Blank0.00009:48 Control Test0.08009:48 Air Blank0.00009:49 Control Test Stats Average0.0800 Std Dev0.0000 Rel Std Dev(%)0.0000 Operator's Signature	

Comments: N/A

Florida Department of Law Enforcement Alcohol Testing Program

AGENCY INSPECTION REPORT - INTOXILYZER 8000

Agency: HIGH SPRINGS PD
Time of Inspection: 09:11

Date of Inspection: 12/29/2022

Serial Number: 80-001283
Software: 8100.27

Check or Test	YES	NO
Date and/or Time Adjusted	Yes	
Diagnostic Check (Pre-Inspection): OK	Yes	
Alcohol Free Subject Test: 0.000		No
Mouth Alcohol Test: Slope Not Met		No
Interferent Detect Test: Interferent Detect		No
Diagnostic Check (Post-Inspection): OK		No

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#: Exp:	0.08g/210L Test (g/210L) Lot#: Exp:	0.20g/210L Test (g/210L) Lot#: Exp:	0.08 g/210L Dry Gas Std Test (g/210L) Lot#: Exp:

Number of Simulators Used: 5

Remarks:

Time-Date changed.BYPASSED TO OPERATE INSTRUMENT

Compliance NOT DETERMINED
P.N 12/29/2022

The above instrument complies (☒) does not comply () with Chapter 11D-8, FAC.

I certify that I hold a valid Florida Department of Law Enforcement Agency Inspector Permit and that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



PHIL NICODEMO

Signature and Printed Name

12/29/2022
Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road.
Suite B1032
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-001283, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-001283</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>HIGH SPRINGS PD</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>12/29/2022</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>11:45</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Phil Nicodemo
Digitally signed by Phil
Nicodemo
Date: 2022.12.29 15:26:21
+05'00'

12/29/2022

Date

PHIL NICODEMO,
Department Inspector

FDLE/ATP Form 69 March 2022
Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality