

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: MIAMI DADE PD
Time of Inspection: 08:56

Date of Inspection: 03/01/2022

Serial Number: 80-005548
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202010A Exp: 10/05/2022	0.08g/210L Test (g/210L) Lot#:202010B Exp: 10/05/2022	0.20g/210L Test (g/210L) Lot#:202010D Exp: 10/06/2022	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG115904 Exp: 06/08/2023
0.000	0.050	0.080	0.197	0.078
0.000	0.051	0.079	0.198	0.078
0.000	0.050	0.080	0.198	0.077
0.000	0.050	0.079	0.198	0.078
0.000	0.050	0.079	0.198	0.077
0.000	0.050	0.079	0.198	0.078
0.000	0.050	0.080	0.197	0.078
0.000	0.051	0.080	0.197	0.078
0.000	0.051	0.080	0.198	0.078
0.000	0.050	0.080	0.198	0.078


Standard Deviations	0.0004	0.0005	0.0004	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0004 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

 _____
Signature and Printed Name

DAVID E REYES-RIVERA

03/01/2022
Date

Type of Test	Serial Number	Agency	Date	Performed By
Stabilities	80-005548	Miami-Dade Police Department	3/1/2022	DERR <i>MLL</i>

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L
0.047 to 0.053 ☒	0.077 to 0.083 ☒	0.194 to 0.206 ☒	0.077 to 0.083 ☒
MIAMI DADE PD Intoxilyzer - Alcohol Analyzer Model 8000 03/01/2022 Software: 8100.27	MIAMI DADE PD Intoxilyzer - Alcohol Analyzer Model 8000 03/01/2022 Software: 8100.27	MIAMI DADE PD Intoxilyzer - Alcohol Analyzer Model 8000 03/01/2022 Software: 8100.27	MIAMI DADE PD Intoxilyzer - Alcohol Analyzer Model 8000 03/01/2022 Software: 8100.27
Test g/210L Time	Test g/210L Time	Test g/210L Time	Test g/210L Time
Air Blank 0.000 06:56	Air Blank 0.000 07:01	Air Blank 0.000 07:06	Air Blank 0.000 07:11
Control Test 0.050 06:57	Control Test 0.079 07:02	Control Test 0.198 07:07	Control Test 0.078 07:12
Air Blank 0.000 06:58	Air Blank 0.000 07:03	Air Blank 0.000 07:08	Air Blank 0.000 07:12
Control Test 0.050 06:58	Control Test 0.079 07:03	Control Test 0.197 07:08	Control Test 0.077 07:12
Air Blank 0.000 06:59	Air Blank 0.000 07:04	Air Blank 0.000 07:09	Air Blank 0.000 07:13
Control Test 0.050 07:00	Control Test 0.079 07:04	Control Test 0.197 07:10	Control Test 0.078 07:13
Air Blank 0.000 07:00	Air Blank 0.000 07:05	Air Blank 0.000 07:10	Air Blank 0.000 07:14
Control Test Stats Average Std Dev Rel Std Dev(%)	Control Test Stats Average Std Dev Rel Std Dev(%)	Control Test Stats Average Std Dev Rel Std Dev(%)	Control Test Stats Average Std Dev Rel Std Dev(%)
0.0500 0.0000 0.0000	0.0790 0.0000 0.0000	0.1973 0.0006 0.2926	0.0777 0.0006 0.7434
Operator's Signature MLL	Operator's Signature MLL	Operator's Signature MLL	Operator's Signature MLL



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-005548, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-005548</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>MIAMI DADE PD</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>03/01/2022</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>08:56</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards. This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

03/01/2022

Date


DAVID E REYES-RIVERA,

Department Inspector

FDLE/ATP Form 69 December 2021

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality