



INSTRUMENT PROCESSING SHEET

Agency Pensacola Police Department

S/N 80-007362

Florida Department of
Law Enforcement

Date In 03-31-2022 DI Completion Date 04-01-2022

☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake By <u>IS</u> ☒ Annual ☐ Registration ☒ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____ 	Quality Checks By <u>IS</u> Date <u>04-01-2022</u> ☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>213</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP-102</u> 32 mm <u>0.160</u> (.139 - .169) 36 mm <u>0.175</u> (.156 - .190) 53 mm <u>0.242</u> (.228 - .278) 103 mm <u>0.503</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>28421</u> ☒ Stability Checks <table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>MP6291</td> <td>202201C 01-11-2024</td> </tr> <tr> <td>0.080</td> <td>MP6292</td> <td>202201D 01-18-2024</td> </tr> <tr> <td>0.200</td> <td>MP6293</td> <td>202201E 01-18-2024</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG113403 05-14-2023</td> </tr> </tbody> </table>	Simulator	Serial #	Lot #/Exp	0.050	MP6291	202201C 01-11-2024	0.080	MP6292	202201D 01-18-2024	0.200	MP6293	202201E 01-18-2024	0.080 DGS	N/A	AG113403 05-14-2023	Flow Calibration By _____ Date _____ Flow Column # _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547) Maintenance By _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____ _____ _____ _____
Simulator	Serial #	Lot #/Exp															
0.050	MP6291	202201C 01-11-2024															
0.080	MP6292	202201D 01-18-2024															
0.200	MP6293	202201E 01-18-2024															
0.080 DGS	N/A	AG113403 05-14-2023															

Calibration Adjustment By _____ Barometric Pressure Gauge _____ ID # _____ <table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> ☐ Post Calibration Adjustment Stability Checks <table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> Notes/Suggested Service: _____ Tech Review: Listed previous Form 48 under Attachments IS 4-4-2022 _____ _____ _____ _____ _____ 	Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Department Inspection By <u>IS</u> Barometric Pressure ID# <u>30793</u> Gauge <u>1014</u> Instrument <u>1014</u> Mouth Alcohol Solution Lot # <u>2021-D</u> Acetone Stock Solution Lot # <u>2021-C</u> <table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td>MP6289</td> </tr> <tr> <td>Interferent</td> <td>MP6290</td> </tr> <tr> <td>0.050</td> <td>MP6291</td> </tr> <tr> <td>0.080</td> <td>MP6292</td> </tr> <tr> <td>0.200</td> <td>MP6293</td> </tr> </tbody> </table> Attachments ☒ Form 41 ☐ Post-Stability Checks ☒ Stability Checks ☐ Flow Calibration ☒ Calibration Certificate ☐ Form 40 ☐ Calibration Adjustment ☒ Other <u>Form 51</u> IS 4-4-2022 and Form 48 ☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use 2022.04. Taylor Gutschow Digitally signed by Taylor Gutschow Date: 2022.04.04 10:19:18 -0400 <u>05</u> <u>15:55:39</u> Tech Review / Date _____ Admin Review / Date <u>04/07</u>	Simulator	Serial Number	0.000	MP6289	Interferent	MP6290	0.050	MP6291	0.080	MP6292	0.200	MP6293
Simulator	Serial #	Lot #	Expiration																																																										
0.000		N/A	N/A																																																										
0.040																																																													
0.100																																																													
0.200																																																													
0.300																																																													
0.080 DGS	N/A																																																												
Simulator	Serial #	Lot #	Expiration																																																										
0.050																																																													
0.080																																																													
0.200																																																													
0.080 DGS	N/A																																																												
Simulator	Serial Number																																																												
0.000	MP6289																																																												
Interferent	MP6290																																																												
0.050	MP6291																																																												
0.080	MP6292																																																												
0.200	MP6293																																																												

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: PENSACOLA PD
Time of Inspection: 13:01

Date of Inspection: 04/01/2022

Serial Number: 80-007362
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202201C Exp: 01/11/2024	0.08g/210L Test (g/210L) Lot#:202201D Exp: 01/18/2024	0.20g/210L Test (g/210L) Lot#:202201E Exp: 01/18/2024	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG113403 Exp: 05/14/2023
0.000	0.049	0.080	0.203	0.079
0.000	0.049	0.079	0.203	0.079
0.000	0.049	0.080	0.203	0.079
0.000	0.049	0.080	0.202	0.079
0.000	0.049	0.080	0.202	0.079
0.000	0.049	0.080	0.203	0.079
0.000	0.050	0.080	0.202	0.079
0.000	0.049	0.080	0.203	0.079
0.000	0.049	0.080	0.203	0.079
0.000	0.049	0.080	0.203	0.079

Standard Deviations	0.0003	0.0003	0.0004	0.0000
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0002 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Israel Soto

ISRAEL SOTO
Signature and Printed Name

04/01/2022
Date

Stability checks

PENSACOLA PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007362
04/01/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	08:41
Control Test	0.050	08:42
Air Blank	0.000	08:42
Control Test	0.050	08:43
Air Blank	0.000	08:43
Control Test	0.049	08:44
Air Blank	0.000	08:45
Control Test Stats		
Average	0.0497	
Std Dev	0.0006	
Rel Std Dev(%)	1.1625	

Operator's Signature

PENSACOLA PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007362
04/01/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	08:47
Control Test	0.080	08:47
Air Blank	0.000	08:48
Control Test	0.079	08:49
Air Blank	0.000	08:49
Control Test	0.079	08:50
Air Blank	0.000	08:50
Control Test Stats		
Average	0.0793	
Std Dev	0.0006	
Rel Std Dev(%)	0.7277	

wet

Operator's Signature

PENSACOLA PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007362
04/01/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	08:51
Control Test	0.202	08:52
Air Blank	0.000	08:53
Control Test	0.201	08:53
Air Blank	0.000	08:54
Control Test	0.200	08:55
Air Blank	0.000	08:55
Control Test Stats		
Average	0.2010	
Std Dev	0.0010	
Rel Std Dev(%)	0.4975	

Operator's Signature

PENSACOLA PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007362
04/01/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	08:57
Control Test	0.080	08:58
Air Blank	0.000	08:58
Control Test	0.080	08:58
Air Blank	0.000	08:59
Control Test	0.080	08:59
Air Blank	0.000	09:00
Control Test Stats		
Average	0.0800	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Dry

Operator's Signature



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road.
Suite B1032
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-007362, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-007362</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>PENSACOLA PD</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>04/01/2022</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>13:01</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Israel Soto
Soto
Date: 2022.04.01 13:59:06
-04'00'

Date

ISRAEL SOTO,

Department Inspector

FDLE/ATP Form 69 March 2022

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

Page 1 of 1

Return Material Authorization

Ship to: ☒ CMI, Inc.

☐ Enforcement Electronics

Shipment to repair facility authorized by: Joshua Hudson on 04-02-2021

Items Returned: Instrument ☒ Supplies ☐ Other ☐ Describe: _____

Instrument Model: Intoxilyzer 8000 Serial Number: 80-007362

Bill To Address:

Pensacola Police Department

Ship to Address:

Alcohol Testing Program FDLE

Tallahassee, Florida

Reason for Return:

Instrument is displaying "Error012 Contact CMI".

Instrument displayed message after attempting to upload instrument records, agency reported instrument was having RAM failures immediately after uploading.

Agency has had multiple instruments with "Error012 Contact CMI".

Please choose one of the following options:

☐ 1. I _____, authorize all repairs.

☐ 2. I _____, authorize repairs up to \$_____.

☒ 3. I require an estimate **BEFORE** any repairs will be authorized and/ or conducted.

Please contact: Name: Joshua Hudson

Phone #: 850.221.8050 Email: JHudson@cityofpensacola.com

ATP Contact Name: Israel Soto ATP Email: israelsoto@fdle.state.fl.us



INSTRUMENT PROCESSING SHEET

Agency Pensacola Police Department

S/N 80-007362

Florida Department of
Law Enforcement

Date In 3/24/2021

DI Completion Date _____

☐ Ship

☐ P/U

☐ H/D

☒ CMI

☐ EE

Intake By <u>RAW</u> ☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____	Quality Checks By _____ Date _____ ☐ Breath Tube Screen ☐ Replace External O-Rings ☐ Instrument Set Up Verified ☐ R-Value _____ ☐ Flow Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547) ☐ Barometric Pressure Check Gauge ID # _____ ☐ Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> </tr> </tbody> </table>	Simulator	Serial #	Lot #/Exp	0.050			0.080			0.200			0.080 DGS	N/A		Flow Calibration By _____ Date _____ Flow Column # _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547) Maintenance By _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____ DI Temp. Checks By _____ ☐ Lab Temp °C _____ External Digital Therm. ID#: _____ ☐ 34°C +/- .2 Serial #: _____ ☐ 34°C +/- .2 Serial #: _____ ☐ 34°C +/- .2 Serial #: _____																																												
Simulator	Serial #	Lot #/Exp																																																											
0.050																																																													
0.080																																																													
0.200																																																													
0.080 DGS	N/A																																																												
Calibration Adjustment By _____ Barometric Pressure Gauge _____ ID # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> ☐ Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>	Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Department Inspection By _____ Barometric Pressure ID# _____ Gauge _____ Instrument _____ Mouth Alcohol Solution Lot # _____ Acetone Stock Solution Lot # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> </tr> <tr> <td>Interferent</td> <td></td> </tr> <tr> <td>0.050</td> <td></td> </tr> <tr> <td>0.080</td> <td></td> </tr> <tr> <td>0.200</td> <td></td> </tr> </tbody> </table>	Simulator	Serial Number	0.000		Interferent		0.050		0.080		0.200	
Simulator	Serial #	Lot #	Expiration																																																										
0.000		N/A	N/A																																																										
0.040																																																													
0.100																																																													
0.200																																																													
0.300																																																													
0.080 DGS	N/A																																																												
Simulator	Serial #	Lot #	Expiration																																																										
0.050																																																													
0.080																																																													
0.200																																																													
0.080 DGS	N/A																																																												
Simulator	Serial Number																																																												
0.000																																																													
Interferent																																																													
0.050																																																													
0.080																																																													
0.200																																																													
Notes/Suggested Service: Instrument is displaying "Error012 Contact CMI". Sending instrument to CMI. IS _____ _____ Compliance with 11D-8 FAC not determined. IS _____ _____ _____ _____	<table border="1" style="width:100%; border-collapse: collapse;"> <tr> <td style="width:50%; vertical-align: top;"> Attachments ☐ Form 41 ☐ Stability Checks ☐ Calibration Certificate ☐ Calibration Adjustment </td> <td style="width:50%; vertical-align: top;"> ☐ Post-Stability Checks ☐ Flow Calibration ☐ Form 40 ☐ Other _____ </td> </tr> <tr> <td colspan="2"> ☐ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☐ Return to/Place into Evidentiary Use ☒ Remain Out of Evidentiary Use ☐ Conduct an Agency Inspection Before Evidentiary Use </td> </tr> <tr> <td colspan="2"> Tech Review / Date _____ Admin Review / Date _____ </td> </tr> </table>		Attachments ☐ Form 41 ☐ Stability Checks ☐ Calibration Certificate ☐ Calibration Adjustment	☐ Post-Stability Checks ☐ Flow Calibration ☐ Form 40 ☐ Other _____	☐ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☐ Return to/Place into Evidentiary Use ☒ Remain Out of Evidentiary Use ☐ Conduct an Agency Inspection Before Evidentiary Use		Tech Review / Date _____ Admin Review / Date _____																																																						
Attachments ☐ Form 41 ☐ Stability Checks ☐ Calibration Certificate ☐ Calibration Adjustment	☐ Post-Stability Checks ☐ Flow Calibration ☐ Form 40 ☐ Other _____																																																												
☐ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☐ Return to/Place into Evidentiary Use ☒ Remain Out of Evidentiary Use ☐ Conduct an Agency Inspection Before Evidentiary Use																																																													
Tech Review / Date _____ Admin Review / Date _____																																																													