



INSTRUMENT PROCESSING SHEET

Agency Walton County Sheriff's OfficeS/N 80-007364Florida Department of
Law EnforcementDate In 10-24-2022 DI Completion Date 10-27-2022☐ Ship ☒ P/U ☐ H/D ☐ CMI ☐ EE

Intake	By IS	Quality Checks	By IS	Date <u>10-25-2022</u>	Flow Calibration	By	Date																									
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☒ Power cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>236</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP-105</u> 32 mm <u>0.160</u> (.139 - .169) 36 mm <u>0.175</u> (.156 - .190) 53 mm <u>0.246</u> (.228 - .278) 103 mm <u>0.500</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>28427</u> ☒ Stability Checks			☐ Flow Column # _____ ☐ 5L/min - 17mm ☐ 15L/min - 53mm ☐ 30L/min - 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																											
		<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP5083</td><td>202201C 01-11-2024</td></tr><tr><td>0.080</td><td>MP5085</td><td>202201D 01-18-2024</td></tr><tr><td>0.200</td><td>MP6297</td><td>202201E 01-18-2024</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>08121080A1 05-05-2023</td></tr></tbody></table>	Simulator	Serial #	Lot #/Exp	0.050	MP5083	202201C 01-11-2024	0.080	MP5085	202201D 01-18-2024	0.200	MP6297	202201E 01-18-2024	0.080 DGS	N/A	08121080A1 05-05-2023															
Simulator	Serial #	Lot #/Exp																														
0.050	MP5083	202201C 01-11-2024																														
0.080	MP5085	202201D 01-18-2024																														
0.200	MP6297	202201E 01-18-2024																														
0.080 DGS	N/A	08121080A1 05-05-2023																														
		<table border="1"><thead><tr><th colspan="2">Maintenance</th><th>By</th></tr></thead><tbody><tr><td>☐ Battery Replacement</td><td></td><td></td></tr><tr><td>☐ Dry Gas Regulator Replacement</td><td></td><td></td></tr><tr><td>☐ Breath Tube Replacement</td><td></td><td></td></tr><tr><td>☐ Other _____</td><td></td><td></td></tr><tr><td>_____</td><td></td><td></td></tr><tr><td>_____</td><td></td><td></td></tr><tr><td>_____</td><td></td><td></td></tr><tr><td>_____</td><td></td><td></td></tr></tbody></table>				Maintenance		By	☐ Battery Replacement			☐ Dry Gas Regulator Replacement			☐ Breath Tube Replacement			☐ Other _____			_____			_____			_____			_____		
Maintenance		By																														
☐ Battery Replacement																																
☐ Dry Gas Regulator Replacement																																
☐ Breath Tube Replacement																																
☐ Other _____																																

Calibration Adjustment	By IS	Department Inspection	By IS																																																																												
Barometric Pressure Gauge <u>10114</u> ^{IS 10-31-2022} ID # <u>30793</u> <table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td>MP5091</td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td>MP5082</td><td>21070</td><td>03-01-2023</td></tr><tr><td>0.100</td><td>MP6290</td><td>21380</td><td>09-13-2023</td></tr><tr><td>0.200</td><td>MP6292</td><td>20510</td><td>12-03-2022</td></tr><tr><td>0.300</td><td>MP6293</td><td>21420</td><td>10-20-2023</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG113403</td><td>05-14-2023</td></tr></tbody></table> ☒ Post Calibration Adjustment Stability Checks <table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td>MP5088</td><td>202201C</td><td>01-11-2024</td></tr><tr><td>0.080</td><td>MP5089</td><td>202201D</td><td>01-18-2024</td></tr><tr><td>0.200</td><td>MP5084</td><td>202201E</td><td>01-18-2024</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>08121080A1</td><td>05-05-2023</td></tr></tbody></table> Notes/Suggested Service: _____ Tech Review: Removed extra "1" from Barometric Pressure Gauge in Calibration Adjustment section. IS 10-31-2022 _____ _____ _____ _____ _____		Simulator	Serial #	Lot #	Expiration	0.000	MP5091	N/A	N/A	0.040	MP5082	21070	03-01-2023	0.100	MP6290	21380	09-13-2023	0.200	MP6292	20510	12-03-2022	0.300	MP6293	21420	10-20-2023	0.080 DGS	N/A	AG113403	05-14-2023	Simulator	Serial #	Lot #	Expiration	0.050	MP5088	202201C	01-11-2024	0.080	MP5089	202201D	01-18-2024	0.200	MP5084	202201E	01-18-2024	0.080 DGS	N/A	08121080A1	05-05-2023		Barometric Pressure ID# <u>28427</u> Gauge <u>1011</u> Instrument <u>1014</u> Mouth Alcohol Solution Lot # <u>2022-A</u> Acetone Stock Solution Lot # <u>2022-B</u> <table border="1"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td>MP6289</td></tr><tr><td>Interferent</td><td>MP5087</td></tr><tr><td>0.050</td><td>MP5088</td></tr><tr><td>0.080</td><td>MP5089</td></tr><tr><td>0.200</td><td>MP5084</td></tr></tbody></table> <table border="1"><thead><tr><th colspan="2">Attachments</th></tr></thead><tbody><tr><td>☒ Form 41</td><td>☒ Post-Stability Checks</td></tr><tr><td>☒ Stability Checks</td><td>☐ Flow Calibration</td></tr><tr><td>☒ Calibration Certificate</td><td>☐ Form 40</td></tr><tr><td>☒ Calibration Adjustment</td><td>☐ Other _____</td></tr></tbody></table> <table border="1"><tbody><tr><td>☒ Instrument Complies with Chapter 11D-8, FAC</td></tr><tr><td>☐ Instrument Does Not Comply with Chapter 11D-8, FAC</td></tr><tr><td>☒ Return to/Place into Evidentiary Use</td></tr><tr><td>☐ Remain Out of Evidentiary Use</td></tr><tr><td>☒ Conduct an Agency Inspection Before Evidentiary Use</td></tr></tbody></table> David Eliezer Reyes-Rivera Digitally signed by David Eliezer Reyes-Rivera Date: 2022.10.31 09:19:05 -0400 Tech Review / Date <u>2022.11.01</u> Admin Review / Date <u>12-13-2024</u>	Simulator	Serial Number	0.000	MP6289	Interferent	MP5087	0.050	MP5088	0.080	MP5089	0.200	MP5084	Attachments		☒ Form 41	☒ Post-Stability Checks	☒ Stability Checks	☐ Flow Calibration	☒ Calibration Certificate	☐ Form 40	☒ Calibration Adjustment	☐ Other _____	☒ Instrument Complies with Chapter 11D-8, FAC	☐ Instrument Does Not Comply with Chapter 11D-8, FAC	☒ Return to/Place into Evidentiary Use	☐ Remain Out of Evidentiary Use	☒ Conduct an Agency Inspection Before Evidentiary Use	
Simulator	Serial #	Lot #	Expiration																																																																												
0.000	MP5091	N/A	N/A																																																																												
0.040	MP5082	21070	03-01-2023																																																																												
0.100	MP6290	21380	09-13-2023																																																																												
0.200	MP6292	20510	12-03-2022																																																																												
0.300	MP6293	21420	10-20-2023																																																																												
0.080 DGS	N/A	AG113403	05-14-2023																																																																												
Simulator	Serial #	Lot #	Expiration																																																																												
0.050	MP5088	202201C	01-11-2024																																																																												
0.080	MP5089	202201D	01-18-2024																																																																												
0.200	MP5084	202201E	01-18-2024																																																																												
0.080 DGS	N/A	08121080A1	05-05-2023																																																																												
Simulator	Serial Number																																																																														
0.000	MP6289																																																																														
Interferent	MP5087																																																																														
0.050	MP5088																																																																														
0.080	MP5089																																																																														
0.200	MP5084																																																																														
Attachments																																																																															
☒ Form 41	☒ Post-Stability Checks																																																																														
☒ Stability Checks	☐ Flow Calibration																																																																														
☒ Calibration Certificate	☐ Form 40																																																																														
☒ Calibration Adjustment	☐ Other _____																																																																														
☒ Instrument Complies with Chapter 11D-8, FAC																																																																															
☐ Instrument Does Not Comply with Chapter 11D-8, FAC																																																																															
☒ Return to/Place into Evidentiary Use																																																																															
☐ Remain Out of Evidentiary Use																																																																															
☒ Conduct an Agency Inspection Before Evidentiary Use																																																																															

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: WALTON COUNTY SO
Time of Inspection: 12:05

Date of Inspection: 10/27/2022

Serial Number: 80-007364
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202201C Exp: 01/11/2024	0.08g/210L Test (g/210L) Lot#:202201D Exp: 01/18/2024	0.20g/210L Test (g/210L) Lot#:202201E Exp: 01/18/2024	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:08121080A1 Exp: 05/05/2023
0.000	0.048	0.078	0.198	0.079
0.000	0.048	0.078	0.199	0.079
0.000	0.048	0.078	0.199	0.079
0.000	0.048	0.078	0.199	0.079
0.000	0.048	0.078	0.199	0.079
0.000	0.049	0.078	0.199	0.078
0.000	0.048	0.077	0.199	0.078
0.000	0.048	0.078	0.199	0.079
0.000	0.049	0.078	0.198	0.078
0.000	0.049	0.078	0.199	0.078

Standard Deviations	0.0004	0.0003	0.0004	0.0005
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0004 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Israel Soto

ISRAEL SOTO

Signature and Printed Name

10/27/2022
Date

Stability checks

WALTON COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007364
10/25/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:42
Control Test	0.047	11:43
Air Blank	0.000	11:44
Control Test	0.046	11:44
Air Blank	0.000	11:45
Control Test	0.046	11:46
Air Blank	0.000	11:46
Control Test Stats		
Average	0.0463	
Std Dev	0.0006	
Rel Std Dev(%)	1.2461	

Operator's Signature

WALTON COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007364
10/25/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:48
Control Test	0.077	11:49
Air Blank	0.000	11:49
Control Test	0.076	11:50
Air Blank	0.000	11:50
Control Test	0.077	11:51
Air Blank	0.000	11:51
Control Test Stats		
Average	0.0767	
Std Dev	0.0006	
Rel Std Dev(%)	0.7531	

Operator's Signature

WALTON COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007364
10/25/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:52
Control Test	0.199	11:53
Air Blank	0.000	11:54
Control Test	0.199	11:54
Air Blank	0.000	11:55
Control Test	0.198	11:56
Air Blank	0.000	11:56
Control Test Stats		
Average	0.1987	
Std Dev	0.0006	
Rel Std Dev(%)	0.2906	

Operator's Signature

wet

WALTON COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007364
10/25/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:57
Control Test	0.075	11:58
Air Blank	0.000	11:58
Control Test	0.075	11:59
Air Blank	0.000	11:59
Control Test	0.075	11:59
Air Blank	0.000	12:00
Control Test Stats		
Average	0.0750	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

Dry



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road.
Suite B1032
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-007364, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-007364</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>WALTON COUNTY SO</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>10/27/2022</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>12:05</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.
This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Israel Soto
Soto
Digitally signed by Israel
Date: 2022.10.27 13:13:32
-04'00'

10/27/2022

Date

ISRAEL SOTO,
Department Inspector

FDLE/ATP Form 69 March 2022
Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

WALTON COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007364
10/26/2022 10:53:25

Optical Bench
Calibration Adjust



Auto Calibration

pg 1 of 2

<<<< 3um >>>> <<<< 9um >>>>

Solution = 0.000 g/210L or 0.0000 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	0.1650	(-0.0160)	0.2160	(-0.0170)
Sample #2	0.1170	(0.0260)	0.1720	(0.0110)
Sample #3	0.1450	(0.0280)	0.1770	(0.0220)
Sample #4	0.1760	(0.0200)	0.1880	(0.0110)
Avg % Abs	0.1460	(0.0247)	0.1790	(0.0147)
STD DEV	0.0295	(0.0042)	0.0082	(0.0064)
REL STD DEV	20.214	(16.878)	4.573	(43.301)

Solution = 0.040 g/210L or 0.1905 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	0.8450	(-0.0020)	1.4910	(-0.0110)
Sample #2	0.8610	(-0.0100)	1.4920	(0.0010)
Sample #3	0.8880	(-0.0060)	1.5040	(-0.0040)
Sample #4	0.8340	(0.0320)	1.4770	(0.0160)
Avg % Abs	0.8610	(0.0053)	1.4910	(0.0043)
STD DEV	0.0270	(0.0232)	0.0135	(0.0104)
REL STD DEV	3.136	(434.633)	0.907	(240.192)

Solution = 0.100 g/210L or 0.4762 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	1.9600	(-0.0060)	3.4730	(-0.0120)
Sample #2	1.8910	(0.0320)	3.4080	(0.0230)
Sample #3	1.9540	(0.0020)	3.4560	(0.0050)
Sample #4	1.8940	(0.0370)	3.4140	(0.0340)
Avg % Abs	1.9130	(0.0237)	3.4260	(0.0207)
STD DEV	0.0355	(0.0189)	0.0262	(0.0146)
REL STD DEV	1.858	(79.985)	0.763	(70.839)

Solution = 0.200 g/210L or 0.9524 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	3.6110	(0.0000)	6.4900	(0.0060)
Sample #2	3.6160	(0.0110)	6.4970	(0.0060)
Sample #3	3.6430	(0.0070)	6.4890	(0.0220)
Sample #4	3.6110	(0.0160)	6.4770	(0.0210)
Avg % Abs	3.6233	(0.0113)	6.4877	(0.0163)
STD DEV	0.0172	(0.0045)	0.0101	(0.0090)
REL STD DEV	0.475	(39.787)	0.155	(54.875)

Solution = 0.300 g/210L or 1.4286 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	5.2790	(-0.0180)	9.3940	(-0.0150)
Sample #2	5.2960	(-0.0040)	9.3950	(-0.0060)
Sample #3	5.2620	(0.0220)	9.3780	(0.0080)
Sample #4	5.2280	(0.0350)	9.3680	(0.0060)
Avg % Abs	5.2620	(0.0177)	9.3803	(0.0027)
STD DEV	0.0340	(0.0199)	0.0137	(0.0076)
REL STD DEV	0.646	(112.403)	0.146	(283.945)

WALTON COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007364
10/26/2022 10:53:25

Optical Bench
Calibration Adjust
✓

Auto Calibration

pg 2 of 2

<<<< 3um >>>>

Zero Order Coef -379.76
First Order Coef 2624.53
Second Order Coef 30.76

Act (g/210L)	Fit (g/210L)	Residual (g/210L)
0.000	0.000	-0.0001
0.040	0.040	0.0000
0.100	0.100	0.0002
0.200	0.200	-0.0002
0.300	0.300	0.0001

<<<< 9um >>>>

-245.29
1411.99
14.58

Act (g/210L)	Fit (g/210L)	Residual (g/210L)
0.000	0.000	-0.0002
0.040	0.040	0.0003
0.100	0.100	-0.0000
0.200	0.200	-0.0001
0.300	0.300	0.0001

<<<< 3um >>>> <<<< 9um >>>>

Solution = 0.080 g/210L or 0.3810 mg/l, Samples = 4, Discarded = 1
Sample
Sample #1 2809.00 3157.00
Sample #2 2768.00 3128.00
Sample #3 2729.00 3095.00
Sample #4 2736.00 3119.00
Avg 2744.3333 3114.0000
STD DEV 20.7926 17.0587
REL STD DEV 0.758 0.548
H2O adjust (mg/l*10k) 1065 695

Barometric Pressure = 1010

*****CALIBRATION SUCCESSFUL*****

Post-stability checks

WALTON COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007364
10/27/2022
Software: 8100.27


Test	g/210L	Time
Air Blank	0.000	10:20
Control Test	0.049	10:21
Air Blank	0.000	10:21
Control Test	0.049	10:22
Air Blank	0.000	10:22
Control Test	0.049	10:23
Air Blank	0.000	10:24
Control Test Stats		
Average	0.0490	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	


Operator's Signature

WALTON COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007364
10/27/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:25
Control Test	0.078	10:25
Air Blank	0.000	10:26
Control Test	0.077	10:26
Air Blank	0.000	10:27
Control Test	0.077	10:28
Air Blank	0.000	10:28
Control Test Stats		
Average	0.0773	
Std Dev	0.0006	
Rel Std Dev(%)	0.7466	

wet


Operator's Signature

WALTON COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007364
10/27/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:29
Control Test	0.199	10:30
Air Blank	0.000	10:30
Control Test	0.198	10:31
Air Blank	0.000	10:31
Control Test	0.197	10:32
Air Blank	0.000	10:33
Control Test Stats		
Average	0.1980	
Std Dev	0.0010	
Rel Std Dev(%)	0.5051	


Operator's Signature

WALTON COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007364
10/27/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:33
Control Test	0.080	10:34
Air Blank	0.000	10:34
Control Test	0.079	10:34
Air Blank	0.000	10:35
Control Test	0.079	10:35
Air Blank	0.000	10:36
Control Test Stats		
Average	0.0793	
Std Dev	0.0006	
Rel Std Dev(%)	0.7277	

Dry


Operator's Signature