

Type of Test	Serial Number	Agency	Date	Performed By
Stabilities	80-00 7443	FHP	08/30/2022	TDG MC

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L																																																																																																																																				
0.047 to 0.053	0.077 to 0.083	0.194 to 0.206	0.077 to 0.083																																																																																																																																				
✓	✓	✓	✓																																																																																																																																				
FHP Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-007443 08/30/2022 Software: 8100.27 Test g/210L Time <table><tr><td>Air Blank</td><td>0.000</td><td>12:40</td></tr><tr><td>Control Test</td><td>0.048</td><td>12:40</td></tr><tr><td>Air Blank</td><td>0.000</td><td>12:41</td></tr><tr><td>Control Test</td><td>0.048</td><td>12:42</td></tr><tr><td>Air Blank</td><td>0.000</td><td>12:42</td></tr><tr><td>Control Test</td><td>0.048</td><td>12:43</td></tr><tr><td>Air Blank</td><td>0.000</td><td>12:43</td></tr><tr><td>Control Test Stats</td><td></td><td></td></tr><tr><td>Average</td><td>0.0480</td><td></td></tr><tr><td>Std Dev</td><td>0.0000</td><td></td></tr><tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr></table>	Air Blank	0.000	12:40	Control Test	0.048	12:40	Air Blank	0.000	12:41	Control Test	0.048	12:42	Air Blank	0.000	12:42	Control Test	0.048	12:43	Air Blank	0.000	12:43	Control Test Stats			Average	0.0480		Std Dev	0.0000		Rel Std Dev(%)	0.0000		FHP Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-007443 08/30/2022 Software: 8100.27 Test g/210L Time <table><tr><td>Air Blank</td><td>0.000</td><td>12:49</td></tr><tr><td>Control Test</td><td>0.077</td><td>12:50</td></tr><tr><td>Air Blank</td><td>0.000</td><td>12:50</td></tr><tr><td>Control Test</td><td>0.077</td><td>12:51</td></tr><tr><td>Air Blank</td><td>0.000</td><td>12:52</td></tr><tr><td>Control Test</td><td>0.077</td><td>12:52</td></tr><tr><td>Air Blank</td><td>0.000</td><td>12:53</td></tr><tr><td>Control Test Stats</td><td></td><td></td></tr><tr><td>Average</td><td>0.0770</td><td></td></tr><tr><td>Std Dev</td><td>0.0000</td><td></td></tr><tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr></table>	Air Blank	0.000	12:49	Control Test	0.077	12:50	Air Blank	0.000	12:50	Control Test	0.077	12:51	Air Blank	0.000	12:52	Control Test	0.077	12:52	Air Blank	0.000	12:53	Control Test Stats			Average	0.0770		Std Dev	0.0000		Rel Std Dev(%)	0.0000		FHP Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-007443 08/30/2022 Software: 8100.27 Test g/210L Time <table><tr><td>Air Blank</td><td>0.000</td><td>12:56</td></tr><tr><td>Control Test</td><td>0.197</td><td>12:57</td></tr><tr><td>Air Blank</td><td>0.000</td><td>12:57</td></tr><tr><td>Control Test</td><td>0.198</td><td>12:58</td></tr><tr><td>Air Blank</td><td>0.000</td><td>12:59</td></tr><tr><td>Control Test</td><td>0.197</td><td>12:59</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:00</td></tr><tr><td>Control Test Stats</td><td></td><td></td></tr><tr><td>Average</td><td>0.1973</td><td></td></tr><tr><td>Std Dev</td><td>0.0006</td><td></td></tr><tr><td>Rel Std Dev(%)</td><td>0.2926</td><td></td></tr></table>	Air Blank	0.000	12:56	Control Test	0.197	12:57	Air Blank	0.000	12:57	Control Test	0.198	12:58	Air Blank	0.000	12:59	Control Test	0.197	12:59	Air Blank	0.000	13:00	Control Test Stats			Average	0.1973		Std Dev	0.0006		Rel Std Dev(%)	0.2926		065 FHP Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-007443 08/30/2022 Software: 8100.27 Test g/210L Time <table><tr><td>Air Blank</td><td>0.000</td><td>13:02</td></tr><tr><td>Control Test</td><td>0.080</td><td>13:03</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:03</td></tr><tr><td>Control Test</td><td>0.079</td><td>13:03</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:04</td></tr><tr><td>Control Test</td><td>0.080</td><td>13:04</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:05</td></tr><tr><td>Control Test Stats</td><td></td><td></td></tr><tr><td>Average</td><td>0.0797</td><td></td></tr><tr><td>Std Dev</td><td>0.0006</td><td></td></tr><tr><td>Rel Std Dev(%)</td><td>0.7247</td><td></td></tr></table>	Air Blank	0.000	13:02	Control Test	0.080	13:03	Air Blank	0.000	13:03	Control Test	0.079	13:03	Air Blank	0.000	13:04	Control Test	0.080	13:04	Air Blank	0.000	13:05	Control Test Stats			Average	0.0797		Std Dev	0.0006		Rel Std Dev(%)	0.7247	
Air Blank	0.000	12:40																																																																																																																																					
Control Test	0.048	12:40																																																																																																																																					
Air Blank	0.000	12:41																																																																																																																																					
Control Test	0.048	12:42																																																																																																																																					
Air Blank	0.000	12:42																																																																																																																																					
Control Test	0.048	12:43																																																																																																																																					
Air Blank	0.000	12:43																																																																																																																																					
Control Test Stats																																																																																																																																							
Average	0.0480																																																																																																																																						
Std Dev	0.0000																																																																																																																																						
Rel Std Dev(%)	0.0000																																																																																																																																						
Air Blank	0.000	12:49																																																																																																																																					
Control Test	0.077	12:50																																																																																																																																					
Air Blank	0.000	12:50																																																																																																																																					
Control Test	0.077	12:51																																																																																																																																					
Air Blank	0.000	12:52																																																																																																																																					
Control Test	0.077	12:52																																																																																																																																					
Air Blank	0.000	12:53																																																																																																																																					
Control Test Stats																																																																																																																																							
Average	0.0770																																																																																																																																						
Std Dev	0.0000																																																																																																																																						
Rel Std Dev(%)	0.0000																																																																																																																																						
Air Blank	0.000	12:56																																																																																																																																					
Control Test	0.197	12:57																																																																																																																																					
Air Blank	0.000	12:57																																																																																																																																					
Control Test	0.198	12:58																																																																																																																																					
Air Blank	0.000	12:59																																																																																																																																					
Control Test	0.197	12:59																																																																																																																																					
Air Blank	0.000	13:00																																																																																																																																					
Control Test Stats																																																																																																																																							
Average	0.1973																																																																																																																																						
Std Dev	0.0006																																																																																																																																						
Rel Std Dev(%)	0.2926																																																																																																																																						
Air Blank	0.000	13:02																																																																																																																																					
Control Test	0.080	13:03																																																																																																																																					
Air Blank	0.000	13:03																																																																																																																																					
Control Test	0.079	13:03																																																																																																																																					
Air Blank	0.000	13:04																																																																																																																																					
Control Test	0.080	13:04																																																																																																																																					
Air Blank	0.000	13:05																																																																																																																																					
Control Test Stats																																																																																																																																							
Average	0.0797																																																																																																																																						
Std Dev	0.0006																																																																																																																																						
Rel Std Dev(%)	0.7247																																																																																																																																						
Operator's Signature MC	Operator's Signature MC	Operator's Signature MC	Operator's Signature MC																																																																																																																																				

Comments:

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: FHP

Time of Inspection: 14:45

Date of Inspection: 08/30/2022

Serial Number: 80-007443

Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202201C Exp: 01/11/2024	0.08g/210L Test (g/210L) Lot#:202201D Exp: 01/18/2024	0.20g/210L Test (g/210L) Lot#:202201E Exp: 01/18/2024	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:00521080A2 Exp: 02/05/2023
0.000	0.048	0.078	0.197	0.080
0.000	0.047	0.077	0.197	0.080
0.000	0.048	0.077	0.197	0.080
0.000	0.048	0.078	0.197	0.080
0.000	0.048	0.078	0.197	0.080
0.000	0.048	0.078	0.197	0.080
0.000	0.048	0.077	0.197	0.080
0.000	0.048	0.078	0.197	0.081
0.000	0.048	0.077	0.197	0.080
0.000	0.049	0.078	0.197	0.080


Standard Deviations	0.0004	0.0005	0.0000	0.0003
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0003 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



TAYLOR D GUTSCHOW

Signature and Printed Name

08/30/2022
Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-007443, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-007443</u>	UNCERTAINTY* $\pm$
Owning Agency:	<u>FHP</u>	0.050 g/ 210 L 0.004
Calibration Date:	<u>08/30/2022</u>	0.080 g/ 210 L 0.004
Calibration Time:	<u>14:45</u>	0.200 g/ 210 L 0.007
		0.080 g/ 210 L Dry Gas Control 0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards. This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

08/30/2022

Date

TAYLOR D GUTSCHOW,
Department Inspector

FDLE/ATP Form 69 December 2021
Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality