



INSTRUMENT PROCESSING SHEET

Agency FHP Troop B

S/N 80-007457

Florida Department of
Law Enforcement

Date In 12/29/2021 DI Completion Date 1/3/2022

☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake By <u>RAW</u> ☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____	Quality Checks By <u>RAW</u> Date <u>01/03/22</u> ☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>200</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP105</u> 32 mm <u>.148</u> (.139 - .169) 36 mm <u>.167</u> (.156 - .190) 53 mm <u>.234</u> (.228 - .278) 103 mm <u>.500</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>30793</u> ☒ Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>MP6291</td> <td>202010A 10/05/22</td> </tr> <tr> <td>0.080</td> <td>MP6292</td> <td>202010B 10/05/22</td> </tr> <tr> <td>0.200</td> <td>MP6293</td> <td>202010D 10/06/22</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG113403 05/14/23</td> </tr> </tbody> </table>	Simulator	Serial #	Lot #/Exp	0.050	MP6291	202010A 10/05/22	0.080	MP6292	202010B 10/05/22	0.200	MP6293	202010D 10/06/22	0.080 DGS	N/A	AG113403 05/14/23	Flow Calibration By _____ Date _____ Flow Column # _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547) Maintenance By _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____ DI Temp. Checks By <u>RAW</u> ☒ Lab Temp °C <u>20.88</u> External Digital Therm. ID#: <u>381189</u> ☒ 34°C +/- .2 Serial #: <u>MP6291</u> ☒ 34°C +/- .2 Serial #: <u>MP6292</u> ☒ 34°C +/- .2 Serial #: <u>MP6293</u>																																												
Simulator	Serial #	Lot #/Exp																																																											
0.050	MP6291	202010A 10/05/22																																																											
0.080	MP6292	202010B 10/05/22																																																											
0.200	MP6293	202010D 10/06/22																																																											
0.080 DGS	N/A	AG113403 05/14/23																																																											
Calibration Adjustment By _____ Barometric Pressure Gauge _____ ID # _____ <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> ☐ Post Calibration Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table>	Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Department Inspection By <u>RAW</u> Barometric Pressure ID# <u>30793</u> Gauge <u>1023</u> Instrument <u>1020</u> Mouth Alcohol Solution Lot # <u>2021-D</u> Acetone Stock Solution Lot # <u>2021-C</u> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td>MP6289</td> </tr> <tr> <td>Interferent</td> <td>MP6290</td> </tr> <tr> <td>0.050</td> <td>MP6291</td> </tr> <tr> <td>0.080</td> <td>MP6292</td> </tr> <tr> <td>0.200</td> <td>MP6293</td> </tr> </tbody> </table>	Simulator	Serial Number	0.000	MP6289	Interferent	MP6290	0.050	MP6291	0.080	MP6292	0.200	MP6293
Simulator	Serial #	Lot #	Expiration																																																										
0.000		N/A	N/A																																																										
0.040																																																													
0.100																																																													
0.200																																																													
0.300																																																													
0.080 DGS	N/A																																																												
Simulator	Serial #	Lot #	Expiration																																																										
0.050																																																													
0.080																																																													
0.200																																																													
0.080 DGS	N/A																																																												
Simulator	Serial Number																																																												
0.000	MP6289																																																												
Interferent	MP6290																																																												
0.050	MP6291																																																												
0.080	MP6292																																																												
0.200	MP6293																																																												
Notes/Suggested Service: _____ _____ _____ _____ _____ _____ _____ _____ _____	Attachments ☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment ☐ Post-Stability Checks ☐ Flow Calibration ☐ Form 40 ☐ Other _____ ☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use Israel Soto Digitally signed by Israel Soto Date: 2022.01.04 15:23:33 +05'00' 2022.01.04 14:52:12 -05'00' Tech Review / Date _____ Admin Review / Date _____																																																												

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: FHP

Serial Number: 80-007457

Time of Inspection: 13:26

Date of Inspection: 01/03/2022

Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#: 202010A Exp: 10/05/2022	0.08g/210L Test (g/210L) Lot#: 202010B Exp: 10/05/2022	0.20g/210L Test (g/210L) Lot#: 202010D Exp: 10/06/2022	0.08 g/210L Dry Gas Std Test (g/210L) Lot#: AG113403 Exp: 05/14/2023
0.000	0.050	0.081	0.202	0.080
0.000	0.051	0.081	0.202	0.080
0.000	0.050	0.081	0.202	0.080
0.000	0.050	0.081	0.202	0.080
0.000	0.050	0.081	0.203	0.080
0.000	0.050	0.081	0.202	0.080
0.000	0.051	0.081	0.202	0.080
0.000	0.050	0.081	0.202	0.080
0.000	0.050	0.081	0.202	0.080
0.000	0.050	0.081	0.202	0.080
0.000	0.050	0.081	0.203	0.080
Standard Deviations	0.0004	0.0000	0.0004	0.0000

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0002

Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



RICHARD A WILLIAMS

Signature and Printed Name

01/03/2022

Date

FHP
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007457
01/03/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:26
Control Test	0.050	10:26
Air Blank	0.000	10:27
Control Test	0.050	10:27
Air Blank	0.000	10:28
Control Test	0.050	10:29
Air Blank	0.000	10:29
Control Test Stats		
Average	0.0500	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

0.05

RAW

Operator's Signature

FHP
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007457
01/03/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:31
Control Test	0.081	10:32
Air Blank	0.000	10:32
Control Test	0.081	10:33
Air Blank	0.000	10:34
Control Test	0.080	10:34
Air Blank	0.000	10:35
Control Test Stats		
Average	0.0807	
Std Dev	0.0006	
Rel Std Dev(%)	0.7157	

0.08
wet

RAW

Operator's Signature

FHP
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007457
01/03/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:36
Control Test	0.203	10:37
Air Blank	0.000	10:37
Control Test	0.202	10:38
Air Blank	0.000	10:38
Control Test	0.202	10:39
Air Blank	0.000	10:40
Control Test Stats		
Average	0.2023	
Std Dev	0.0006	
Rel Std Dev(%)	0.2853	

0.20

RAW

Operator's Signature

FHP
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007457
01/03/2022
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:43
Control Test	0.080	10:44
Air Blank	0.000	10:44
Control Test	0.080	10:45
Air Blank	0.000	10:45
Control Test	0.081	10:45
Air Blank	0.000	10:46
Control Test Stats		
Average	0.0803	
Std Dev	0.0006	
Rel Std Dev(%)	0.7187	

0.08
DGS

RAW

Operator's Signature

Stability Checks

80-007457

01/03/22

RAW



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2729 Fort Knox Blvd.
Bldg. 2, Suite 1300
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-007457, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-007457</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>FHP</u>	0.050 g/ 210 L	0.005
Calibration Date:	<u>01/03/2022</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>13:26</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Richard A Williams
Digitally signed by Richard A Williams
Date: 2022.01.04 14:14:06 -05'00'

01/03/2022

Date

RICHARD A WILLIAMS,
Department Inspector

FDLE/ATP Form 69 December 2021

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality



Agency **Florida Highway Patrol**

S/N 80-007457

Date In 6/10/2022

DI Completion Date 06-13-2022

☐ Ship

P/U

☐ H/D

□ EE

Intake	By <u>PJN</u>	Quality Checks	By <u>PJN</u>	Date <u>6/13/2022</u>	Flow Calibration	By _____	Date _____												
☒ Annual ☐ Registration ☒ Return from CMI / EE Visual Inspection: ☒ Case ☒ Keyboard ☒ Feet ☒ Ports ☒ Handle ☒ Dry Gas Shelf ☒ Breath Tube ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____	☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>201</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP 103</u> 32 mm <u>.156</u> (.139 - .169) 36 mm <u>.164</u> (.156 - .190) 53 mm <u>.234</u> (.228 - .278) 103 mm <u>.480</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>28662</u> ☒ Stability Checks	Flow Column # _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)	Maintenance By _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____ _____ _____ _____ _____																
	<table border="1"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>MP6291</td> <td>202201C 01/11/2024</td> </tr> <tr> <td>0.080</td> <td>MP6292</td> <td>202201D 01/18/2024</td> </tr> <tr> <td>0.200</td> <td>MP6293</td> <td>202201E 01/18/2024</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG121002 07/29/2023</td> </tr> </tbody> </table>	Simulator	Serial #	Lot #/Exp	0.050	MP6291	202201C 01/11/2024	0.080	MP6292	202201D 01/18/2024	0.200	MP6293	202201E 01/18/2024	0.080 DGS	N/A	AG121002 07/29/2023			
Simulator	Serial #	Lot #/Exp																	
0.050	MP6291	202201C 01/11/2024																	
0.080	MP6292	202201D 01/18/2024																	
0.200	MP6293	202201E 01/18/2024																	
0.080 DGS	N/A	AG121002 07/29/2023																	

Calibration Adjustment				By _____	
Barometric Pressure Gauge _____ ID # _____					
Simulator	Serial #	Lot #	Expiration		
0.000		N/A	N/A		
0.040					
0.100					
0.200					
0.300					
0.080 DGS	N/A				
☐ Post Calibration Adjustment Stability Checks					
Simulator	Serial #	Lot #	Expiration		
0.050					
0.080					
0.200					
0.080 DGS	N/A				
Notes/Suggested Service:					

Department Inspection		By IS _____
Barometric Pressure ID# <u>28427</u>		
Gauge <u>1014</u> Instrument <u>1016</u>		
Mouth Alcohol Solution Lot # <u>2022-A</u>		
Acetone Stock Solution Lot # <u>2021-C</u>		
Simulator	Serial Number	
0.000	MP6289	
Interferent	MP6290	
0.050	MP6291	
0.080	MP6292	
0.200	MP6293	
Attachments		
☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment	☐ Post-Stability Checks ☐ Flow Calibration ☐ Form 40 ☐ Other _____	
☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC		
☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use		
☒ Conduct an Agency Inspection Before Evidentiary Use		
David Eliezer Reyes-Rivera		Digitally signed by David Eliezer Reyes-Rivera Date: 2022.06.13 13:28:45 -04'00' 13 14:27:43 -04'00'
Tech Review / Date		Admin Review / Date

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: FHP

Time of Inspection: 12:47

Date of Inspection: 06/13/2022

Serial Number: 80-007457

Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202201C Exp: 01/11/2024	0.08g/210L Test (g/210L) Lot#:202201D Exp: 01/18/2024	0.20g/210L Test (g/210L) Lot#:202201E Exp: 01/18/2024	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG113403 Exp: 05/14/2023
0.000	0.049	0.080	0.203	0.080
0.000	0.049	0.080	0.203	0.081
0.000	0.049	0.080	0.202	0.081
0.000	0.049	0.080	0.203	0.081
0.000	0.049	0.080	0.203	0.081
0.000	0.049	0.080	0.204	0.081
0.000	0.049	0.080	0.203	0.081
0.000	0.049	0.080	0.202	0.082
0.000	0.049	0.080	0.201	0.081
0.000	0.049	0.080	0.199	0.081

Standard Deviations	0.0000	0.0000	0.0014	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0004 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Israel Soto

ISRAEL SOTO

Signature and Printed Name

06/13/2022

Date

Type of Test	Serial Number	Agency	Date	Performed By
Stability Checks	80-007457	Florida Highway Patrol	6/13/2022	PN

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L
0.047 to 0.053	0.077 to 0.083	0.194 to 0.206	0.077 to 0.083
✓	✓	✓	✓
FHP Intoxilyzer - Alcohol Analyzer Model 8000 06/13/2022 Software: 8100.27 SN 80-007457 Test g/210L Time Air Blank 0.000 09:13 Control Test 0.049 09:14 Air Blank 0.000 09:15 Control Test 0.049 09:15 Air Blank 0.000 09:16 Control Test 0.049 09:17 Air Blank 0.000 09:17 Control Test Stats Average 0.0490 Std Dev 0.0000 Rel Std Dev(%) 0.0000 Operator's Signature	FHP Intoxilyzer - Alcohol Analyzer Model 8000 06/13/2022 Software: 8100.27 SN 80-007457 Test g/210L Time Air Blank 0.000 09:19 Control Test 0.081 09:20 Air Blank 0.000 09:21 Control Test 0.080 09:21 Air Blank 0.000 09:22 Control Test 0.080 09:23 Air Blank 0.000 09:23 Control Test Stats Average 0.0803 Std Dev 0.0006 Rel Std Dev(%) 0.7187 Operator's Signature	FHP Intoxilyzer - Alcohol Analyzer Model 8000 06/13/2022 Software: 8100.27 SN 80-007457 Test g/210L Time Air Blank 0.000 09:25 Control Test 0.204 09:26 Air Blank 0.000 09:26 Control Test 0.203 09:27 Air Blank 0.000 09:28 Control Test 0.203 09:28 Air Blank 0.000 09:29 Control Test Stats Average 0.2033 Std Dev 0.0006 Rel Std Dev(%) 0.2839 Operator's Signature	FHP Intoxilyzer - Alcohol Analyzer Model 8000 06/13/2022 Software: 8100.27 SN 80-007457 Test g/210L Time Air Blank 0.000 09:31 Control Test 0.080 09:31 Air Blank 0.000 09:31 Control Test 0.080 09:32 Air Blank 0.000 09:32 Control Test 0.080 09:33 Air Blank 0.000 09:33 Control Test Stats Average 0.0800 Std Dev 0.0000 Rel Std Dev(%) 0.0000 Operator's Signature

Comments: N/A



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road.
Suite B1032
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-007457, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-007457</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>FHP</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>06/13/2022</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>12:47</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Israel Soto
Soto
Digitally signed by Israel
Date: 2022.06.13
13:15:05 -04'00'

06/13/2022

Date

ISRAEL SOTO,

Department Inspector

FDLE/ATP Form 69 March 2022
Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality