



INSTRUMENT PROCESSING SHEET

Agency Panama City Beach Police DepartmentS/N 80-000838Florida Department of
Law EnforcementDate In 06/14/2023 DI Completion Date 06-19-2023☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake	By ALL	Quality Checks	By IS	Date 06-15-2023	Flow Calibration	By	Date																																										
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☒ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>145</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP-105</u> 32 mm <u>0.160</u> (.139 - .169) 36 mm <u>0.171</u> (.156 - .190) 53 mm <u>0.250</u> (.228 - .278) 103 mm <u>0.519</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>28421</u> ☒ Stability Checks			☐ Flow Column # _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																												
		<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP6291</td><td>202201C 01-11-2024</td></tr><tr><td>0.080</td><td>MP6292</td><td>202303L 03-29-2025</td></tr><tr><td>0.200</td><td>MP6293</td><td>202201E 01-18-2024</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG229803 10-25-2024</td></tr></tbody></table>			Simulator	Serial #	Lot #/Exp	0.050	MP6291	202201C 01-11-2024	0.080	MP6292	202303L 03-29-2025	0.200	MP6293	202201E 01-18-2024	0.080 DGS	N/A	AG229803 10-25-2024	<table border="1"><thead><tr><th colspan="2">Maintenance</th><th>By</th></tr></thead><tbody><tr><td>☐ Battery Replacement</td><td></td><td></td></tr><tr><td>☐ Dry Gas Regulator Replacement</td><td></td><td></td></tr><tr><td>☐ Breath Tube Replacement</td><td></td><td></td></tr><tr><td>☐ Other _____</td><td></td><td></td></tr><tr><td>_____</td><td></td><td></td></tr><tr><td>_____</td><td></td><td></td></tr><tr><td>_____</td><td></td><td></td></tr><tr><td>_____</td><td></td><td></td></tr></tbody></table>			Maintenance		By	☐ Battery Replacement			☐ Dry Gas Regulator Replacement			☐ Breath Tube Replacement			☐ Other _____			_____			_____			_____			_____		
Simulator	Serial #	Lot #/Exp																																															
0.050	MP6291	202201C 01-11-2024																																															
0.080	MP6292	202303L 03-29-2025																																															
0.200	MP6293	202201E 01-18-2024																																															
0.080 DGS	N/A	AG229803 10-25-2024																																															
Maintenance		By																																															
☐ Battery Replacement																																																	
☐ Dry Gas Regulator Replacement																																																	
☐ Breath Tube Replacement																																																	
☐ Other _____																																																	

Calibration Adjustment		By IS			Department Inspection																																												
Barometric Pressure Gauge <u>1009</u> ID # <u>28662</u>					Barometric Pressure ID# <u>28421</u>																																												
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td>MP5091</td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td>MP5082</td><td>22460</td><td>12-28-2024</td></tr><tr><td>0.100</td><td>MP6296</td><td>22430</td><td>11-30-2024</td></tr><tr><td>0.200</td><td>MP5084</td><td>22400</td><td>10-12-2024</td></tr><tr><td>0.300</td><td>MP5085</td><td>23070</td><td>03-06-2025</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>06723080A5</td><td>04-05-2025</td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.000	MP5091	N/A	N/A	0.040	MP5082	22460	12-28-2024	0.100	MP6296	22430	11-30-2024	0.200	MP5084	22400	10-12-2024	0.300	MP5085	23070	03-06-2025	0.080 DGS	N/A	06723080A5	04-05-2025				Gauge <u>1013</u> Instrument <u>1012</u>																
Simulator	Serial #	Lot #	Expiration																																														
0.000	MP5091	N/A	N/A																																														
0.040	MP5082	22460	12-28-2024																																														
0.100	MP6296	22430	11-30-2024																																														
0.200	MP5084	22400	10-12-2024																																														
0.300	MP5085	23070	03-06-2025																																														
0.080 DGS	N/A	06723080A5	04-05-2025																																														
					Mouth Alcohol Solution Lot # <u>2022-A</u>																																												
					Acetone Stock Solution Lot # <u>2022-B</u>																																												
					<table border="1"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td>MP6289</td></tr><tr><td>Interferent</td><td>MP6290</td></tr><tr><td>0.050</td><td>MP6291</td></tr><tr><td>0.080</td><td>MP6292</td></tr><tr><td>0.200</td><td>MP6293</td></tr></tbody></table>			Simulator	Serial Number	0.000	MP6289	Interferent	MP6290	0.050	MP6291	0.080	MP6292	0.200	MP6293																														
Simulator	Serial Number																																																
0.000	MP6289																																																
Interferent	MP6290																																																
0.050	MP6291																																																
0.080	MP6292																																																
0.200	MP6293																																																
☒ Post Calibration Adjustment Stability Checks					Attachments																																												
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td>MP6291</td><td>202201C</td><td>01-11-2024</td></tr><tr><td>0.080</td><td>MP6292</td><td>202303L</td><td>03-29-2025</td></tr><tr><td>0.200</td><td>MP6293</td><td>202201E</td><td>01-18-2024</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG229803</td><td>10-25-2024</td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.050	MP6291	202201C	01-11-2024	0.080	MP6292	202303L	03-29-2025	0.200	MP6293	202201E	01-18-2024	0.080 DGS	N/A	AG229803	10-25-2024				☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☒ Calibration Adjustment																								
Simulator	Serial #	Lot #	Expiration																																														
0.050	MP6291	202201C	01-11-2024																																														
0.080	MP6292	202303L	03-29-2025																																														
0.200	MP6293	202201E	01-18-2024																																														
0.080 DGS	N/A	AG229803	10-25-2024																																														
					☒ Post-Stability Checks ☐ Flow Calibration ☐ Form 40 ☐ Other _____																																												
Notes/Suggested Service: <u>Agency Inspector indicated instrument failed 0.050 g/210L test during Agency Inspection. 0.050 g/210L Stability Check values outside nominal range. Optical Bench Calibration Adjustment Performed. IS</u>					☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC																																												
					☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use																																												
					☒ Conduct an Agency Inspection Before Evidentiary Use																																												
					Taylor Gutschow Digitally signed by Taylor Gutschow Date: 2023.06.19 11:39:14 -0400																																												
					Phil Nicodemo Digitally signed by Phil Nicodemo Date: 2023.06.22 08:20:32 -0400																																												
					Tech Review / Date _____ Admin Review / Date _____																																												

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: PANAMA CITY BEACH PD

Time of Inspection: 10:24

Date of Inspection: 06/19/2023

Serial Number: 80-000838

Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202201C Exp: 01/11/2024	0.08g/210L Test (g/210L) Lot#:202303L Exp: 03/29/2025	0.20g/210L Test (g/210L) Lot#:202201E Exp: 01/18/2024	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG229803 Exp: 10/25/2024
0.000	0.049	0.079	0.197	0.079
0.000	0.049	0.079	0.197	0.079
0.000	0.049	0.079	0.197	0.079
0.000	0.048	0.079	0.197	0.079
0.000	0.048	0.080	0.197	0.079
0.000	0.048	0.080	0.197	0.079
0.000	0.048	0.080	0.195	0.079
0.000	0.047	0.080	0.195	0.080
0.000	0.046	0.080	0.194	0.080
0.000	0.045	0.081	0.194	0.080

Standard Deviations	0.0013	0.0006	0.0013	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0009 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Israel Soto

ISRAEL SOTO

Signature and Printed Name

06/19/2023

Date

Stability checks

PANAMA CITY BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000838
06/15/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:50
Control Test	0.047	10:51
Air Blank	0.000	10:51
Control Test	0.046	10:52
Air Blank	0.000	10:53
Control Test	0.047	10:53
Air Blank	0.000	10:54
Control Test Stats		
Average	0.0467	
Std Dev	0.0006	
Rel Std Dev(%)	1.2372	

Operator's Signature

PANAMA CITY BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000838
06/15/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	10:56
Control Test	0.078	10:56
Air Blank	0.000	10:57
Control Test	0.078	10:58
Air Blank	0.000	10:58
Control Test	0.077	10:59
Air Blank	0.000	10:59
Control Test Stats		
Average	0.0777	
Std Dev	0.0006	
Rel Std Dev(%)	0.7434	

Operator's Signature

PANAMA CITY BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000838
06/15/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:00
Control Test	0.197	11:01
Air Blank	0.000	11:01
Control Test	0.198	11:02
Air Blank	0.000	11:02
Control Test	0.198	11:03
Air Blank	0.000	11:03
Control Test Stats		
Average	0.1977	
Std Dev	0.0006	
Rel Std Dev(%)	0.2921	

Operator's Signature

Wet

PANAMA CITY BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000838
06/15/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:13
Control Test	0.078	11:13
Air Blank	0.000	11:14
Control Test	0.078	11:14
Air Blank	0.000	11:14
Control Test	0.078	11:15
Air Blank	0.000	11:15
Control Test Stats		
Average	0.0780	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

Dry



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road.
Suite B1032
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000838, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000838</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>PANAMA CITY BEACH PD</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>06/19/2023</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>10:24</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Israel Soto
Soto
Date: 2023.06.19 11:30:42
-04'00'

Date

ISRAEL SOTO,
Department Inspector

FDLE/ATP Form 69 March 2022

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

PANAMA CITY BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000838
06/15/2023 13:05:16

Optical Bench
Calibration Adjustment

Auto Calibration

pg 1 of 2

<<<<< 3um >>>>> <<<<< 9um >>>>>

Solution = 0.000 g/210L or 0.0000 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	0.0500	(-0.0270)	0.0920	(-0.0140)
Sample #2	0.0570	(-0.0080)	0.0770	(0.0080)
Sample #3	0.0300	(0.0250)	0.0660	(0.0220)
Sample #4	0.0440	(0.0260)	0.0870	(0.0160)
Avg % Abs	0.0437	(0.0143)	0.0767	(0.0153)
STD DEV	0.0135	(0.0193)	0.0105	(0.0070)
REL STD DEV	30.923	(134.984)	13.701	(45.807)

Solution = 0.040 g/210L or 0.1905 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	0.7850	(-0.0130)	1.5110	(-0.0060)
Sample #2	0.8170	(-0.0170)	1.5150	(0.0070)
Sample #3	0.8060	(0.0050)	1.4980	(0.0190)
Sample #4	0.8150	(-0.0020)	1.5260	(0.0010)
Avg % Abs	0.8127	(-0.0047)	1.5130	(0.0090)
STD DEV	0.0059	(0.0112)	0.0141	(0.0092)
REL STD DEV	0.721	(240.853)	0.932	(101.835)

Solution = 0.100 g/210L or 0.4762 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	1.9530	(-0.0220)	3.6110	(-0.0070)
Sample #2	1.9210	(0.0020)	3.5790	(0.0100)
Sample #3	1.9270	(0.0120)	3.5820	(0.0100)
Sample #4	1.9230	(0.0240)	3.5940	(0.0170)
Avg % Abs	1.9237	(0.0127)	3.5850	(0.0123)
STD DEV	0.0031	(0.0110)	0.0079	(0.0040)
REL STD DEV	0.159	(86.962)	0.221	(32.769)

Solution = 0.200 g/210L or 0.9524 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	3.7070	(-0.0120)	6.8770	(-0.0100)
Sample #2	3.6830	(-0.0010)	6.8470	(0.0090)
Sample #3	3.6980	(0.0160)	6.8290	(0.0230)
Sample #4	3.7070	(0.0070)	6.8450	(0.0220)
Avg % Abs	3.6960	(0.0073)	6.8403	(0.0180)
STD DEV	0.0121	(0.0085)	0.0099	(0.0078)
REL STD DEV	0.328	(115.976)	0.144	(43.390)

Solution = 0.300 g/210L or 1.4286 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	5.4510	(-0.0170)	9.9700	(-0.0030)
Sample #2	5.4210	(0.0050)	9.9650	(0.0080)
Sample #3	5.4380	(0.0010)	9.9730	(0.0040)
Sample #4	5.4170	(0.0250)	9.9740	(0.0060)
Avg % Abs	5.4253	(0.0103)	9.9707	(0.0060)
STD DEV	0.0112	(0.0129)	0.0049	(0.0020)
REL STD DEV	0.206	(124.434)	0.049	(33.333)

PANAMA CITY BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000838
06/15/2023 13:05:16

Optical Bench
Calibration Adjustment
✓

Auto Calibration

pg 2 of 2

<<<< 3um >>>>

Zero Order Coef -123.41
First Order Coef 2487.78
Second Order Coef 31.29

Act (g/210L)	Fit (g/210L)	Residual (g/210L)
0.000	-0.000	0.0003
0.040	0.040	-0.0003
0.100	0.100	-0.0003
0.200	0.199	0.0005
0.300	0.300	-0.0002

<<<< 9um >>>>

-111.88
1319.05
12.61

Act (g/210L)	Fit (g/210L)	Residual (g/210L)
0.000	-0.000	0.0002
0.040	0.040	-0.0002
0.100	0.100	-0.0004
0.200	0.200	0.0005
0.300	0.300	-0.0002

<<<< 3um >>>>

Solution = 0.080 g/210L or 0.3810 mg/l, Samples = 4, Discarded = 1
Sample
Sample #1 3207.00
Sample #2 3241.00
Sample #3 3176.00
Sample #4 3250.00
Avg 3222.3333
STD DEV 40.3774
REL STD DEV 1.253
H2O adjust (mg/l*10k) 587

<<<< 9um >>>>

3393.00
3412.00
3406.00
3412.00
3410.0000
3.4641
0.102
399

Barometric Pressure = 1008

*****CALIBRATION SUCCESSFUL*****

Post stability checks

PANAMA CITY BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000838
06/19/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	07:47
Control Test	0.049	07:48
Air Blank	0.000	07:49
Control Test	0.048	07:49
Air Blank	0.000	07:50
Control Test	0.048	07:51
Air Blank	0.000	07:51
Control Test Stats		
Average	0.0483	
Std Dev	0.0006	
Rel Std Dev(%)	1.1945	

Operator's Signature

PANAMA CITY BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000838
06/19/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	07:52
Control Test	0.079	07:53
Air Blank	0.000	07:53
Control Test	0.079	07:54
Air Blank	0.000	07:54
Control Test	0.079	07:55
Air Blank	0.000	07:56
Control Test Stats		
Average	0.0790	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

PANAMA CITY BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000838
06/19/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	07:57
Control Test	0.197	07:57
Air Blank	0.000	07:58
Control Test	0.197	07:59
Air Blank	0.000	07:59
Control Test	0.197	08:00
Air Blank	0.000	08:00
Control Test Stats		
Average	0.1970	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

PANAMA CITY BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000838
06/19/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	08:02
Control Test	0.079	08:02
Air Blank	0.000	08:02
Control Test	0.079	08:03
Air Blank	0.000	08:03
Control Test	0.079	08:04
Air Blank	0.000	08:04
Control Test Stats		
Average	0.0790	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

wet

Dry



INSTRUMENT PROCESSING SHEET

Agency Panama City Beach Police DepartmentS/N 80-000838Florida Department of
Law EnforcementDate In 01-04-2023 DI Completion Date 01-06-2023☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake	By IS	Quality Checks	By IS	Date <u>01-05-2023</u>	Flow Calibration	By	Date																																							
☒ Annual ☐ Registration ☒ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☒ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>153</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP-105</u> 32 mm <u>0.160</u> (.139 - .169) 36 mm <u>0.175</u> (.156 - .190) 53 mm <u>0.246</u> (.228 - .278) 103 mm <u>0.515</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>30793</u> ☒ Stability Checks			Flow Column # _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																									
		<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP6291</td><td>202201C 01-11-2024</td></tr><tr><td>0.080</td><td>MP6292</td><td>202201D 01-18-2024</td></tr><tr><td>0.200</td><td>MP6293</td><td>202201E 01-18-2024</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG113403 05-14-2023</td></tr></tbody></table>	Simulator	Serial #	Lot #/Exp	0.050	MP6291	202201C 01-11-2024	0.080	MP6292	202201D 01-18-2024	0.200	MP6293	202201E 01-18-2024	0.080 DGS	N/A	AG113403 05-14-2023																													
Simulator	Serial #	Lot #/Exp																																												
0.050	MP6291	202201C 01-11-2024																																												
0.080	MP6292	202201D 01-18-2024																																												
0.200	MP6293	202201E 01-18-2024																																												
0.080 DGS	N/A	AG113403 05-14-2023																																												
Calibration Adjustment		By _____		Department Inspection			By IS _____																																							
Barometric Pressure Gauge _____ ID # _____				Barometric Pressure ID# <u>30793</u> Gauge <u>1022</u> Instrument <u>1023</u> Mouth Alcohol Solution Lot # <u>2022-A</u> Acetone Stock Solution Lot # <u>2022-B</u>																																										
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td></td><td></td><td></td></tr><tr><td>0.100</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.300</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A					<table border="1"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td>MP6289</td></tr><tr><td>Interferent</td><td>MP6290</td></tr><tr><td>0.050</td><td>MP6291</td></tr><tr><td>0.080</td><td>MP6292</td></tr><tr><td>0.200</td><td>MP6293</td></tr></tbody></table>			Simulator	Serial Number	0.000	MP6289	Interferent	MP6290	0.050	MP6291	0.080	MP6292	0.200	MP6293
Simulator	Serial #	Lot #	Expiration																																											
0.000		N/A	N/A																																											
0.040																																														
0.100																																														
0.200																																														
0.300																																														
0.080 DGS	N/A																																													
Simulator	Serial Number																																													
0.000	MP6289																																													
Interferent	MP6290																																													
0.050	MP6291																																													
0.080	MP6292																																													
0.200	MP6293																																													
☐ Post Calibration Adjustment Stability Checks				Attachments																																										
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td></td><td></td><td></td></tr><tr><td>0.080</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A					☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment ☐ Post-Stability Checks ☐ Flow Calibration ☐ Form 40 ☐ Other _____																						
Simulator	Serial #	Lot #	Expiration																																											
0.050																																														
0.080																																														
0.200																																														
0.080 DGS	N/A																																													
Notes/Suggested Service: <u>Stability Checks performed</u> <u>01-06-2023. IS</u> _____ _____ _____ _____ _____ _____ _____ _____				☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use																																										
				Tech Review / Date _____ Admin Review / Date _____																																										

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: PANAMA CITY BEACH PD
Time of Inspection: 09:51

Date of Inspection: 01/06/2023

Serial Number: 80-000838
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202201C Exp: 01/11/2024	0.08g/210L Test (g/210L) Lot#:202201D Exp: 01/18/2024	0.20g/210L Test (g/210L) Lot#:202201E Exp: 01/18/2024	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG113403 Exp: 05/14/2023
0.000	0.048	0.078	0.199	0.078
0.000	0.048	0.078	0.200	0.078
0.000	0.048	0.078	0.199	0.078
0.000	0.048	0.077	0.199	0.078
0.000	0.048	0.077	0.199	0.078
0.000	0.048	0.078	0.200	0.078
0.000	0.048	0.077	0.200	0.078
0.000	0.048	0.078	0.200	0.078
0.000	0.048	0.078	0.200	0.078
0.000	0.049	0.077	0.199	0.078

Standard Deviations	0.0003	0.0005	0.0005	0.0000
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0003 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Israel Soto

ISRAEL SOTO

Signature and Printed Name

01/06/2023
Date

Stability Checks

PANAMA CITY BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000838
01/06/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	07:43
Control Test	0.048	07:43
Air Blank	0.000	07:44
Control Test	0.048	07:44
Air Blank	0.000	07:45
Control Test	0.048	07:46
Air Blank	0.000	07:46
Control Test Stats		
Average	0.0480	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	



Operator's Signature

PANAMA CITY BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000838
01/06/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	07:47
Control Test	0.077	07:48
Air Blank	0.000	07:49
Control Test	0.078	07:49
Air Blank	0.000	07:50
Control Test	0.078	07:51
Air Blank	0.000	07:51
Control Test Stats		
Average	0.0777	
Std Dev	0.0006	
Rel Std Dev(%)	0.7434	

wet



Operator's Signature

PANAMA CITY BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000838
01/06/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	07:52
Control Test	0.200	07:53
Air Blank	0.000	07:54
Control Test	0.200	07:54
Air Blank	0.000	07:55
Control Test	0.200	07:56
Air Blank	0.000	07:56
Control Test Stats		
Average	0.2000	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	



Operator's Signature

PANAMA CITY BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000838
01/06/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	07:58
Control Test	0.078	07:58
Air Blank	0.000	07:59
Control Test	0.079	07:59
Air Blank	0.000	07:59
Control Test	0.079	08:00
Air Blank	0.000	08:00
Control Test Stats		
Average	0.0787	
Std Dev	0.0006	
Rel Std Dev(%)	0.7339	

Dry



Operator's Signature



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road.
Suite B1032
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000838, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000838</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>PANAMA CITY BEACH PD</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>01/06/2023</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>09:51</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

01/06/2023

Date

Israel Soto

ISRAEL SOTO,
Department Inspector

Digitally signed by Israel

Soto

Date: 2023.01.06

11:19:12 -05'00'

FDLE/ATP Form 69 March 2022

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

Page 1 of 1