

Stability Checks

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L
0.047 to 0.053	0.077 to 0.083	0.194 to 0.206	0.077 to 0.083
<p>✓</p> <p>MIAMI BEACH PD Intoxilyzer - Alconol Analyzer Model 8000 SN 80-002232 12/18/2023 Software: 8100.27</p> <p>Test g/210L Time</p> <p>Air Blank 0.000 12:11 Control Test 0.049 12:12 Air Blank 0.000 12:12 Control Test 0.049 12:13 Air Blank 0.000 12:13 Control Test 0.049 12:14 Air Blank 0.000 12:15</p> <p>Control Test Stats Average 0.0490 Std Dev 0.0000 Rel Std Dev(%) 0.0000</p> <p>Operator's Signature _____</p>	<p>✓</p> <p>MIAMI BEACH PD Intoxilyzer - Alconol Analyzer Model 8000 SN 80-002232 12/18/2023 Software: 8100.27</p> <p>Test g/210L Time</p> <p>Air Blank 0.000 12:17 Control Test 0.078 12:18 Air Blank 0.000 12:19 Control Test 0.077 12:19 Air Blank 0.000 12:20 Control Test 0.078 12:20 Air Blank 0.000 12:21</p> <p>Control Test Stats Average 0.0777 Std Dev 0.0006 Rel Std Dev(%) 0.7434</p> <p>Operator's Signature _____</p>	<p>✓</p> <p>MIAMI BEACH PD Intoxilyzer - Alconol Analyzer Model 8000 SN 80-002232 12/18/2023 Software: 8100.27</p> <p>Test g/210L Time</p> <p>Air Blank 0.000 12:24 Control Test 0.197 12:25 Air Blank 0.000 12:25 Control Test 0.197 12:26 Air Blank 0.000 12:26 Control Test 0.197 12:27 Air Blank 0.000 12:28</p> <p>Control Test Stats Average 0.1970 Std Dev 0.0000 Rel Std Dev(%) 0.0000</p> <p>Operator's Signature _____</p>	<p>065</p> <p>MIAMI BEACH PD Intoxilyzer - Alconol Analyzer Model 8000 SN 80-002232 12/18/2023 Software: 8100.27</p> <p>Test g/210L Time</p> <p>Air Blank 0.000 12:04 Control Test 0.079 12:04 Air Blank 0.000 12:05 Control Test 0.078 12:05 Air Blank 0.000 12:06 Control Test 0.079 12:06 Air Blank 0.000 12:06</p> <p>Control Test Stats Average 0.0787 Std Dev 0.0006 Rel Std Dev(%) 0.7339</p> <p>Operator's Signature _____</p>

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: MIAMI BEACH PD

Time of Inspection: 12:45

Date of Inspection: 12/19/2023

Serial Number: 80-002232

Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202303K Exp: 03/29/2025	0.08g/210L Test (g/210L) Lot#:202303L Exp: 03/29/2025	0.20g/210L Test (g/210L) Lot#:202304C Exp: 04/05/2025	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:01923080A3 Exp: 02/05/2025
0.000	0.049	0.078	0.196	0.080
0.000	0.049	0.078	0.197	0.079
0.000	0.049	0.078	0.197	0.079
0.000	0.049	0.079	0.196	0.079
0.000	0.049	0.078	0.196	0.079
0.000	0.049	0.078	0.197	0.079
0.000	0.049	0.078	0.197	0.078
0.000	0.049	0.078	0.197	0.079
0.000	0.050	0.079	0.197	0.079
0.000	0.049	0.079	0.196	0.079


Standard Deviations	0.0003	0.0004	0.0005	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0004 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



Signature and Printed Name

TAYLOR D GUTSCHOW

12/19/2023
Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-002232, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	80-002232	UNCERTAINTY* \pm
Owning Agency:	MIAMI BEACH PD	0.050 g/ 210 L 0.004
Calibration Date:	12/19/2023	0.080 g/ 210 L 0.004
Calibration Time:	12:45	0.200 g/ 210 L 0.007
		0.080 g/ 210 L Dry Gas Control 0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

12/19/2023

Date

TAYLOR D GUTSCHOW,

Department Inspector

FDLE/ATP Form 69 December 2021

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

Return Material Authorization

Ship to:



CMI, Inc.



Enforcement Electronics

Shipment to repair facility authorized by: Taylor Gutschow on 10/04/2023

Items Returned: Instrument ☒ Supplies ☐ Other ☐ Describe: _____

Instrument Model: Intoxilyzer 8000 Serial Number: 80-002232

Bill To Address:

Miami Beach PD

Attn: Pedro Socarras

Ship to Address:

Florida Department of Law Enforcement

Alcohol Testing Program

4700 Terminal Drive, Suite 1

Fort Myers, FL 33907

Reason for Return:

Spoke to Service Supervisor Lisa Elliot. Instrument returned from repair (Work Order 407814)
but will not power on. Returning for re-evaluation.

Please choose one of the following options:

☐ 1. I _____, authorize all repairs.

☐ 2. I _____, authorize repairs up to \$_____.

☒ 3. I require an estimate **BEFORE** any repairs will be authorized and/ or conducted.

Please contact: Name: Pedro Socarras

Phone #: 305-345-6526

Email: PedroSocarras@miamibeachfl.gov

ATP Contact Name: Taylor Gutschow

ATP Email: TaylorGutschow@fdle.state.fl.us

Return Material Authorization

Ship to:



CMI, Inc.



Enforcement Electronics

Shipment to repair facility authorized by: Taylor Gutschow on 9/07/2023

Items Returned: Instrument ☒ Supplies ☐ Other ☐ Describe: _____

Instrument Model: Intoxilyzer 8000 Serial Number: 80-002232

Bill To Address:

Miami Beach PD

Attn: Pedro Socarras

Ship to Address:

Florida Department of Law Enforcement

Alcohol Testing Program

4700 Terminal Drive, Suite 1

Fort Myers, FL 33907

Reason for Return:

Instrument just returned from repair (Work Order 407814) but will not power on. Returning for re-evaluation.

Please choose one of the following options:

☐ 1. I _____, authorize all repairs.

☐ 2. I _____, authorize repairs up to \$ _____.

☒ 3. I require an estimate **BEFORE** any repairs will be authorized and/ or conducted.

Please contact: Name: Pedro Socarras

Phone #: 305-345-6526 Email: PedroSocarras@miamibeachfl.gov

ATP Contact Name: Taylor Gutschow ATP Email: TaylorGutschow@fdle.state.fl.us







INSTRUMENT PROCESSING SHEET

Agency Miami Beach PDS/N 80-002232Florida Department of
Law EnforcementDate In 04/12/2023 DI Completion Date 04/26/2023☐ Ship ☐ P/U ☐ H/D ☒ CMI ☐ EE

Intake	By TDG	Quality Checks	By TDG	Date <u>04/24/2023</u>	Flow Calibration	By	Date																																							
<input checked="" type="checkbox"/> Annual <input type="checkbox"/> Registration <input type="checkbox"/> Return from CMI / EE Visual Inspection: <input checked="" type="checkbox"/> Case <input checked="" type="checkbox"/> Handle <input checked="" type="checkbox"/> Keyboard <input checked="" type="checkbox"/> Dry Gas Shelf <input checked="" type="checkbox"/> Feet <input checked="" type="checkbox"/> Breath Tube <input checked="" type="checkbox"/> Ports <input checked="" type="checkbox"/> Screws Tight Other Equipment/ Accessories: <input type="checkbox"/> Power cord <input type="checkbox"/> Printer Cable <input type="checkbox"/> Static Bag <input type="checkbox"/> 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____		<input checked="" type="checkbox"/> Breath Tube Screen <input checked="" type="checkbox"/> Replace External O-Rings <input checked="" type="checkbox"/> Instrument Set Up Verified <input checked="" type="checkbox"/> R-Value <u>240</u> <input checked="" type="checkbox"/> Flow Verification (L/s) Flow Column # <u>ATP104</u> 32 mm <u>0.156</u> (.139 - .169) 36 mm <u>0.171</u> (.156 - .190) 53 mm <u>0.242</u> (.228 - .278) 103 mm <u>0.515</u> (.447 - .547) <input checked="" type="checkbox"/> Barometric Pressure Check Gauge ID # <u>26932</u> <input checked="" type="checkbox"/> Stability Checks			Flow Column # _____ <input type="checkbox"/> 5L/min - 17mm <input type="checkbox"/> 15L/min - 53mm <input type="checkbox"/> 30L/min - 103mm <input type="checkbox"/> R-Value _____ <input type="checkbox"/> Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																									
		<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP6286</td><td>202201C 01/11/2024</td></tr><tr><td>0.080</td><td>MP4864</td><td>202201D 01/18/2024</td></tr><tr><td>0.200</td><td>MP6288</td><td>202201E 01/18/2024</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG223802 08/26/2024</td></tr></tbody></table>			Simulator	Serial #	Lot #/Exp	0.050	MP6286	202201C 01/11/2024	0.080	MP4864	202201D 01/18/2024	0.200	MP6288	202201E 01/18/2024	0.080 DGS	N/A	AG223802 08/26/2024	<table border="1"><thead><tr><th colspan="2">Maintenance</th><th>By</th></tr></thead><tbody><tr><td colspan="2"><input type="checkbox"/> Battery Replacement <input type="checkbox"/> Dry Gas Regulator Replacement <input type="checkbox"/> Breath Tube Replacement <input type="checkbox"/> Other _____</td><td>_____</td></tr></tbody></table>			Maintenance		By	<input type="checkbox"/> Battery Replacement <input type="checkbox"/> Dry Gas Regulator Replacement <input type="checkbox"/> Breath Tube Replacement <input type="checkbox"/> Other _____		_____																		
Simulator	Serial #	Lot #/Exp																																												
0.050	MP6286	202201C 01/11/2024																																												
0.080	MP4864	202201D 01/18/2024																																												
0.200	MP6288	202201E 01/18/2024																																												
0.080 DGS	N/A	AG223802 08/26/2024																																												
Maintenance		By																																												
<input type="checkbox"/> Battery Replacement <input type="checkbox"/> Dry Gas Regulator Replacement <input type="checkbox"/> Breath Tube Replacement <input type="checkbox"/> Other _____		_____																																												
Calibration Adjustment		By _____		Department Inspection			By <u>TDG</u>																																							
Barometric Pressure Gauge _____ ID # _____				Barometric Pressure ID# <u>26932</u> Gauge <u>1017</u> Instrument <u>1009</u> Mouth Alcohol Solution Lot # <u>2021-D</u> Acetone Stock Solution Lot # <u>2022-B</u>																																										
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td></td><td></td><td></td></tr><tr><td>0.100</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.300</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A					<table border="1"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td>MP6284</td></tr><tr><td>Interferent</td><td>MP6285</td></tr><tr><td>0.050</td><td>MP6286</td></tr><tr><td>0.080</td><td>MP4864</td></tr><tr><td>0.200</td><td>MP6288</td></tr></tbody></table>		Simulator	Serial Number	0.000	MP6284	Interferent	MP6285	0.050	MP6286	0.080	MP4864	0.200	MP6288	
Simulator	Serial #	Lot #	Expiration																																											
0.000		N/A	N/A																																											
0.040																																														
0.100																																														
0.200																																														
0.300																																														
0.080 DGS	N/A																																													
Simulator	Serial Number																																													
0.000	MP6284																																													
Interferent	MP6285																																													
0.050	MP6286																																													
0.080	MP4864																																													
0.200	MP6288																																													
<input type="checkbox"/> Post Calibration Adjustment Stability Checks				Attachments																																										
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td></td><td></td><td></td></tr><tr><td>0.080</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A					<input checked="" type="checkbox"/> Form 41 <input checked="" type="checkbox"/> Stability Checks <input checked="" type="checkbox"/> Calibration Certificate <input type="checkbox"/> Calibration Adjustment			<input type="checkbox"/> Post-Stability Checks <input type="checkbox"/> Flow Calibration <input type="checkbox"/> Form 40 <input checked="" type="checkbox"/> Other <u>Form 51</u>																			
Simulator	Serial #	Lot #	Expiration																																											
0.050																																														
0.080																																														
0.200																																														
0.080 DGS	N/A																																													
Notes/Suggested Service: <u>AI Socarras will provide a box and static bag for shipment to CMI. (TDG)</u> _____ _____ _____ _____ _____ _____ _____ _____ _____				<input checked="" type="checkbox"/> Instrument Complies with Chapter 11D-8, FAC <input type="checkbox"/> Instrument Does Not Comply with Chapter 11D-8, FAC <input type="checkbox"/> Return to/Place into Evidentiary Use <input checked="" type="checkbox"/> Remain Out of Evidentiary Use <input type="checkbox"/> Conduct an Agency Inspection Before Evidentiary Use																																										
				Israel Soto <small>Digitally signed by Israel Soto Date: 2023.04.26 18:17:59 -0400</small>			Phil Nicodemo <small>Digitally signed by Phil Nicodemo Date: 2023.05.12 15:54:26 -0400</small>																																							
				Tech Review / Date _____			Admin Review / Date _____																																							

Type of Test	Serial Number	Agency	Date	Performed By
Stabilities	80-00 2232	Miami Beach PD	04/24/2023	TDG MG

0.05g/210L		0.08g/210L		0.20g/210L		DGS 0.08g/210L	
0.047 to 0.053		0.077 to 0.083		0.194 to 0.206		0.077 to 0.083	
✓		✓		✓		✓	
MIAMI BEACH PD Intoxilyzer - Alcohol Analyzer Model: 8000 04/24/2023 Software: 8100.27		MIAMI BEACH PD Intoxilyzer - Alcohol Analyzer Model: 8000 04/24/2023 Software: 8100.27		MIAMI BEACH PD Intoxilyzer - Alcohol Analyzer Model: 8000 04/24/2023 Software: 8100.27		MIAMI BEACH PD Intoxilyzer - Alcohol Analyzer Model: 8000 04/24/2023 Software: 8100.27	
Test g/210L Time		Test g/210L Time		Test g/210L Time		Test g/210L Time	
Air Blank 0.000 12:19		Air Blank 0.000 12:26		Air Blank 0.000 12:33		Air Blank 0.000 12:12	
Control Test 0.051 12:20		Control Test 0.079 12:27		Control Test 0.199 12:34		Control Test 0.079 12:12	
Air Blank 0.000 12:21		Air Blank 0.000 12:27		Air Blank 0.000 12:34		Air Blank 0.000 12:13	
Control Test 0.050 12:21		Control Test 0.079 12:28		Control Test 0.199 12:35		Control Test 0.079 12:13	
Air Blank 0.000 12:22		Air Blank 0.000 12:28		Air Blank 0.000 12:36		Air Blank 0.000 12:14	
Control Test 0.050 12:23		Control Test 0.079 12:29		Control Test 0.198 12:36		Control Test 0.079 12:14	
Air Blank 0.000 12:23		Air Blank 0.000 12:29		Air Blank 0.000 12:37		Air Blank 0.000 12:14	
Control Test Stats		Control Test Stats		Control Test Stats		Control Test Stats	
Average 0.0503		Average 0.0790		Average 0.1987		Average 0.0790	
Std Dev 0.0006		Std Dev 0.0000		Std Dev 0.0006		Std Dev 0.0000	
Rel Std Dev(%) 1.1471		Rel Std Dev(%) 0.0000		Rel Std Dev(%) 0.2906		Rel Std Dev(%) 0.0000	
Operator's Signature 		Operator's Signature 		Operator's Signature 		Operator's Signature 	

Comments:

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: MIAMI BEACH PD
Time of Inspection: 12:11

Date of Inspection: 04/26/2023

Serial Number: 80-002232
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202201C Exp: 01/11/2024	0.08g/210L Test (g/210L) Lot#:202201D Exp: 01/18/2024	0.20g/210L Test (g/210L) Lot#:202201E Exp: 01/18/2024	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG223802 Exp: 08/26/2024
0.000	0.049	0.078	0.199	0.079
0.000	0.049	0.078	0.199	0.079
0.000	0.049	0.078	0.199	0.079
0.000	0.049	0.078	0.199	0.078
0.000	0.049	0.078	0.199	0.079
0.000	0.049	0.078	0.200	0.079
0.000	0.049	0.079	0.199	0.078
0.000	0.050	0.078	0.199	0.079
0.000	0.049	0.078	0.199	0.079
0.000	0.049	0.078	0.199	0.079


Standard Deviations	0.0003	0.0003	0.0003	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0003 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

 TAYLOR D GUTSCHOW
Signature and Printed Name

04/26/2023
Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-002232, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-002232</u>	UNCERTAINTY* \pm
Owning Agency:	<u>MIAMI BEACH PD</u>	0.050 g/ 210 L 0.004
Calibration Date:	<u>04/26/2023</u>	0.080 g/ 210 L 0.004
Calibration Time:	<u>12:11</u>	0.200 g/ 210 L 0.007
		0.080 g/ 210 L Dry Gas Control 0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence (k=3).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards. This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

FDLE/ATP Form 69 December 2021

Issuing Authority: Alcohol Testing Program

04/26/2023

Date

TAYLOR D GUTSCHOW,

Department Inspector

Service • Integrity • Respect • Quality

Return Material Authorization

Ship to: ☒ CMI, Inc.

☐ Enforcement Electronics

Shipment to repair facility authorized by: Pedro Socarras on 04/26/2023

Items Returned: Instrument ☒ Supplies ☐ Other ☐ Describe: _____

Instrument Model: Intoxilyzer 8000 Serial Number: 80-002232

Bill To Address:

Miami Beach PD

Attn: Pedro Socarras

Ship to Address:

Florida Department of Law Enforcement

Fort Myers Regional Operations Center

Attn: Alcohol Testing Program

4700 Terminal Drive, Suite 1

Fort Myers, FL 33907

Reason for Return:

Abnormal countdown during instrument startup. Instrument also experienced a Diagnostic Fail.
The Diagnostic Fail did not recur after the power was cycled. Instrument passed inspection. All
records have been uploaded by FDLE.

Please choose one of the following options:

- ☐ 1. I _____, authorize all repairs.
- ☐ 2. I _____, authorize repairs up to \$_____.
- ☒ 3. I require an estimate **BEFORE** any repairs will be authorized and/ or conducted.

Please contact: Name: Pedro Socarras

Phone #: 305-345-6526

Email: PedroSocarras@miamibeachfl.gov

ATP Contact Name: Taylor Gutschow ATP Email: TaylorGutschow@fdle.state.fl.us