



INSTRUMENT PROCESSING SHEET

Agency Fernandina Beach Police DepartmentS/N 80-005538Florida Department of
Law EnforcementDate In 3/15/2023DI Completion Date 04-11-2023☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake	By PN	Quality Checks	By PN	Date <u>3/24/2023</u>	Flow Calibration	By	Date																										
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: <u>Agency Inspector indicated</u> <u>instrument measured the 0.05</u> <u>low on an Agency Inspection.</u> <u>PN</u>		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>172</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP 105</u> 32 mm <u>.167</u> (.139 - .169) 36 mm <u>.179</u> (.156 - .190) 53 mm <u>.234</u> (.228 - .278) 103 mm <u>.464</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>28421</u> ☒ Stability Checks			Flow Column # _____ ☐ 5L/min - 17mm ☐ 15L/min - 53mm ☐ 30L/min - 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																												
		<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP6296</td><td>202201C 01/11/2024</td></tr><tr><td>0.080</td><td>MP6297</td><td>202201D 01/18/2024</td></tr><tr><td>0.200</td><td>MP6298</td><td>202201E 01/18/2024</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG229803 10/25/2024</td></tr></tbody></table>	Simulator	Serial #	Lot #/Exp	0.050	MP6296	202201C 01/11/2024	0.080	MP6297	202201D 01/18/2024	0.200	MP6298	202201E 01/18/2024	0.080 DGS	N/A	AG229803 10/25/2024																
Simulator	Serial #	Lot #/Exp																															
0.050	MP6296	202201C 01/11/2024																															
0.080	MP6297	202201D 01/18/2024																															
0.200	MP6298	202201E 01/18/2024																															
0.080 DGS	N/A	AG229803 10/25/2024																															
Calibration Adjustment By PN _____		Department Inspection By IS _____																															
Barometric Pressure Gauge <u>1015</u> ID # <u>28662</u>		Barometric Pressure ID# <u>30793</u>																															
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td>MP5091</td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td>MP5082</td><td>21410</td><td>9/30/2023</td></tr><tr><td>0.100</td><td>MP5083</td><td>22310</td><td>8/11/2024</td></tr><tr><td>0.200</td><td>MP5084</td><td>22050</td><td>2/7/2024</td></tr><tr><td>0.300</td><td>MP5085</td><td>22220</td><td>6/15/2024</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>08121080A1</td><td>5/5/2023</td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.000	MP5091	N/A	N/A	0.040	MP5082	21410	9/30/2023	0.100	MP5083	22310	8/11/2024	0.200	MP5084	22050	2/7/2024	0.300	MP5085	22220	6/15/2024	0.080 DGS	N/A	08121080A1	5/5/2023	Gauge <u>1022</u> Instrument <u>1021</u> Mouth Alcohol Solution Lot # <u>2022-A</u> Acetone Stock Solution Lot # <u>2022-B</u>			
Simulator	Serial #	Lot #	Expiration																														
0.000	MP5091	N/A	N/A																														
0.040	MP5082	21410	9/30/2023																														
0.100	MP5083	22310	8/11/2024																														
0.200	MP5084	22050	2/7/2024																														
0.300	MP5085	22220	6/15/2024																														
0.080 DGS	N/A	08121080A1	5/5/2023																														
☒ Post Calibration Adjustment Stability Checks		<table border="1"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td>MP6289</td></tr><tr><td>Interferent</td><td>MP6290</td></tr><tr><td>0.050</td><td>MP6291</td></tr><tr><td>0.080</td><td>MP6292</td></tr><tr><td>0.200</td><td>MP6293</td></tr></tbody></table>				Simulator	Serial Number	0.000	MP6289	Interferent	MP6290	0.050	MP6291	0.080	MP6292	0.200	MP6293																
Simulator	Serial Number																																
0.000	MP6289																																
Interferent	MP6290																																
0.050	MP6291																																
0.080	MP6292																																
0.200	MP6293																																
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td>MP6296</td><td>202201C</td><td>01/11/2024</td></tr><tr><td>0.080</td><td>MP6297</td><td>202201D</td><td>01/18/2024</td></tr><tr><td>0.200</td><td>MP6298</td><td>202201E</td><td>01/18/2024</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG229803</td><td>10/25/2024</td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.050	MP6296	202201C	01/11/2024	0.080	MP6297	202201D	01/18/2024	0.200	MP6298	202201E	01/18/2024	0.080 DGS	N/A	AG229803	10/25/2024	Attachments ☒ Form 41 ☒ Post-Stability Checks ☒ Stability Checks ☐ Flow Calibration ☒ Calibration Certificate ☐ Form 40 ☒ Calibration Adjustment ☐ Other _____											
Simulator	Serial #	Lot #	Expiration																														
0.050	MP6296	202201C	01/11/2024																														
0.080	MP6297	202201D	01/18/2024																														
0.200	MP6298	202201E	01/18/2024																														
0.080 DGS	N/A	AG229803	10/25/2024																														
Notes/Suggested Service: <u>Performed a discretionary optical bench calibration</u> <u>adjustment. PN 3/24/2023</u>		☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use																															
Tech Review: Corrected DGS lot # under Quality Checks. IS 04-13-2023		Taylor Gutschow Digitally signed by Taylor Gutschow Date: 2023.04.13 11:04:50 04'00' <u>5 09:39:26</u> Tech Review / Date Admin Review / Date																															

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT – INTOXILYZER 8000

Agency: FERNANDINA BEACH PD
Time of Inspection: 11:16

Date of Inspection: 04/11/2023

Serial Number: 80-005538
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202201C Exp: 01/11/2024	0.08g/210L Test (g/210L) Lot#:202201D Exp: 01/18/2024	0.20g/210L Test (g/210L) Lot#:202201E Exp: 01/18/2024	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG229803 Exp: 10/25/2024
0.000	0.050	0.079	0.201	0.080
0.000	0.050	0.079	0.201	0.080
0.000	0.050	0.080	0.201	0.080
0.000	0.050	0.080	0.201	0.079
0.000	0.050	0.080	0.201	0.079
0.000	0.050	0.080	0.201	0.079
0.000	0.051	0.080	0.201	0.079
0.000	0.051	0.080	0.201	0.079
0.000	0.050	0.079	0.200	0.079
0.000	0.051	0.079	0.201	0.079

Standard Deviations	0.0004	0.0005	0.0003	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0004 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Israel Soto ISRAEL SOTO
Signature and Printed Name

04/11/2023
Date

FERNANDINA BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005538
03/24/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	12:49
Control Test	0.048	12:50
Air Blank	0.000	12:50
Control Test	0.048	12:51
Air Blank	0.000	12:52
Control Test	0.047	12:52
Air Blank	0.000	12:53
Control Test Stats		
Average	0.0477	
Std Dev	0.0006	
Rel Std Dev(%)	1.2112	


Operator's Signature

FERNANDINA BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005538
03/24/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	12:57
Control Test	0.077	12:57
Air Blank	0.000	12:58
Control Test	0.078	12:59
Air Blank	0.000	12:59
Control Test	0.077	13:00
Air Blank	0.000	13:01
Control Test Stats		
Average	0.0773	
Std Dev	0.0006	
Rel Std Dev(%)	0.7466	


Operator's Signature

FERNANDINA BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005538
03/24/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	13:04
Control Test	0.198	13:04
Air Blank	0.000	13:05
Control Test	0.198	13:06
Air Blank	0.000	13:06
Control Test	0.197	13:07
Air Blank	0.000	13:07
Control Test Stats		
Average	0.1977	
Std Dev	0.0006	
Rel Std Dev(%)	0.2921	


Operator's Signature

FERNANDINA BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005538
03/24/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	13:08
Control Test	0.078	13:09
Air Blank	0.000	13:09
Control Test	0.078	13:09
Air Blank	0.000	13:10
Control Test	0.078	13:10
Air Blank	0.000	13:11
Control Test Stats		
Average	0.0760	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	


Operator's Signature

STABILITY CHECKS

DGS



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road.
Suite B1032
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-005538, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-005538</u>	UNCERTAINTY* $\pm$
Owning Agency:	<u>FERNANDINA BEACH PD</u>	0.050 g/ 210 L 0.004
Calibration Date:	<u>04/11/2023</u>	0.080 g/ 210 L 0.004
Calibration Time:	<u>11:16</u>	0.200 g/ 210 L 0.007
		0.080 g/ 210 L Dry Gas Control 0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Israel Soto
Soto
Date: 2023.04.11 11:43:22
-04'00'

04/11/2023

Date

ISRAEL SOTO,
Department Inspector

FDLE/ATP Form 69 March 2022

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

FERNANDINA BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005538
03/24/2023 13:37:28

Optical Bench Calibration
Adjustment



Auto Calibration

pg 1 of 2

<<<<< 3um >>>>> <<<<< 9um >>>>>

Solution = 0.000 g/210L or 0.0000 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	0.0470	(-0.0080)	0.1620	(-0.0070)
Sample #2	0.0960	(0.0040)	0.1580	(0.0110)
Sample #3	0.0440	(0.0560)	0.1430	(0.0210)
Sample #4	0.0610	(0.0580)	0.1490	(0.0340)
Avg % Abs	0.0670	(0.0393)	0.1500	(0.0220)
STD DEV	0.0265	(0.0306)	0.0075	(0.0115)
REL STD DEV	39.573	(77.837)	5.033	(52.421)

Solution = 0.040 g/210L or 0.1905 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	0.8050	(-0.0140)	1.5220	(-0.0110)
Sample #2	0.7600	(0.0100)	1.5040	(0.0140)
Sample #3	0.7980	(0.0200)	1.5070	(0.0330)
Sample #4	0.7430	(0.0720)	1.4980	(0.0320)
Avg % Abs	0.7670	(0.0340)	1.5030	(0.0263)
STD DEV	0.0282	(0.0333)	0.0046	(0.0107)
REL STD DEV	3.671	(97.902)	0.305	(40.605)

Solution = 0.100 g/210L or 0.4762 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	1.8330	(-0.0110)	3.4970	(0.0010)
Sample #2	1.8160	(0.0360)	3.4820	(0.0300)
Sample #3	1.8020	(0.0470)	3.4840	(0.0210)
Sample #4	1.7910	(0.0530)	3.4560	(0.0350)
Avg % Abs	1.8030	(0.0453)	3.4740	(0.0287)
STD DEV	0.0125	(0.0086)	0.0156	(0.0071)
REL STD DEV	0.695	(19.018)	0.450	(24.749)

Solution = 0.200 g/210L or 0.9524 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	3.5750	(-0.0120)	6.6790	(0.0140)
Sample #2	3.5390	(0.0160)	6.6420	(0.0530)
Sample #3	3.5490	(0.0300)	6.6570	(0.0430)
Sample #4	3.5000	(0.0550)	6.6340	(0.0590)
Avg % Abs	3.5293	(0.0337)	6.6443	(0.0517)
STD DEV	0.0259	(0.0198)	0.0117	(0.0081)
REL STD DEV	0.734	(58.684)	0.176	(15.644)

Solution = 0.300 g/210L or 1.4286 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	5.1490	(-0.0040)	9.6200	(-0.0010)
Sample #2	5.1740	(0.0110)	9.5830	(0.0610)
Sample #3	5.1330	(0.0440)	9.5700	(0.0670)
Sample #4	5.1110	(0.0500)	9.5650	(0.0640)
Avg % Abs	5.1393	(0.0350)	9.5727	(0.0640)
STD DEV	0.0320	(0.0210)	0.0093	(0.0030)
REL STD DEV	0.622	(60.000)	0.097	(4.688)

Optical Bench Calibration
Adjustment

FERNANDINA BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005538
03/24/2023 13:37:28

Auto Calibration

pg 2 of 2

<<<< 3um >>>>

Zero Order Coef -155.88
First Order Coef 2648.44
Second Order Coef 30.74

Act (g/210L)	Fit (g/210L)	Residual (g/210L)
0.000	0.000	-0.0005
0.040	0.040	0.0002
0.100	0.099	0.0009
0.200	0.201	-0.0011
0.300	0.300	0.0004

<<<< 9um >>>>

-191.73
1366.37
15.12

Act (g/210L)	Fit (g/210L)	Residual (g/210L)
0.000	0.000	-0.0003
0.040	0.040	0.0002
0.100	0.099	0.0005
0.200	0.201	-0.0006
0.300	0.300	0.0003

<<<< 3um >>>>

Solution = 0.080 g/210L or 0.3810 mg/l, Samples = 4, Discarded = 1
Sample

Sample #1	3344.00	3225.00
Sample #2	3289.00	3163.00
Sample #3	3297.00	3186.00
Sample #4	3316.00	3154.00
Avg	3300.6667	3167.6667
STD DEV	13.8684	16.5025
REL STD DEV	0.420	0.521
H2O adjust (mg/l*10k)	509	642

Barometric Pressure = 1013

*****CALIBRATION SUCCESSFUL*****

FERNANDINA BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005538
03/24/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	15:41
Control Test	0.049	15:42
Air Blank	0.000	15:42
Control Test	0.048	15:43
Air Blank	0.000	15:43
Control Test	0.048	15:44
Air Blank	0.000	15:45
Control Test Stats		
Average	0.0483	
Std Dev	0.0006	
Rel Std Dev(%)	1.1945	


Operator's Signature

FERNANDINA BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005538
03/24/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	15:45
Control Test	0.078	15:46
Air Blank	0.000	15:47
Control Test	0.078	15:47
Air Blank	0.000	15:48
Control Test	0.078	15:49
Air Blank	0.000	15:49
Control Test Stats		
Average	0.0780	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	


Operator's Signature

FERNANDINA BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005538
03/24/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	15:52
Control Test	0.199	15:53
Air Blank	0.000	15:53
Control Test	0.198	15:54
Air Blank	0.000	15:55
Control Test	0.198	15:55
Air Blank	0.000	15:56
Control Test Stats		
Average	0.1983	
Std Dev	0.0006	
Rel Std Dev(%)	0.2911	


Operator's Signature

FERNANDINA BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005538
03/24/2023
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	15:57
Control Test	0.079	15:57
Air Blank	0.000	15:58
Control Test	0.079	15:58
Air Blank	0.000	15:58
Control Test	0.079	15:59
Air Blank	0.000	15:59
Control Test Stats		
Average	0.0790	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	


Operator's Signature

Post calibration Adjustment
Stability checks

PN



Agency Fernandina Beach PD

S/N 80-005538

Date In 12-22-2023 DI Completion Date N/A

☐ Ship ☐ P/U ☐ H/D ☒ CMI ☐ EE

Calibration Adjustment

By_

Barometric Pressure Gauge _____ ID # _____

☐ Post Calibration Adjustment Stability Checks

Notes/Suggested Service: Instrument reads all zeroes
when stability testing wet solutions ALL 01-04-2024
Instrument will not pump to simulator to analyze ARS.
Send to repair. (BS 1/11/2024)

Department Inspection

By _____

Barometric Pressure ID# _____

Gauge _____ Instrument _____

Mouth Alcohol Solution Lot # _____

Acetone Stock Solution Lot #

Attachments

- | | |
|--|---|
| ☐ Form 41 | ☐ Post-Stability Checks |
| ☒ Stability Checks | ☐ Flow Calibration |
| ☐ Calibration Certificate | ☐ Form 40 |
| ☐ Calibration Adjustment | ☒ Other Form 51 |

- ☐ Instrument Complies with Chapter 11D-8, FAC
 - ☒ Instrument Does Not Comply with Chapter 11D-8, FAC

 - ☐ Return to/Place into Evidentiary Use
 - ☒ Remain Out of Evidentiary Use

 - ☐ Conduct an Agency Inspection Before Evidentiary Use

Tech Review / Date

Admin Review / Date

Stability Checks

FERNANDINA BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005538
01/04/2024
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	12:28
Control Test	0.000	12:28
Air Blank	0.000	12:29
Control Test	0.000	12:29
Air Blank	0.000	12:30
Control Test	0.000	12:31
Air Blank	0.000	12:31
Control Test Stats		
Average	0.0000	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

FERNANDINA BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005538
01/04/2024
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	12:32
Control Test	0.000	12:32
Air Blank	0.000	12:33
Control Test	0.000	12:34
Air Blank	0.000	12:34
Control Test	0.000	12:35
Air Blank	0.000	12:35
Control Test Stats		
Average	0.0000	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

FERNANDINA BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005538
01/04/2024
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	12:37
Control Test	0.000	12:38
Air Blank	0.000	12:39
Control Test	0.000	12:39
Air Blank	0.000	12:40
Control Test	0.000	12:40
Air Blank	0.000	12:41
Control Test Stats		
Average	0.0000	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

FERNANDINA BEACH PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005538
01/04/2024
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	12:42
Control Test	0.082	12:43
Air Blank	0.000	12:43
Control Test	0.082	12:44
Air Blank	0.000	12:44
Control Test	0.082	12:44
Air Blank	0.000	12:45
Control Test Stats		
Average	0.0820	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

Return Material Authorization

Ship to: ☒ CMI, Inc.

☐ Enforcement Electronics

Shipment to repair facility authorized by: Jason Smith on 1/12/2024

Items Returned: Instrument ☒ Supplies ☐ Other ☐ Describe: _____

Instrument Model: Intoxilyzer 8000 Serial Number: 80-005538

Bill To Address:

Jason Smith

Fernandina Beach PD

Ship to Address:

FDLE Off-Site Mail Facility

c/o Florida Dept of Law Enforcement

Alcohol Testing Program

813 B Lake Bradford Road

Tallahassee, FL 32304

Reason for Return:

Instrument is not pumping to the simulator to read control samples. Pump can turn on manually
with the keyboard.

Please choose one of the following options:

☐ 1. I _____, authorize all repairs.

☐ 2. I _____, authorize repairs up to \$_____.

☒ 3. I require an estimate **BEFORE** any repairs will be authorized and/ or conducted.

Please contact: Name: Jason Smith

Phone #: 904-310-3211

Email: jsmith@fbfl.org

ATP Contact Name: Benjamin Siddoway ATP Email: BenjaminSiddoway@fdle.state.fl.us