



Agency Hamilton County SO

S/N 80-000797

Date In 12/18/2024 DI Completion Date 12/19/2024

☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

## Calibration Adjustment

By \_\_\_\_\_

## ❑ Post Calibration Adjustment Stability Checks

[illegible]

## Department Inspection

By DA

Acetone Stock Solution Lot # 2023-B

## Attachments

- ☒ Instrument Complies with Chapter 11D-8, FAC
- ☐ Instrument Does Not Comply with Chapter 11D-8, FAC
- ☒ Return to/Place into Evidentiary Use
- ☐ Remain Out of Evidentiary Use
- ☒ Conduct an Agency Inspection Before Evidentiary Use

Phil Nicodemo

Shayla Platt Shayla Platt  
Date: 2024.12.20

Tech Review / Date

Admin Review / Date

Stability Checks 80-000797 12/19/24 DA

HAMILTON COUNTY SO  
Intoxilyzer - Alcohol Analyzer  
Model 8000 SN 80-000797  
12/19/2024  
Software: 8100.27

| Test               | g/210L | Time  |
|--------------------|--------|-------|
| Air Blank          | 0.000  | 10:33 |
| Control Test       | 0.049  | 10:34 |
| Air Blank          | 0.000  | 10:35 |
| Control Test       | 0.050  | 10:35 |
| Air Blank          | 0.000  | 10:36 |
| Control Test       | 0.048  | 10:37 |
| Air Blank          | 0.000  | 10:37 |
| Control Test Stats |        |       |
| Average            | 0.0490 |       |
| Std Dev            | 0.0010 |       |
| Rel Std Dev(%)     | 2.0408 |       |

DA

Operator's Signature

HAMILTON COUNTY SO  
Intoxilyzer - Alcohol Analyzer  
Model 8000 SN 80-000797  
12/19/2024  
Software: 8100.27

| Test               | g/210L | Time  |
|--------------------|--------|-------|
| Air Blank          | 0.000  | 10:39 |
| Control Test       | 0.080  | 10:40 |
| Air Blank          | 0.000  | 10:41 |
| Control Test       | 0.079  | 10:41 |
| Air Blank          | 0.000  | 10:42 |
| Control Test       | 0.079  | 10:43 |
| Air Blank          | 0.000  | 10:43 |
| Control Test Stats |        |       |
| Average            | 0.0793 |       |
| Std Dev            | 0.0006 |       |
| Rel Std Dev(%)     | 0.7277 |       |


wet



Operator's Signature

HAMILTON COUNTY SO  
Intoxilyzer - Alcohol Analyzer  
Model 8000 SN 80-000797  
12/19/2024  
Software: 8100.27

| Test               | g/210L | Time  |
|--------------------|--------|-------|
| Air Blank          | 0.000  | 10:44 |
| Control Test       | 0.200  | 10:45 |
| Air Blank          | 0.000  | 10:46 |
| Control Test       | 0.200  | 10:46 |
| Air Blank          | 0.000  | 10:47 |
| Control Test       | 0.199  | 10:48 |
| Air Blank          | 0.000  | 10:48 |
| Control Test Stats |        |       |
| Average            | 0.1997 |       |
| Std Dev            | 0.0006 |       |
| Rel Std Dev(%)     | 0.2892 |       |




Operator's Signature

HAMILTON COUNTY SO  
Intoxilyzer - Alcohol Analyzer  
Model 8000 SN 80-000797  
12/19/2024  
Software: 8100.27

| Test               | g/210L | Time  |
|--------------------|--------|-------|
| Air Blank          | 0.000  | 10:55 |
| Control Test       | 0.080  | 10:55 |
| Air Blank          | 0.000  | 10:56 |
| Control Test       | 0.081  | 10:56 |
| Air Blank          | 0.000  | 10:56 |
| Control Test       | 0.081  | 10:57 |
| Air Blank          | 0.000  | 10:57 |
| Control Test Stats |        |       |
| Average            | 0.0807 |       |
| Std Dev            | 0.0006 |       |
| Rel Std Dev(%)     | 0.7157 |       |

DGS



Operator's Signature

# Florida Department of Law Enforcement Alcohol Testing Program

## DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: HAMILTON COUNTY SO  
Time of Inspection: 12:37

Date of Inspection: 12/19/2024

Serial Number: 80-000797  
Software: 8100.27

| Check or Test                                  | YES | NO | Check or Test                             | YES | NO |
|------------------------------------------------|-----|----|-------------------------------------------|-----|----|
| Diagnostic Check<br>(Pre-Inspection): OK       | Yes |    | Date and/or Time Adjusted                 |     | No |
| Minimum Sample Volume<br>Check: OK             | Yes |    | Barometric Pressure Sensor<br>Check: OK   | Yes |    |
| Alcohol Free Subject<br>Test: 0.000            | Yes |    | Mouth Alcohol Test:<br>Slope Not Met      | Yes |    |
| Interferent Detect Test:<br>Interferent Detect | Yes |    | Diagnostic Check<br>(Post-Inspection): OK | Yes |    |

| Alcohol Free<br>Test<br>(g/210L) | 0.05g/210L Test<br>(g/210L)<br>Lot#:202406K<br>Exp: 06/19/2026 | 0.08g/210L Test<br>(g/210L)<br>Lot#:202406L<br>Exp: 06/19/2026 | 0.20g/210L Test<br>(g/210L)<br>Lot#:202406N<br>Exp: 06/20/2026 | 0.08 g/210L<br>Dry Gas Std Test<br>(g/210L)<br>Lot#:AG429602<br>Exp: 10/22/2026 |
|----------------------------------|----------------------------------------------------------------|----------------------------------------------------------------|----------------------------------------------------------------|---------------------------------------------------------------------------------|
| 0.000                            | 0.049                                                          | 0.079                                                          | 0.200                                                          | 0.080                                                                           |
| 0.000                            | 0.049                                                          | 0.080                                                          | 0.199                                                          | 0.080                                                                           |
| 0.000                            | 0.049                                                          | 0.080                                                          | 0.200                                                          | 0.080                                                                           |
| 0.000                            | 0.050                                                          | 0.079                                                          | 0.200                                                          | 0.080                                                                           |
| 0.000                            | 0.049                                                          | 0.080                                                          | 0.200                                                          | 0.080                                                                           |
| 0.000                            | 0.049                                                          | 0.080                                                          | 0.200                                                          | 0.079                                                                           |
| 0.000                            | 0.049                                                          | 0.080                                                          | 0.200                                                          | 0.080                                                                           |
| 0.000                            | 0.049                                                          | 0.080                                                          | 0.199                                                          | 0.079                                                                           |
| 0.000                            | 0.049                                                          | 0.080                                                          | 0.200                                                          | 0.079                                                                           |
| 0.000                            | 0.049                                                          | 0.080                                                          | 0.200                                                          | 0.079                                                                           |

|                     |        |        |        |        |
|---------------------|--------|--------|--------|--------|
| Standard Deviations | 0.0003 | 0.0004 | 0.0004 | 0.0005 |
|---------------------|--------|--------|--------|--------|

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0004 Number of Simulators Used: 5

Remarks:

The above instrument complies ( ☒ ) does not comply ( ☐ ) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



DESTINEE N ARMSTRONG

Signature and Printed Name

12/19/2024  
Date



# Calibration Certificate

Florida Department of Law Enforcement  
Alcohol Testing Program  
2331 Phillips Road  
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000797, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

|                   |                    |                                      |
|-------------------|--------------------|--------------------------------------|
| Serial Number:    | 80-000797          | UNCERTAINTY * $\pm$                  |
| Owning Agency:    | HAMILTON COUNTY SO | 0.050 g/ 210 L 0.004                 |
| Calibration Date: | 12/19/2024         | 0.080 g/ 210 L 0.004                 |
| Calibration Time: | 12:37              | 0.200 g/ 210 L 0.007                 |
|                   |                    | 0.080 g/ 210 L Dry Gas Control 0.005 |

All results are reported in g/ 210 L.  
Bias is limited by calibration acceptance criteria. All calibration results must be within  $\pm 0.005$  or 5%, whichever is greater, of the target alcohol concentration.  
\*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ( $k=3$ ).  
The instrument results before and after any adjustment are found in the associated pre and post stability checks.

**TRACEABILITY INFORMATION**  
This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.  
This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

FDLE/ATP Form 69 October 2024  
Issuing Authority: Alcohol Testing Program  
Date 12/19/2024   
DESTINEE N ARMSTRONG,  
Department Inspector  
Service • Integrity • Respect • Quality  
Page 1 of 1