



Agency FL Highway Patrol

S/N 80-006760

Date In 01-05-2024 DI Completion Date 01-23-2024

☐ Ship ☒ P/U ☐ H/D ☐ CMI ☐ EE

Intake By ALL Date 01-10-2024

- ☒ Annual
- ☐ Registration
- ☐ Return from CMI / EE

- Case
- Keyboard
- Feet
- Ports
- Handle
- Dry Gas Shelf
- Breath Tube
- Screws Tight

- ☐ Power cord
- ☐ Static Bag
- ☐ Printer Cable
- ☐ 12V DC Cable

Notes:

Quality Checks By ALL Date 01-11-2024

☒ Breath Tube Screen
☒ Replace External O-Rings
☒ Instrument Set Up Verified
☒ R-Value 116
☒ Flow Verification (L/s)
 Flow Column # ATP-103
 32 mm .148 (.139 - .169)
 36 mm .164 (.156 - .190)
 53 mm .238 (.228 - .278)
 103 mm .500 (.447 - .547)

■ Barometric Pressure Check
Gauge ID # 30793

■ Stability Checks

Flow Calibration By_____ Date_____

Flow Column # _____

☐ 5L/min – 17mm

☐ 15L/min – 53mm

☐ 30L/min – 103mm

☐ R-Value _____

☐ Post Calibration Verification (L/s)

Flow Column # _____

32 mm	_____	(.139 - .169)
36 mm	_____	(.156 - .190)
53 mm	_____	(.228 - .278)
103 mm	_____	(.447 - .547)

Maintenance By_____Date_____

☐ Battery Replacement
☐ Dry Gas Regulator Replacement
☐ Breath Tube Replacement
☐ Other _____

Calibration Adjustment By _____

Barometric Pressure Gauge _____ ID # _____

❑ Post Calibration Adjustment Stability Checks

Department Inspection By IS

Barometric Pressure ID# 28663
Gauge 1025 Instrument 1022
Mouth Alcohol Solution Lot # 2023-A
Acetone Stock Solution Lot # 2022-B

Attachments

☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment	☐ Post-Stability Checks ☐ Flow Calibration ☐ Form 40 ☐ Other _____
---	---

Notes/Suggested Service: _____

- ☒ Instrument Complies with Chapter 11D-8, FAC
- ☐ Instrument Does Not Comply with Chapter 11D-8, FAC
- ☒ Return to/Place into Evidentiary Use
- ☐ Remain Out of Evidentiary Use
- ☒ Conduct an Agency Inspection Before Evidentiary Use

Benjamin
Siddoway

Phil Nicodemo Digitally signed by Phil Nicodemo
Date: 2024.01.24 13:32:41 -05'00'

Tech Review / Date

Admin Review / Date

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: FL HIGHWAY PATROL
Time of Inspection: 12:52

Date of Inspection: 01/23/2024

Serial Number: 80-006760
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202303K Exp: 03/29/2025	0.08g/210L Test (g/210L) Lot#:202303L Exp: 03/29/2025	0.20g/210L Test (g/210L) Lot#:202304C Exp: 04/05/2025	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG310901 Exp: 04/19/2025
0.000	0.049	0.079	0.195	0.078
0.000	0.049	0.078	0.195	0.079
0.000	0.049	0.079	0.195	0.079
0.000	0.049	0.079	0.195	0.078
0.000	0.049	0.079	0.195	0.079
0.000	0.049	0.079	0.195	0.078
0.000	0.049	0.079	0.195	0.078
0.000	0.049	0.079	0.195	0.078
0.000	0.049	0.079	0.195	0.078
0.000	0.049	0.079	0.195	0.078
0.000	0.049	0.079	0.195	0.078
0.000	0.050	0.079	0.195	0.078
Standard Deviations	0.0003	0.0003	0.0000	0.0004

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0002 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Israel Soto

ISRAEL SOTO

Signature and Printed Name

01/23/2024
Date

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006760
01/11/2024
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:28
Control Test	0.050	11:28
Air Blank	0.000	11:29
Control Test	0.050	11:30
Air Blank	0.000	11:30
Control Test	0.050	11:31
Air Blank	0.000	11:31
Control Test Stats		
Average	0.0500	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006760
01/11/2024
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:34
Control Test	0.080	11:34
Air Blank	0.000	11:35
Control Test	0.080	11:36
Air Blank	0.000	11:36
Control Test	0.079	11:37
Air Blank	0.000	11:37
Control Test Stats		
Average	0.0797	
Std Dev	0.0006	
Rel Std Dev(%)	0.7247	

Operator's Signature

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006760
01/11/2024
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:44
Control Test	0.198	11:44
Air Blank	0.000	11:45
Control Test	0.197	11:46
Air Blank	0.000	11:46
Control Test	0.197	11:47
Air Blank	0.000	11:47
Control Test Stats		
Average	0.1973	
Std Dev	0.0006	
Rel Std Dev(%)	0.2926	

Operator's Signature

FL HIGHWAY PATROL
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006760
01/11/2024
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	11:39
Control Test	0.079	11:39
Air Blank	0.000	11:40
Control Test	0.079	11:40
Air Blank	0.000	11:41
Control Test	0.079	11:41
Air Blank	0.000	11:42
Control Test Stats		
Average	0.0790	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Operator's Signature

065



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road.
Suite B 1032
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-006760, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-006760</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>FL HIGHWAY PATROL</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>01/23/2024</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>12:52</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence (k=3).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.
This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

01/23/2024

Date

ISRAEL SOTO,

Department Inspector

FDLE/ATP Form 69 March 2022

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality