



INSTRUMENT PROCESSING SHEET

Agency Miami Dade PD

S/N 80-000882

Florida Department of
Law EnforcementDate In 12/21/2023 DI Completion Date 01/12/2024☐ Ship ☐ P/U ☐ H/D ☒ CMI ☐ EE

Intake	By TDG	Date	Quality Checks	By TDG	Date	Flow Calibration	By	Date																												
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: <u>AI reports the instrument will only partially upload in the field, and remote uploads are unsuccessful. Presented with similar complaints in late 2023.</u>		01/11/2024	☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>151</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP106</u> 32 mm <u>0.144</u> (.139 - .169) 36 mm <u>0.164</u> (.156 - .190) 53 mm <u>0.230</u> (.228 - .278) 103 mm <u>0.496</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>26932</u> ☒ Stability Checks		01/11/2024	Flow Column # _____ ☐ 5L/min - 17mm ☐ 15L/min - 53mm ☐ 30L/min - 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																														
			<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP5094</td><td>202303K 03/29/2025</td></tr><tr><td>0.080</td><td>MP5095</td><td>202303L 03/29/2025</td></tr><tr><td>0.200</td><td>MP5096</td><td>202304C 04/05/2025</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>01923080A3 02/05/2025</td></tr></tbody></table>	Simulator	Serial #	Lot #/Exp	0.050	MP5094	202303K 03/29/2025	0.080	MP5095	202303L 03/29/2025	0.200	MP5096	202304C 04/05/2025	0.080 DGS	N/A	01923080A3 02/05/2025																		
Simulator	Serial #	Lot #/Exp																																		
0.050	MP5094	202303K 03/29/2025																																		
0.080	MP5095	202303L 03/29/2025																																		
0.200	MP5096	202304C 04/05/2025																																		
0.080 DGS	N/A	01923080A3 02/05/2025																																		
Calibration Adjustment			Department Inspection																																	
Barometric Pressure Gauge _____ ID # _____			Barometric Pressure ID# <u>26932</u>																																	
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td></td><td></td><td></td></tr><tr><td>0.100</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.300</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>			Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Gauge <u>1013</u> Instrument <u>1012</u> Mouth Alcohol Solution Lot # <u>2023-A</u> Acetone Stock Solution Lot # <u>2022-B</u>					
Simulator	Serial #	Lot #	Expiration																																	
0.000		N/A	N/A																																	
0.040																																				
0.100																																				
0.200																																				
0.300																																				
0.080 DGS	N/A																																			
☐ Post Calibration Adjustment Stability Checks			<table border="1"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td>MP5092</td></tr><tr><td>Interferent</td><td>MP5093</td></tr><tr><td>0.050</td><td>MP5094</td></tr><tr><td>0.080</td><td>MP5095</td></tr><tr><td>0.200</td><td>MP5096</td></tr></tbody></table>						Simulator	Serial Number	0.000	MP5092	Interferent	MP5093	0.050	MP5094	0.080	MP5095	0.200	MP5096																
Simulator	Serial Number																																			
0.000	MP5092																																			
Interferent	MP5093																																			
0.050	MP5094																																			
0.080	MP5095																																			
0.200	MP5096																																			
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td></td><td></td><td></td></tr><tr><td>0.080</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Attachments ☒ Form 41 ☐ Post-Stability Checks ☒ Stability Checks ☐ Flow Calibration ☒ Calibration Certificate ☐ Form 40 ☐ Calibration Adjustment ☒ Other <u>Form 51</u>													
Simulator	Serial #	Lot #	Expiration																																	
0.050																																				
0.080																																				
0.200																																				
0.080 DGS	N/A																																			
Notes/Suggested Service: <u>Uploaded via direct-connect on 1/11 and 1/12 with no issue. Sending to CMI. (TDG)</u>			☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☐ Return to/Place into Evidentiary Use ☒ Remain Out of Evidentiary Use ☐ Conduct an Agency Inspection Before Evidentiary Use																																	
Benjamin Siddoway Digitally signed by Benjamin Siddoway Date: 2024.01.12 13:47:56 -05'00'			Phil Nicodemo Digitally signed by Phil Nicodemo Date: 2024.01.22 14:15:12 -05'00'																																	
Tech Review / Date			Admin Review / Date																																	

Stability Checks

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L
0.047 to 0.053	0.077 to 0.083	0.194 to 0.206	0.077 to 0.083
✓	✓	✓	✓
MIAMI DADE PD Intoxilyzer - Alcohol Analyzer Model 8000 01/11/2024 Software: 8100.27 Test g/210L Time Air Blank 0.000 14:11 Control Test 0.051 14:11 Air Blank 0.000 14:12 Control Test 0.050 14:13 Air Blank 0.000 14:13 Control Test 0.050 14:14 Air Blank 0.000 14:14 Control Test Status Average 0.0503 Std Dev 0.0006 Rel Std Dev(%) 1.1471 Operator's Signature 	MIAMI DADE PD Intoxilyzer - Alcohol Analyzer Model 8000 01/11/2024 Software: 8100.27 Test g/210L Time Air Blank 0.000 14:17 Control Test 0.080 14:18 Air Blank 0.000 14:19 Control Test 0.077 14:19 Air Blank 0.000 14:20 Control Test 0.079 14:20 Air Blank 0.000 14:21 Control Test Status Average 0.0787 Std Dev 0.0015 Rel Std Dev(%) 1.9418 Operator's Signature 	MIAMI DADE PD Intoxilyzer - Alcohol Analyzer Model 8000 01/11/2024 Software: 8100.27 Test g/210L Time Air Blank 0.000 14:24 Control Test 0.197 14:25 Air Blank 0.000 14:25 Control Test 0.196 14:26 Air Blank 0.000 14:27 Control Test 0.196 14:27 Air Blank 0.000 14:28 Control Test Status Average 0.1963 Std Dev 0.0006 Rel Std Dev(%) 0.2941 Operator's Signature 	MIAMI DADE PD Intoxilyzer - Alcohol Analyzer Model 8000 01/11/2024 Software: 8100.27 Test g/210L Time Air Blank 0.000 14:04 Control Test 0.080 14:04 Air Blank 0.000 14:05 Control Test 0.081 14:05 Air Blank 0.000 14:05 Control Test 0.082 14:06 Air Blank 0.000 14:06 Control Test Status Average 0.0810 Std Dev 0.0010 Rel Std Dev(%) 1.2346 Operator's Signature 

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: MIAMI DADE PD
Time of Inspection: 12:52

Date of Inspection: 01/12/2024

Serial Number: 80-000882
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202303K Exp: 03/29/2025	0.08g/210L Test (g/210L) Lot#:202303L Exp: 03/29/2025	0.20g/210L Test (g/210L) Lot#:202304C Exp: 04/05/2025	0.08 g/210L Dry Gas Std Test* (g/210L) Lot#:01923080A3 Exp: 02/05/2025
0.000	0.050	0.078	0.197	0.080
0.000	0.050	0.078	0.197	0.080
0.000	0.050	0.078	0.197	0.080
0.000	0.050	0.078	0.197	0.080
0.000	0.050	0.077	0.197	0.080
0.000	0.050	0.078	0.197	0.081
0.000	0.050	0.078	0.197	0.080
0.000	0.050	0.078	0.197	0.081
0.000	0.050	0.077	0.197	0.080
0.000	0.050	0.078	0.196	0.080


Standard Deviations	0.0000	0.0004	0.0003	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0002 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



TAYLOR D GUTSCHOW
Signature and Printed Name

01/12/2024
Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000882, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000882</u>	UNCERTAINTY* $\pm$
Owning Agency:	<u>MIAMI DADE PD</u>	0.050 g/ 210 L 0.004
Calibration Date:	<u>01/12/2024</u>	0.080 g/ 210 L 0.004
Calibration Time:	<u>12:52</u>	0.200 g/ 210 L 0.007
		0.080 g/ 210 L Dry Gas Control 0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.
This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

01/12/2024

Date

Taylor D Gutschow

TAYLOR D GUTSCHOW,
Department Inspector

FDLE/ATP Form 69 December 2021

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

Return Material Authorization

Ship to:



CMI, Inc.



Enforcement Electronics

Shipment to repair facility authorized by: Richard Closius on 01/12/2024

Items Returned: Instrument ☒ Supplies ☐ Other ☐ Describe: _____

Instrument Model: Intoxilyzer 8000 Serial Number: 80-000882

Bill To Address:

Miami Dade Police Department

Attn: Richard Closius

Ship to Address:

Florida Department of Law Enforcement

Fort Myers Regional Operations Center

Attn: Alcohol Testing Program

4700 Terminal Drive, Suite 1

Fort Myers, FL 33907

Reason for Return:

Instrument will only partially upload in the field. Attempts to remotely upload are unsuccessful.

Instrument previously had a RAM Fail/Error 17 that was cleared remotely by CMI on 10/17/23.

All records have been uploaded via direct-connect by FDLE.

Please choose one of the following options:

☐ 1. I _____, authorize all repairs.

☐ 2. I _____, authorize repairs up to \$_____.

☒ 3. I require an estimate **BEFORE** any repairs will be authorized and/ or conducted.

Please contact: Name: Richard Closius

Phone #: (305) 458-3991

Email: rclosius@mdpd.com

ATP Contact Name: Taylor Gutschow

ATP Email: TaylorGutschow@fdle.state.fl.us