



INSTRUMENT PROCESSING SHEET

Agency FFWCCS/N 80-000906Florida Department of
Law EnforcementDate In 06/06/2024DI Completion Date 06/12/2024☐ Ship☒ P/U☐ H/D☐ CMI☐ EE

Intake	By TDG	Date	Quality Checks	By TDG	Date	Flow Calibration	By	Date																												
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☒ Power cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes: <u>Dropped off in a pelican case with DGS.</u>		<u>06/11/2024</u>	☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>230</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP104</u> 32 mm <u>0.152</u> (.139 - .169) 36 mm <u>0.171</u> (.156 - .190) 53 mm <u>0.246</u> (.228 - .278) 103 mm <u>0.507</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>26932</u> ☒ Stability Checks		<u>06/12/2024</u>	Flow Column # _____ ☐ 5L/min - 17mm ☐ 15L/min - 53mm ☐ 30L/min - 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																														
			<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP5099</td><td>202303K 03/29/2025</td></tr><tr><td>0.080</td><td>MP5100</td><td>202303L 03/29/2025</td></tr><tr><td>0.200</td><td>MP5101</td><td>202304C 04/05/2025</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG222203 08/10/2024</td></tr></tbody></table>	Simulator	Serial #	Lot #/Exp	0.050	MP5099	202303K 03/29/2025	0.080	MP5100	202303L 03/29/2025	0.200	MP5101	202304C 04/05/2025	0.080 DGS	N/A	AG222203 08/10/2024																		
Simulator	Serial #	Lot #/Exp																																		
0.050	MP5099	202303K 03/29/2025																																		
0.080	MP5100	202303L 03/29/2025																																		
0.200	MP5101	202304C 04/05/2025																																		
0.080 DGS	N/A	AG222203 08/10/2024																																		
Calibration Adjustment			Department Inspection																																	
Barometric Pressure Gauge _____ ID # _____			Barometric Pressure ID# <u>26932</u>																																	
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td></td><td></td><td></td></tr><tr><td>0.100</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.300</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>			Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Gauge <u>1013</u> Instrument <u>1012</u> Mouth Alcohol Solution Lot # <u>2023-A</u> Acetone Stock Solution Lot # <u>2023-B</u>					
Simulator	Serial #	Lot #	Expiration																																	
0.000		N/A	N/A																																	
0.040																																				
0.100																																				
0.200																																				
0.300																																				
0.080 DGS	N/A																																			
☐ Post Calibration Adjustment Stability Checks			<table border="1"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td>MP5097</td></tr><tr><td>Interferent</td><td>MP5098</td></tr><tr><td>0.050</td><td>MP5099</td></tr><tr><td>0.080</td><td>MP5100</td></tr><tr><td>0.200</td><td>MP5101</td></tr></tbody></table>						Simulator	Serial Number	0.000	MP5097	Interferent	MP5098	0.050	MP5099	0.080	MP5100	0.200	MP5101																
Simulator	Serial Number																																			
0.000	MP5097																																			
Interferent	MP5098																																			
0.050	MP5099																																			
0.080	MP5100																																			
0.200	MP5101																																			
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td></td><td></td><td></td></tr><tr><td>0.080</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Attachments ☒ Form 41 ☐ Post-Stability Checks ☒ Stability Checks ☐ Flow Calibration ☒ Calibration Certificate ☐ Form 40 ☐ Calibration Adjustment ☐ Other _____													
Simulator	Serial #	Lot #	Expiration																																	
0.050																																				
0.080																																				
0.200																																				
0.080 DGS	N/A																																			
Notes/Suggested Service: <u>Instrument had a Department Inspection in May and was inadvertently dropped off with other instruments for another inspection. (TDG)</u>			☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use																																	
			Phil Nicodemo Tech Review / Date																																	
			Shayla Platt Admin Review / Date																																	
			Digitally signed by Phil Nicodemo Date: 2024.06.19 09:30:07 -0400																																	
			Digitally signed by Shayla Platt Date: 2024.06.20 12:03:55 -0400																																	

Stability Checks

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L																																																																																																																																																
0.047 to 0.053	0.077 to 0.083	0.194 to 0.206	0.077 to 0.083																																																																																																																																																
FFWCC Intoxilyzer - Alcohol Analyzer Model 8000 06/12/2024 Software: 8100.27 SN 80-000906 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>11:12</td></tr> <tr><td>Control Test</td><td>0.049</td><td>11:13</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:14</td></tr> <tr><td>Control Test</td><td>0.049</td><td>11:14</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:15</td></tr> <tr><td>Control Test</td><td>0.048</td><td>11:16</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:16</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0487</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel. Std Dev(%)</td><td>1.1853</td><td></td></tr> </tbody> </table> Operator's Signature 	Test	g/210L	Time	Air Blank	0.000	11:12	Control Test	0.049	11:13	Air Blank	0.000	11:14	Control Test	0.049	11:14	Air Blank	0.000	11:15	Control Test	0.048	11:16	Air Blank	0.000	11:16	Control Test Stats			Average	0.0487		Std Dev	0.0006		Rel. Std Dev(%)	1.1853		FFWCC Intoxilyzer - Alcohol Analyzer Model 8000 06/12/2024 Software: 8100.27 SN 80-000906 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>11:21</td></tr> <tr><td>Control Test</td><td>0.078</td><td>11:22</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:22</td></tr> <tr><td>Control Test</td><td>0.079</td><td>11:23</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:24</td></tr> <tr><td>Control Test</td><td>0.078</td><td>11:24</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:25</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0783</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel. Std Dev(%)</td><td>0.7370</td><td></td></tr> </tbody> </table> Operator's Signature 	Test	g/210L	Time	Air Blank	0.000	11:21	Control Test	0.078	11:22	Air Blank	0.000	11:22	Control Test	0.079	11:23	Air Blank	0.000	11:24	Control Test	0.078	11:24	Air Blank	0.000	11:25	Control Test Stats			Average	0.0783		Std Dev	0.0006		Rel. Std Dev(%)	0.7370		FFWCC Intoxilyzer - Alcohol Analyzer Model 8000 06/12/2024 Software: 8100.27 SN 80-000906 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>11:28</td></tr> <tr><td>Control Test</td><td>0.198</td><td>11:29</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:30</td></tr> <tr><td>Control Test</td><td>0.198</td><td>11:30</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:31</td></tr> <tr><td>Control Test</td><td>0.197</td><td>11:31</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:32</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.1977</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel. Std Dev(%)</td><td>0.2921</td><td></td></tr> </tbody> </table> Operator's Signature 	Test	g/210L	Time	Air Blank	0.000	11:28	Control Test	0.198	11:29	Air Blank	0.000	11:30	Control Test	0.198	11:30	Air Blank	0.000	11:31	Control Test	0.197	11:31	Air Blank	0.000	11:32	Control Test Stats			Average	0.1977		Std Dev	0.0006		Rel. Std Dev(%)	0.2921		FFWCC Intoxilyzer - Alcohol Analyzer Model 8000 06/12/2024 Software: 8100.27 SN 80-000906 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>11:05</td></tr> <tr><td>Control Test</td><td>0.082</td><td>11:05</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:06</td></tr> <tr><td>Control Test</td><td>0.080</td><td>11:06</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:07</td></tr> <tr><td>Control Test</td><td>0.081</td><td>11:07</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:08</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0810</td><td></td></tr> <tr><td>Std Dev</td><td>0.0010</td><td></td></tr> <tr><td>Rel. Std Dev(%)</td><td>1.2346</td><td></td></tr> </tbody> </table> Operator's Signature 	Test	g/210L	Time	Air Blank	0.000	11:05	Control Test	0.082	11:05	Air Blank	0.000	11:06	Control Test	0.080	11:06	Air Blank	0.000	11:07	Control Test	0.081	11:07	Air Blank	0.000	11:08	Control Test Stats			Average	0.0810		Std Dev	0.0010		Rel. Std Dev(%)	1.2346	
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	11:12																																																																																																																																																	
Control Test	0.049	11:13																																																																																																																																																	
Air Blank	0.000	11:14																																																																																																																																																	
Control Test	0.049	11:14																																																																																																																																																	
Air Blank	0.000	11:15																																																																																																																																																	
Control Test	0.048	11:16																																																																																																																																																	
Air Blank	0.000	11:16																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0487																																																																																																																																																		
Std Dev	0.0006																																																																																																																																																		
Rel. Std Dev(%)	1.1853																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	11:21																																																																																																																																																	
Control Test	0.078	11:22																																																																																																																																																	
Air Blank	0.000	11:22																																																																																																																																																	
Control Test	0.079	11:23																																																																																																																																																	
Air Blank	0.000	11:24																																																																																																																																																	
Control Test	0.078	11:24																																																																																																																																																	
Air Blank	0.000	11:25																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0783																																																																																																																																																		
Std Dev	0.0006																																																																																																																																																		
Rel. Std Dev(%)	0.7370																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	11:28																																																																																																																																																	
Control Test	0.198	11:29																																																																																																																																																	
Air Blank	0.000	11:30																																																																																																																																																	
Control Test	0.198	11:30																																																																																																																																																	
Air Blank	0.000	11:31																																																																																																																																																	
Control Test	0.197	11:31																																																																																																																																																	
Air Blank	0.000	11:32																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.1977																																																																																																																																																		
Std Dev	0.0006																																																																																																																																																		
Rel. Std Dev(%)	0.2921																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	11:05																																																																																																																																																	
Control Test	0.082	11:05																																																																																																																																																	
Air Blank	0.000	11:06																																																																																																																																																	
Control Test	0.080	11:06																																																																																																																																																	
Air Blank	0.000	11:07																																																																																																																																																	
Control Test	0.081	11:07																																																																																																																																																	
Air Blank	0.000	11:08																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0810																																																																																																																																																		
Std Dev	0.0010																																																																																																																																																		
Rel. Std Dev(%)	1.2346																																																																																																																																																		

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT – INTOXILYZER 8000

Agency: FFWCC

Time of Inspection: 14:34

Date of Inspection: 06/12/2024

Serial Number: 80-000906

Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202303K Exp: 03/29/2025	0.08g/210L Test (g/210L) Lot#:202303L Exp: 03/29/2025	0.20g/210L Test (g/210L) Lot#:202304C Exp: 04/05/2025	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG222203 Exp: 08/10/2024
0.000	0.049	0.078	0.198	0.080
0.000	0.049	0.079	0.198	0.080
0.000	0.049	0.079	0.198	0.080
0.000	0.049	0.078	0.199	0.079
0.000	0.049	0.079	0.198	0.080
0.000	0.049	0.079	0.198	0.080
0.000	0.049	0.078	0.198	0.079
0.000	0.049	0.079	0.199	0.080
0.000	0.049	0.078	0.199	0.079
0.000	0.050	0.079	0.198	0.079


Standard Deviations	0.0003	0.0005	0.0004	0.0005
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0004 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



TAYLOR D GUTSCHOW

Signature and Printed Name

06/12/2024
Date



ANAB

ANSI National Accreditation Board
ACCREDITED

ISO/IEC 17025
FORENSIC CALIBRATION
LABORATORY

Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000906, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000906</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>FFWCC</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>06/12/2024</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>14:34</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration. *Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards. This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

06/12/2024

Date

Taylor D Gutschow

TAYLOR D GUTSCHOW,

Department Inspector

FDLE/ATP Form 69 December 2021

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality



INSTRUMENT PROCESSING SHEET

Agency FFWCCS/N 80-000906Florida Department of
Law EnforcementDate In 05/02/2024 DI Completion Date 05/13/2024☐ Ship ☒ P/U ☐ H/D ☐ CMI ☐ EE

Intake By <u>TDG</u> Date <u>05/13/2024</u>		Quality Checks By <u>TDG</u> Date <u>05/13/2024</u>		Flow Calibration By _____ Date _____																													
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☒ Power cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes: <u>Hand-delivered in pelican case w/ DGS.</u>		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>234</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP104</u> 32 mm <u>0.148</u> (.139 - .169) 36 mm <u>0.171</u> (.156 - .190) 53 mm <u>0.238</u> (.228 - .278) 103 mm <u>0.503</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>68639</u> ☒ Stability Checks		Flow Column # _____ ☐ 5L/min - 17mm ☐ 15L/min - 53mm ☐ 30L/min - 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																													
		<table border="1" style="width:100%"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP6286</td><td>202303K 03/29/2025</td></tr><tr><td>0.080</td><td>MP6287</td><td>202303L 03/29/2025</td></tr><tr><td>0.200</td><td>MP6288</td><td>202304C 04/05/2025</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG222203 08/10/2024</td></tr></tbody></table>		Simulator	Serial #	Lot #/Exp	0.050	MP6286	202303K 03/29/2025	0.080	MP6287	202303L 03/29/2025	0.200	MP6288	202304C 04/05/2025	0.080 DGS	N/A	AG222203 08/10/2024	Maintenance By _____ Date _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____														
Simulator	Serial #	Lot #/Exp																															
0.050	MP6286	202303K 03/29/2025																															
0.080	MP6287	202303L 03/29/2025																															
0.200	MP6288	202304C 04/05/2025																															
0.080 DGS	N/A	AG222203 08/10/2024																															
Calibration Adjustment By _____				Department Inspection By <u>TDG</u>																													
Barometric Pressure Gauge _____ ID # _____				Barometric Pressure ID# <u>68639</u>																													
<table border="1" style="width:100%"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td></td><td></td><td></td></tr><tr><td>0.100</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.300</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>				Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Gauge <u>1014</u> Instrument <u>1013</u> Mouth Alcohol Solution Lot # <u>2023-A</u> Acetone Stock Solution Lot # <u>2022-B</u>	
Simulator	Serial #	Lot #	Expiration																														
0.000		N/A	N/A																														
0.040																																	
0.100																																	
0.200																																	
0.300																																	
0.080 DGS	N/A																																
☐ Post Calibration Adjustment Stability Checks				<table border="1" style="width:100%"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td>MP6284</td></tr><tr><td>Interferent</td><td>MP6285</td></tr><tr><td>0.050</td><td>MP6286</td></tr><tr><td>0.080</td><td>MP6287</td></tr><tr><td>0.200</td><td>MP6288</td></tr></tbody></table>		Simulator	Serial Number	0.000	MP6284	Interferent	MP6285	0.050	MP6286	0.080	MP6287	0.200	MP6288																
Simulator	Serial Number																																
0.000	MP6284																																
Interferent	MP6285																																
0.050	MP6286																																
0.080	MP6287																																
0.200	MP6288																																
<table border="1" style="width:100%"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td></td><td></td><td></td></tr><tr><td>0.080</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>				Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Attachments ☒ Form 41 ☐ Post-Stability Checks ☒ Stability Checks ☐ Flow Calibration ☒ Calibration Certificate ☐ Form 40 ☐ Calibration Adjustment ☐ Other _____									
Simulator	Serial #	Lot #	Expiration																														
0.050																																	
0.080																																	
0.200																																	
0.080 DGS	N/A																																
Notes/Suggested Service: _____				☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use																													
				Digitally signed by <u>Shayla Platt</u> Phil Nicodemo Date: 2024.05.16 07:43:55 -0400 Date: 2024.05.16 10:46:30 -0400																													
				Tech Review / Date _____ Admin Review / Date _____																													

Stability Checks

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L																																																																																																																																				
0.047 to 0.053	0.077 to 0.083	0.194 to 0.206	0.077 to 0.083																																																																																																																																				
FFIACC Intoxilyzer - Alcohol Analyzer Model 8000 05/13/2024 Software: 8100.27 SN 80-000906 Test g/210L Time <table border="1"> <tr><td>Air Blank</td><td>0.000</td><td>10:10</td></tr> <tr><td>Control Test</td><td>0.049</td><td>10:11</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:11</td></tr> <tr><td>Control Test</td><td>0.050</td><td>10:12</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:13</td></tr> <tr><td>Control Test</td><td>0.049</td><td>10:13</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:14</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0493</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>1.1703</td><td></td></tr> </table> Operator's Signature 	Air Blank	0.000	10:10	Control Test	0.049	10:11	Air Blank	0.000	10:11	Control Test	0.050	10:12	Air Blank	0.000	10:13	Control Test	0.049	10:13	Air Blank	0.000	10:14	Control Test Stats			Average	0.0493		Std Dev	0.0006		Rel Std Dev(%)	1.1703		FFIACC Intoxilyzer - Alcohol Analyzer Model 8000 05/13/2024 Software: 8100.27 SN 80-000906 Test g/210L Time <table border="1"> <tr><td>Air Blank</td><td>0.000</td><td>10:17</td></tr> <tr><td>Control Test</td><td>0.079</td><td>10:17</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:18</td></tr> <tr><td>Control Test</td><td>0.079</td><td>10:19</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:19</td></tr> <tr><td>Control Test</td><td>0.077</td><td>10:20</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:20</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0783</td><td></td></tr> <tr><td>Std Dev</td><td>0.0012</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>1.4741</td><td></td></tr> </table> Operator's Signature 	Air Blank	0.000	10:17	Control Test	0.079	10:17	Air Blank	0.000	10:18	Control Test	0.079	10:19	Air Blank	0.000	10:19	Control Test	0.077	10:20	Air Blank	0.000	10:20	Control Test Stats			Average	0.0783		Std Dev	0.0012		Rel Std Dev(%)	1.4741		FFIACC Intoxilyzer - Alcohol Analyzer Model 8000 05/13/2024 Software: 8100.27 SN 80-000906 Test g/210L Time <table border="1"> <tr><td>Air Blank</td><td>0.000</td><td>10:29</td></tr> <tr><td>Control Test</td><td>0.198</td><td>10:29</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:30</td></tr> <tr><td>Control Test</td><td>0.197</td><td>10:31</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:31</td></tr> <tr><td>Control Test</td><td>0.197</td><td>10:32</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:32</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.1973</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.2926</td><td></td></tr> </table> Operator's Signature 	Air Blank	0.000	10:29	Control Test	0.198	10:29	Air Blank	0.000	10:30	Control Test	0.197	10:31	Air Blank	0.000	10:31	Control Test	0.197	10:32	Air Blank	0.000	10:32	Control Test Stats			Average	0.1973		Std Dev	0.0006		Rel Std Dev(%)	0.2926		FFIACC Intoxilyzer - Alcohol Analyzer Model 8000 05/13/2024 Software: 8100.27 SN 80-000906 Test g/210L Time <table border="1"> <tr><td>Air Blank</td><td>0.000</td><td>10:07</td></tr> <tr><td>Control Test</td><td>0.082</td><td>10:07</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:08</td></tr> <tr><td>Control Test</td><td>0.080</td><td>10:08</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:08</td></tr> <tr><td>Control Test</td><td>0.080</td><td>10:09</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:09</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0807</td><td></td></tr> <tr><td>Std Dev</td><td>0.0012</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>1.4314</td><td></td></tr> </table> Operator's Signature 	Air Blank	0.000	10:07	Control Test	0.082	10:07	Air Blank	0.000	10:08	Control Test	0.080	10:08	Air Blank	0.000	10:08	Control Test	0.080	10:09	Air Blank	0.000	10:09	Control Test Stats			Average	0.0807		Std Dev	0.0012		Rel Std Dev(%)	1.4314	
Air Blank	0.000	10:10																																																																																																																																					
Control Test	0.049	10:11																																																																																																																																					
Air Blank	0.000	10:11																																																																																																																																					
Control Test	0.050	10:12																																																																																																																																					
Air Blank	0.000	10:13																																																																																																																																					
Control Test	0.049	10:13																																																																																																																																					
Air Blank	0.000	10:14																																																																																																																																					
Control Test Stats																																																																																																																																							
Average	0.0493																																																																																																																																						
Std Dev	0.0006																																																																																																																																						
Rel Std Dev(%)	1.1703																																																																																																																																						
Air Blank	0.000	10:17																																																																																																																																					
Control Test	0.079	10:17																																																																																																																																					
Air Blank	0.000	10:18																																																																																																																																					
Control Test	0.079	10:19																																																																																																																																					
Air Blank	0.000	10:19																																																																																																																																					
Control Test	0.077	10:20																																																																																																																																					
Air Blank	0.000	10:20																																																																																																																																					
Control Test Stats																																																																																																																																							
Average	0.0783																																																																																																																																						
Std Dev	0.0012																																																																																																																																						
Rel Std Dev(%)	1.4741																																																																																																																																						
Air Blank	0.000	10:29																																																																																																																																					
Control Test	0.198	10:29																																																																																																																																					
Air Blank	0.000	10:30																																																																																																																																					
Control Test	0.197	10:31																																																																																																																																					
Air Blank	0.000	10:31																																																																																																																																					
Control Test	0.197	10:32																																																																																																																																					
Air Blank	0.000	10:32																																																																																																																																					
Control Test Stats																																																																																																																																							
Average	0.1973																																																																																																																																						
Std Dev	0.0006																																																																																																																																						
Rel Std Dev(%)	0.2926																																																																																																																																						
Air Blank	0.000	10:07																																																																																																																																					
Control Test	0.082	10:07																																																																																																																																					
Air Blank	0.000	10:08																																																																																																																																					
Control Test	0.080	10:08																																																																																																																																					
Air Blank	0.000	10:08																																																																																																																																					
Control Test	0.080	10:09																																																																																																																																					
Air Blank	0.000	10:09																																																																																																																																					
Control Test Stats																																																																																																																																							
Average	0.0807																																																																																																																																						
Std Dev	0.0012																																																																																																																																						
Rel Std Dev(%)	1.4314																																																																																																																																						

Florida Department of Law Enforcement

Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: FFWCC

Time of Inspection: 13:42

Date of Inspection: 05/13/2024

Serial Number: 80-000906

Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202303K Exp: 03/29/2025	0.08g/210L Test (g/210L) Lot#:202303L Exp: 03/29/2025	0.20g/210L Test (g/210L) Lot#:202304C Exp: 04/05/2025	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG222203 Exp: 08/10/2024
0.000	0.048	0.079	0.197	0.081
0.000	0.049	0.079	0.198	0.080
0.000	0.049	0.079	0.198	0.081
0.000	0.049	0.079	0.197	0.080
0.000	0.049	0.079	0.197	0.080
0.000	0.049	0.079	0.198	0.081
0.000	0.049	0.078	0.198	0.080
0.000	0.049	0.079	0.198	0.080
0.000	0.050	0.079	0.198	0.080
0.000	0.049	0.079	0.198	0.080

Standard Deviations	0.0004	0.0003	0.0004	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0003 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



TAYLOR D GUTSCHOW

Signature and Printed Name

05/13/2024

Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000906, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	80-000906	UNCERTAINTY* $\pm$
Owning Agency:	FFWCC	0.050 g/ 210 L 0.004
Calibration Date:	05/13/2024	0.080 g/ 210 L 0.004
Calibration Time:	13:42	0.200 g/ 210 L 0.007
		0.080 g/ 210 L Dry Gas Control 0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards. This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

05/13/2024

Date

Taylor D Gutschow

TAYLOR D GUTSCHOW,

Department Inspector

FDLE/ATP Form 69 December 2021

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality