



INSTRUMENT PROCESSING SHEET

Agency Fort Lauderdale PDS/N 80-006939Florida Department of
Law EnforcementDate In 09/13/2024 DI Completion Date 10/17/2024☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake By <u>TDG</u> Date <u>09/23/2024</u>		Quality Checks By <u>TDG</u> Date (See Notes)		Flow Calibration By _____ Date _____																																									
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: <u>Keyboard is missing F2 button.</u>		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>214</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP106</u> 32 mm <u>0.156</u> (.139 - .169) 36 mm <u>0.167</u> (.156 - .190) 53 mm <u>0.246</u> (.228 - .278) 103 mm <u>0.503</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>26932</u> ☒ Stability Checks		☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																									
		<table border="1" style="width:100%"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP6286</td><td>202303K 03/29/2025</td></tr><tr><td>0.080</td><td>MP6287</td><td>202303L 03/29/2025</td></tr><tr><td>0.200</td><td>MP6288</td><td>202304C 04/05/2025</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>01923080A3 02/05/2025</td></tr></tbody></table>		Simulator	Serial #	Lot #/Exp	0.050	MP6286	202303K 03/29/2025	0.080	MP6287	202303L 03/29/2025	0.200	MP6288	202304C 04/05/2025	0.080 DGS	N/A	01923080A3 02/05/2025	Maintenance By <u>TDG</u> Date <u>10/16/2024</u> ☒ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____																										
Simulator	Serial #	Lot #/Exp																																											
0.050	MP6286	202303K 03/29/2025																																											
0.080	MP6287	202303L 03/29/2025																																											
0.200	MP6288	202304C 04/05/2025																																											
0.080 DGS	N/A	01923080A3 02/05/2025																																											
Calibration Adjustment By _____				Department Inspection By <u>TDG</u>																																									
Barometric Pressure Gauge ID # _____				Barometric Pressure ID# <u>26932</u> Gauge <u>1018</u> Instrument <u>1016</u> Mouth Alcohol Solution Lot # <u>2023-A</u> Acetone Stock Solution Lot # <u>2023-B</u>																																									
<table border="1" style="width:100%"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td></td><td></td><td></td></tr><tr><td>0.100</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.300</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>				Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			<table border="1" style="width:100%"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td>MP6284</td></tr><tr><td>Interferent</td><td>MP6285</td></tr><tr><td>0.050</td><td>MP6286</td></tr><tr><td>0.080</td><td>MP6287</td></tr><tr><td>0.200</td><td>MP6288</td></tr></tbody></table>		Simulator	Serial Number	0.000	MP6284	Interferent	MP6285	0.050	MP6286	0.080	MP6287	0.200	MP6288
Simulator	Serial #	Lot #	Expiration																																										
0.000		N/A	N/A																																										
0.040																																													
0.100																																													
0.200																																													
0.300																																													
0.080 DGS	N/A																																												
Simulator	Serial Number																																												
0.000	MP6284																																												
Interferent	MP6285																																												
0.050	MP6286																																												
0.080	MP6287																																												
0.200	MP6288																																												
☐ Post Calibration Adjustment Stability Checks				Attachments ☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment																																									
<table border="1" style="width:100%"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td></td><td></td><td></td></tr><tr><td>0.080</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>				Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			☐ Post-Stability Checks ☐ Flow Calibration ☒ Form 40 ☐ Other _____																					
Simulator	Serial #	Lot #	Expiration																																										
0.050																																													
0.080																																													
0.200																																													
0.080 DGS	N/A																																												
Notes/Suggested Service: <u>Checked breath tube screen and replaced o-rings on 9/23. Verified setup on 10/16. Finished Quality Checks on 10/17. (TDG)</u>				☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use																																									
				Phil Nicodemmo Digitally signed by Phil Nicodemmo Date: 2024.10.24 07:50:36 -0400																																									
				Shayla Platt Digitally signed by Shayla Platt Date: 2024.10.30 09:49:45 -0400																																									
				Tech Review / Date _____ Admin Review / Date _____																																									

Florida Department of Law Enforcement Alcohol Testing Program

AGENCY INSPECTION REPORT - INTOXILYZER 8000

Agency: FORT LAUDERDALE PD
Time of Inspection: 11:41

Date of Inspection: 10/17/2024

Serial Number: 80-006939
Software: 8100.27

Check or Test	YES	NO
Date and/or Time Adjusted		No
Diagnostic Check (Pre-Inspection): OK		No
Alcohol Free Subject Test: 0.000		No
Mouth Alcohol Test: Slope Not Met		No
Interferent Detect Test: Interferent Detect		No
Diagnostic Check (Post-Inspection): OK		No

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#: Exp:	0.08g/210L Test (g/210L) Lot#: Exp:	0.20g/210L Test (g/210L) Lot#: Exp:	0.08 g/210L Dry Gas Std Test (g/210L) Lot#: Exp:

Number of Simulators Used: _____

Remarks:

AI NOT CONDUCTED. BYPASSED TO BRING OUT OF DISABLED MODE.

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I hold a valid Florida Department of Law Enforcement Agency Inspector Permit and that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Taylor D Gutschow

TAYLOR D GUTSCHOW

Signature and Printed Name

10/17/2024
Date

FORT LAUDERDALE PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006939
10/17/2024
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	13:29
Control Test	0.051	13:29
Air Blank	0.000	13:30
Control Test	0.050	13:30
Air Blank	0.000	13:31
Control Test	0.050	13:32
Air Blank	0.000	13:32
Control Test Stats		
Average	0.0503	
Std Dev	0.0006	
Rel Std Dev(%)	1.1471	



Operator's Signature

FORT LAUDERDALE PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006939
10/17/2024
Software: 8100.27

Wet

Test	g/210L	Time
Air Blank	0.000	13:35
Control Test	0.080	13:35
Air Blank	0.000	13:36
Control Test	0.080	13:37
Air Blank	0.000	13:37
Control Test	0.080	13:38
Air Blank	0.000	13:38
Control Test Stats		
Average	0.0800	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

ML

Operator's Signature

FORT LAUDERDALE PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006939
10/17/2024
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	13:42
Control Test	0.200	13:42
Air Blank	0.000	13:43
Control Test	0.200	13:44
Air Blank	0.000	13:44
Control Test	0.199	13:45
Air Blank	0.000	13:45
Control Test Stats		
Average	0.1997	
Std Dev	0.0006	
Rel Std Dev(%)	0.2892	

ML

Operator's Signature

FORT LAUDERDALE PD
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-006939
10/17/2024
Software: 8100.27

DLS

Test	g/210L	Time
Air Blank	0.000	11:43
Control Test	0.079	11:44
Air Blank	0.000	11:44
Control Test	0.078	11:45
Air Blank	0.000	11:45
Control Test	0.079	11:45
Air Blank	0.000	11:46
Control Test Stats		
Average	0.0787	
Std Dev	0.0006	
Rel Std Dev(%)	0.7339	

ML

Operator's Signature

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: FORT LAUDERDALE PD
Time of Inspection: 16:06

Date of Inspection: 10/17/2024

Serial Number: 80-006939
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202303K Exp: 03/29/2025	0.08g/210L Test (g/210L) Lot#:202303L Exp: 03/29/2025	0.20g/210L Test (g/210L) Lot#:202304C Exp: 04/05/2025	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:01923080A3 Exp: 02/05/2025
0.000	0.050	0.081	0.199	0.079
0.000	0.050	0.080	0.199	0.079
0.000	0.050	0.080	0.199	0.078
0.000	0.051	0.080	0.199	0.079
0.000	0.050	0.080	0.199	0.079
0.000	0.050	0.080	0.199	0.078
0.000	0.051	0.081	0.199	0.078
0.000	0.051	0.080	0.200	0.079
0.000	0.051	0.081	0.199	0.079
0.000	0.050	0.081	0.199	0.079

Standard Deviations	0.0005	0.0005	0.0003	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0004 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



TAYLOR D GUTSCHOW

Signature and Printed Name

10/17/2024
Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-006939, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-006939</u>	UNCERTAINTY* $\pm$
Owning Agency:	<u>FORT LAUDERDALE PD</u>	0.050 g/ 210 L 0.004
Calibration Date:	<u>10/17/2024</u>	0.080 g/ 210 L 0.004
Calibration Time:	<u>16:06</u>	0.200 g/ 210 L 0.007
		0.080 g/ 210 L Dry Gas Control 0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards. This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

10/17/2024

Date

TAYLOR D GUTSCHOW,
Department Inspector

FDLE/ATP Form 69 December 2021

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality