



INSTRUMENT PROCESSING SHEET

Agency Miami Dade PDS/N 80-000880Florida Department of
Law EnforcementDate In 02/21/2025 DI Completion Date 03/05/2025☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake	By TDG	Date	Quality Checks	By TDG	Date	Flow Calibration	By	Date																												
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes:		<u>02/25/2025</u>	☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>229</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP101</u> 32 mm <u>0.144</u> (.139 - .169) 36 mm <u>0.167</u> (.156 - .190) 53 mm <u>0.234</u> (.228 - .278) 103 mm <u>0.503</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>26932</u> ☒ Stability Checks		<u>03/04/2025</u>	Flow Column # _____ ☐ 5L/min - 17mm ☐ 15L/min - 53mm ☐ 30L/min - 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																														
			<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP6286</td><td>202303K 03/29/2025</td></tr><tr><td>0.080</td><td>MP6287</td><td>202303L 03/29/2025</td></tr><tr><td>0.200</td><td>MP6288</td><td>202304C 04/05/2025</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG429602 10/22/2026</td></tr></tbody></table>	Simulator	Serial #	Lot #/Exp	0.050	MP6286	202303K 03/29/2025	0.080	MP6287	202303L 03/29/2025	0.200	MP6288	202304C 04/05/2025	0.080 DGS	N/A	AG429602 10/22/2026																		
Simulator	Serial #	Lot #/Exp																																		
0.050	MP6286	202303K 03/29/2025																																		
0.080	MP6287	202303L 03/29/2025																																		
0.200	MP6288	202304C 04/05/2025																																		
0.080 DGS	N/A	AG429602 10/22/2026																																		
Calibration Adjustment			Department Inspection																																	
By _____			By <u>TDG</u>																																	
Barometric Pressure Gauge _____ ID # _____			Barometric Pressure ID# <u>26932</u>																																	
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td></td><td></td><td></td></tr><tr><td>0.100</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.300</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>			Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Gauge <u>1014</u> Instrument <u>1013</u> Mouth Alcohol Solution Lot # <u>2024-A</u> Acetone Stock Solution Lot # <u>2023-B</u>					
Simulator	Serial #	Lot #	Expiration																																	
0.000		N/A	N/A																																	
0.040																																				
0.100																																				
0.200																																				
0.300																																				
0.080 DGS	N/A																																			
☐ Post Calibration Adjustment Stability Checks			<table border="1"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td>MP6284</td></tr><tr><td>Interferent</td><td>MP6285</td></tr><tr><td>0.050</td><td>MP6286</td></tr><tr><td>0.080</td><td>MP6287</td></tr><tr><td>0.200</td><td>MP6288</td></tr></tbody></table>						Simulator	Serial Number	0.000	MP6284	Interferent	MP6285	0.050	MP6286	0.080	MP6287	0.200	MP6288																
Simulator	Serial Number																																			
0.000	MP6284																																			
Interferent	MP6285																																			
0.050	MP6286																																			
0.080	MP6287																																			
0.200	MP6288																																			
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td></td><td></td><td></td></tr><tr><td>0.080</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Attachments ☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Calibration Adjustment ☐ Post-Stability Checks ☐ Flow Calibration ☐ Form 40 ☐ Other _____													
Simulator	Serial #	Lot #	Expiration																																	
0.050																																				
0.080																																				
0.200																																				
0.080 DGS	N/A																																			
Notes/Suggested Service: _____			☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use																																	
			Phil Nicodemo Digitally signed by Phil Nicodemo Date: 2025.03.10 10:28:46 -0400																																	
			Shayla Platt Digitally signed by Shayla Platt Date: 2025.03.10 10:54:13 -0400																																	
			Tech Review / Date _____ Admin Review / Date _____																																	

Stability Checks

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L
0.047 to 0.053	0.077 to 0.083	0.194 to 0.206	0.077 to 0.083
VIEW: DQCE PD Intoxilyzer - Alcohol Analyzer Model: 8000 03/04/2025 Software: 8100.27 Test Time Air Blank 0.000 13:59 Control Test 0.049 14:00 Air Blank 0.000 14:01 Control Test 0.050 14:01 Air Blank 0.000 14:02 Control Test 0.049 14:03 Air Blank 0.000 14:03 Control Test Stats Average 0.0493 Std Dev 0.0006 Rel. Std Dev(%) 1.1703 Operator's Signature 	VIEW: DQCE PD Intoxilyzer - Alcohol Analyzer Model: 8000 03/04/2025 Software: 8100.27 Test Time Air Blank 0.000 13:53 Control Test 0.079 13:53 Air Blank 0.000 13:54 Control Test 0.079 13:54 Air Blank 0.000 13:55 Control Test 0.080 13:56 Air Blank 0.000 13:56 Control Test Stats Average 0.0793 Std Dev 0.0006 Rel. Std Dev(%) 0.7277 Operator's Signature 	VIEW: DQCE PD Intoxilyzer - Alcohol Analyzer Model: 8000 03/04/2025 Software: 8100.27 Test Time Air Blank 0.000 14:13 Control Test 0.196 14:14 Air Blank 0.000 14:15 Control Test 0.196 14:15 Air Blank 0.000 14:16 Control Test 0.197 14:16 Air Blank 0.000 14:17 Control Test Stats Average 0.1963 Std Dev 0.0006 Rel. Std Dev(%) 0.2941 Operator's Signature 	VIEW: DQCE PD Intoxilyzer - Alcohol Analyzer Model: 8000 03/04/2025 Software: 8100.27 Test Time Air Blank 0.000 13:11 Control Test 0.079 13:11 Air Blank 0.000 13:12 Control Test 0.080 13:12 Air Blank 0.000 13:13 Control Test 0.079 13:13 Air Blank 0.000 13:13 Control Test Stats Average 0.0793 Std Dev 0.0006 Rel. Std Dev(%) 0.7277 Operator's Signature 

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: MIAMI DADE PD
Time of Inspection: 11:58

Date of Inspection: 03/05/2025

Serial Number: 80-000880
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202303K Exp: 03/29/2025	0.08g/210L Test (g/210L) Lot#:202303L Exp: 03/29/2025	0.20g/210L Test (g/210L) Lot#:202304C Exp: 04/05/2025	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG429602 Exp: 10/22/2026
0.000	0.049	0.079	0.197	0.080
0.000	0.049	0.079	0.197	0.080
0.000	0.049	0.079	0.198	0.080
0.000	0.049	0.079	0.197	0.079
0.000	0.050	0.079	0.197	0.080
0.000	0.050	0.079	0.197	0.079
0.000	0.049	0.078	0.197	0.079
0.000	0.049	0.079	0.197	0.079
0.000	0.049	0.079	0.197	0.079
0.000	0.049	0.079	0.197	0.079


Standard Deviations	0.0004	0.0003	0.0003	0.0005
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0003 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



TAYLOR D GUTSCHOW

Signature and Printed Name

03/05/2025
Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000880, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	80-000880	UNCERTAINTY* $\pm$
Owning Agency:	MIAMI DADE PD	0.050 g/ 210 L 0.004
Calibration Date:	03/05/2025	0.080 g/ 210 L 0.004
Calibration Time:	11:58	0.200 g/ 210 L 0.007
		0.080 g/ 210 L Dry Gas Control 0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards. This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

FDLE/ATP Form 69 December 2021

Issuing Authority: Alcohol Testing Program

03/05/2025

Date

TAYLOR D GUTSCHOW,

Department Inspector

Service • Integrity • Respect • Quality