



INSTRUMENT PROCESSING SHEET

Agency North Miami PDS/N 80-001656Florida Department of
Law EnforcementDate In 01/23/2025 DI Completion Date 02/05/2025☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake By <u>TDG</u> Date <u>02/04/2025</u>		Quality Checks By <u>TDG</u> Date <u>02/05/2025</u>		Flow Calibration By _____ Date _____																																																													
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☐ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: _____ _____ _____ _____ _____ _____ _____ _____ _____ _____		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>212</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP101</u> 32 mm <u>0.164</u> (.139 - .169) 36 mm <u>0.179</u> (.156 - .190) 53 mm <u>0.250</u> (.228 - .278) 103 mm <u>0.519</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>26932</u> ☒ Stability Checks <table border="1" style="width:100%"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP6286</td><td>202303K 03/29/2025</td></tr><tr><td>0.080</td><td>MP6287</td><td>202303L 03/29/2025</td></tr><tr><td>0.200</td><td>MP6288</td><td>202304C 04/05/2025</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG429602 10/22/2026</td></tr></tbody></table>		Simulator	Serial #	Lot #/Exp	0.050	MP6286	202303K 03/29/2025	0.080	MP6287	202303L 03/29/2025	0.200	MP6288	202304C 04/05/2025	0.080 DGS	N/A	AG429602 10/22/2026	Flow Column # _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																																														
Simulator	Serial #	Lot #/Exp																																																															
0.050	MP6286	202303K 03/29/2025																																																															
0.080	MP6287	202303L 03/29/2025																																																															
0.200	MP6288	202304C 04/05/2025																																																															
0.080 DGS	N/A	AG429602 10/22/2026																																																															
				Maintenance By _____ Date _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Breath Tube Replacement ☐ Other _____ _____ _____ _____ _____ _____																																																													
Calibration Adjustment By _____				Department Inspection By <u>TDG</u>																																																													
Barometric Pressure Gauge ID # _____ <table border="1" style="width:100%"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td></td><td></td><td></td></tr><tr><td>0.100</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.300</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table> ☐ Post Calibration Adjustment Stability Checks <table border="1" style="width:100%"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td></td><td></td><td></td></tr><tr><td>0.080</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>				Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Barometric Pressure ID# <u>26932</u> Gauge <u>1022</u> Instrument <u>1020</u> Mouth Alcohol Solution Lot # <u>2024-A</u> Acetone Stock Solution Lot # <u>2023-B</u> <table border="1" style="width:100%"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td>MP6284</td></tr><tr><td>Interferent</td><td>MP6285</td></tr><tr><td>0.050</td><td>MP6286</td></tr><tr><td>0.080</td><td>MP6287</td></tr><tr><td>0.200</td><td>MP6288</td></tr></tbody></table>		Simulator	Serial Number	0.000	MP6284	Interferent	MP6285	0.050	MP6286	0.080	MP6287	0.200	MP6288
Simulator	Serial #	Lot #	Expiration																																																														
0.000		N/A	N/A																																																														
0.040																																																																	
0.100																																																																	
0.200																																																																	
0.300																																																																	
0.080 DGS	N/A																																																																
Simulator	Serial #	Lot #	Expiration																																																														
0.050																																																																	
0.080																																																																	
0.200																																																																	
0.080 DGS	N/A																																																																
Simulator	Serial Number																																																																
0.000	MP6284																																																																
Interferent	MP6285																																																																
0.050	MP6286																																																																
0.080	MP6287																																																																
0.200	MP6288																																																																
Notes/Suggested Service: <u>Added plastic caps (TDG 2/4/25)</u> _____ _____ _____ _____ _____ _____ _____ _____ _____				Attachments ☒ Form 41 ☐ Post-Stability Checks ☒ Stability Checks ☐ Flow Calibration ☒ Calibration Certificate ☐ Form 40 ☐ Calibration Adjustment ☐ Other _____																																																													
				☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use Destinee Armstrong Digitally signed by Destinee Armstrong Date: 2025.02.06 11:05:59 -05'00' Shayla Platt Shayla Platt Date: 2025.02.10 12:25:08 -05'00' Tech Review / Date _____ Admin Review / Date _____																																																													

Stability Checks

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L																																																																																																																																																
0.047 to 0.053	0.077 to 0.083	0.194 to 0.206	0.077 to 0.083																																																																																																																																																
✓	✓	✓	✓																																																																																																																																																
NORTH MIAMI PD Intoxilyzer - Alcotest Analyzer Model 8000 SN 80-001656 02/05/2025 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>11:07</td></tr> <tr><td>Control Test</td><td>0.049</td><td>11:08</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:08</td></tr> <tr><td>Control Test</td><td>0.049</td><td>11:09</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:10</td></tr> <tr><td>Control Test</td><td>0.049</td><td>11:10</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:11</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0490</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </tbody> </table> Operator's Signature <i>mw</i>	Test	g/210L	Time	Air Blank	0.000	11:07	Control Test	0.049	11:08	Air Blank	0.000	11:08	Control Test	0.049	11:09	Air Blank	0.000	11:10	Control Test	0.049	11:10	Air Blank	0.000	11:11	Control Test Stats			Average	0.0490		Std Dev	0.0000		Rel Std Dev(%)	0.0000		NORTH MIAMI PD Intoxilyzer - Alcotest Analyzer Model 8000 SN 80-001656 02/05/2025 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>10:53</td></tr> <tr><td>Control Test</td><td>0.078</td><td>10:54</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:54</td></tr> <tr><td>Control Test</td><td>0.079</td><td>10:55</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:55</td></tr> <tr><td>Control Test</td><td>0.079</td><td>10:56</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:57</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0787</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.7339</td><td></td></tr> </tbody> </table> Operator's Signature <i>mw</i>	Test	g/210L	Time	Air Blank	0.000	10:53	Control Test	0.078	10:54	Air Blank	0.000	10:54	Control Test	0.079	10:55	Air Blank	0.000	10:55	Control Test	0.079	10:56	Air Blank	0.000	10:57	Control Test Stats			Average	0.0787		Std Dev	0.0006		Rel Std Dev(%)	0.7339		NORTH MIAMI PD Intoxilyzer - Alcotest Analyzer Model 8000 SN 80-001656 02/05/2025 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>11:01</td></tr> <tr><td>Control Test</td><td>0.198</td><td>11:01</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:02</td></tr> <tr><td>Control Test</td><td>0.198</td><td>11:03</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:03</td></tr> <tr><td>Control Test</td><td>0.198</td><td>11:04</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:05</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.1980</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </tbody> </table> Operator's Signature <i>mw</i>	Test	g/210L	Time	Air Blank	0.000	11:01	Control Test	0.198	11:01	Air Blank	0.000	11:02	Control Test	0.198	11:03	Air Blank	0.000	11:03	Control Test	0.198	11:04	Air Blank	0.000	11:05	Control Test Stats			Average	0.1980		Std Dev	0.0000		Rel Std Dev(%)	0.0000		NORTH MIAMI PD Intoxilyzer - Alcotest Analyzer Model 8000 SN 80-001656 02/05/2025 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>10:36</td></tr> <tr><td>Control Test</td><td>0.078</td><td>10:37</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:37</td></tr> <tr><td>Control Test</td><td>0.078</td><td>10:38</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:38</td></tr> <tr><td>Control Test</td><td>0.078</td><td>10:38</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:39</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0780</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </tbody> </table> Operator's Signature <i>mw</i>	Test	g/210L	Time	Air Blank	0.000	10:36	Control Test	0.078	10:37	Air Blank	0.000	10:37	Control Test	0.078	10:38	Air Blank	0.000	10:38	Control Test	0.078	10:38	Air Blank	0.000	10:39	Control Test Stats			Average	0.0780		Std Dev	0.0000		Rel Std Dev(%)	0.0000	
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	11:07																																																																																																																																																	
Control Test	0.049	11:08																																																																																																																																																	
Air Blank	0.000	11:08																																																																																																																																																	
Control Test	0.049	11:09																																																																																																																																																	
Air Blank	0.000	11:10																																																																																																																																																	
Control Test	0.049	11:10																																																																																																																																																	
Air Blank	0.000	11:11																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0490																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	10:53																																																																																																																																																	
Control Test	0.078	10:54																																																																																																																																																	
Air Blank	0.000	10:54																																																																																																																																																	
Control Test	0.079	10:55																																																																																																																																																	
Air Blank	0.000	10:55																																																																																																																																																	
Control Test	0.079	10:56																																																																																																																																																	
Air Blank	0.000	10:57																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0787																																																																																																																																																		
Std Dev	0.0006																																																																																																																																																		
Rel Std Dev(%)	0.7339																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	11:01																																																																																																																																																	
Control Test	0.198	11:01																																																																																																																																																	
Air Blank	0.000	11:02																																																																																																																																																	
Control Test	0.198	11:03																																																																																																																																																	
Air Blank	0.000	11:03																																																																																																																																																	
Control Test	0.198	11:04																																																																																																																																																	
Air Blank	0.000	11:05																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.1980																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	10:36																																																																																																																																																	
Control Test	0.078	10:37																																																																																																																																																	
Air Blank	0.000	10:37																																																																																																																																																	
Control Test	0.078	10:38																																																																																																																																																	
Air Blank	0.000	10:38																																																																																																																																																	
Control Test	0.078	10:38																																																																																																																																																	
Air Blank	0.000	10:39																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0780																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: NORTH MIAMI PD
Time of Inspection: 13:50

Date of Inspection: 02/05/2025

Serial Number: 80-001656
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202303K Exp: 03/29/2025	0.08g/210L Test (g/210L) Lot#:202303L Exp: 03/29/2025	0.20g/210L Test (g/210L) Lot#:202304C Exp: 04/05/2025	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG429602 Exp: 10/22/2026
0.000	0.050	0.080	0.199	0.078
0.000	0.050	0.080	0.199	0.078
0.000	0.050	0.079	0.198	0.078
0.000	0.050	0.080	0.199	0.078
0.000	0.050	0.080	0.199	0.078
0.000	0.050	0.080	0.199	0.078
0.000	0.050	0.080	0.198	0.078
0.000	0.050	0.080	0.198	0.078
0.000	0.050	0.080	0.199	0.079
0.000	0.050	0.080	0.199	0.078


Standard Deviations	0.0000	0.0003	0.0004	0.0003
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0002 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.


 TAYLOR D GUTSCHOW
 Signature and Printed Name

02/05/2025
 Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-001656, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-001656</u>	UNCERTAINTY* $\pm$
Owning Agency:	<u>NORTH MIAMI PD</u>	0.050 g/ 210 L 0.004
Calibration Date:	<u>02/05/2025</u>	0.080 g/ 210 L 0.004
Calibration Time:	<u>13:50</u>	0.200 g/ 210 L 0.007
		0.080 g/ 210 L Dry Gas Control 0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.
This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

02/05/2025

Date

TAYLOR D GUTSCHOW,

Department Inspector

FDLE/ATP Form 69 December 2021

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality