



INSTRUMENT PROCESSING SHEET

Agency Florida Fish and Wildlife Conservation Commission S/N 80-007494

Florida Department of
Law Enforcement

Date In 04/17/2025 DI Completion Date 05/07/2025 ☐ Ship ☒ P/U ☐ H/D ☐ CMI ☐ EE

Intake	By	TDG	Date	05/05/2025	Quality Checks	By	TDG	Date	05/06/2025	Flow Calibration	By	Date																													
☒ Annual ☐ Registration ☐ Return from CMI / EE Visual Inspection: ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/ Accessories: ☒ Power cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: <u>DGS and analog line. AI</u> <u>dropped off in pelican case.</u>					☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value <u>188</u> ☒ Flow Verification (L/s) Flow Column # <u>ATP106</u> 32 mm <u>0.140</u> (.139 - .169) 36 mm <u>0.160</u> (.156 - .190) 53 mm <u>0.234</u> (.228 - .278) 103 mm <u>0.496</u> (.447 - .547) ☒ Barometric Pressure Check Gauge ID # <u>28199</u> ☒ Stability Checks					Flow Column # _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value _____ ☐ Post Calibration Verification (L/s) Flow Column # _____ 32 mm _____ (.139 - .169) 36 mm _____ (.156 - .190) 53 mm _____ (.228 - .278) 103 mm _____ (.447 - .547)																															
					<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP6286</td><td>202406K 06/19/2026</td></tr><tr><td>0.080</td><td>MP6287</td><td>202406L 06/19/2026</td></tr><tr><td>0.200</td><td>MP6288</td><td>202406N 06/20/2026</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG429602 10/22/2026</td></tr></tbody></table>			Simulator	Serial #	Lot #/Exp	0.050	MP6286	202406K 06/19/2026	0.080	MP6287	202406L 06/19/2026	0.200	MP6288	202406N 06/20/2026	0.080 DGS	N/A	AG429602 10/22/2026	<table border="1"><thead><tr><th colspan="2">Maintenance By _____ Date _____</th></tr><tr><td>☐ Battery Replacement</td><td></td></tr><tr><td>☐ Dry Gas Regulator Replacement</td><td></td></tr><tr><td>☐ Breath Tube Replacement</td><td></td></tr><tr><td>☐ Other _____</td><td></td></tr></thead></table>				Maintenance By _____ Date _____		☐ Battery Replacement		☐ Dry Gas Regulator Replacement		☐ Breath Tube Replacement		☐ Other _____						
Simulator	Serial #	Lot #/Exp																																							
0.050	MP6286	202406K 06/19/2026																																							
0.080	MP6287	202406L 06/19/2026																																							
0.200	MP6288	202406N 06/20/2026																																							
0.080 DGS	N/A	AG429602 10/22/2026																																							
Maintenance By _____ Date _____																																									
☐ Battery Replacement																																									
☐ Dry Gas Regulator Replacement																																									
☐ Breath Tube Replacement																																									
☐ Other _____																																									
Calibration Adjustment By _____					Department Inspection By <u>TDG</u>																																				
Barometric Pressure Gauge _____ ID # _____					Barometric Pressure ID# <u>28199</u>																																				
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td></td><td></td><td></td></tr><tr><td>0.100</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.300</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>					Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Gauge <u>1017</u> Instrument <u>1015</u> Mouth Alcohol Solution Lot # <u>2024-A</u> Acetone Stock Solution Lot # <u>2023-B</u>								
Simulator	Serial #	Lot #	Expiration																																						
0.000		N/A	N/A																																						
0.040																																									
0.100																																									
0.200																																									
0.300																																									
0.080 DGS	N/A																																								
☐ Post Calibration Adjustment Stability Checks					<table border="1"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td>MP6284</td></tr><tr><td>Interferent</td><td>MP6285</td></tr><tr><td>0.050</td><td>MP6286</td></tr><tr><td>0.080</td><td>MP6287</td></tr><tr><td>0.200</td><td>MP6288</td></tr></tbody></table>							Simulator	Serial Number	0.000	MP6284	Interferent	MP6285	0.050	MP6286	0.080	MP6287	0.200	MP6288																		
Simulator	Serial Number																																								
0.000	MP6284																																								
Interferent	MP6285																																								
0.050	MP6286																																								
0.080	MP6287																																								
0.200	MP6288																																								
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td></td><td></td><td></td></tr><tr><td>0.080</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>					Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			<table border="1"><thead><tr><th colspan="2">Attachments</th></tr><tr><td>☒ Form 41</td><td>☐ Post-Stability Checks</td></tr><tr><td>☒ Stability Checks</td><td>☐ Flow Calibration</td></tr><tr><td>☒ Calibration Certificate</td><td>☐ Form 40</td></tr><tr><td>☐ Calibration Adjustment</td><td>☐ Other _____</td></tr></thead></table>							Attachments		☒ Form 41	☐ Post-Stability Checks	☒ Stability Checks	☐ Flow Calibration	☒ Calibration Certificate	☐ Form 40	☐ Calibration Adjustment	☐ Other _____
Simulator	Serial #	Lot #	Expiration																																						
0.050																																									
0.080																																									
0.200																																									
0.080 DGS	N/A																																								
Attachments																																									
☒ Form 41	☐ Post-Stability Checks																																								
☒ Stability Checks	☐ Flow Calibration																																								
☒ Calibration Certificate	☐ Form 40																																								
☐ Calibration Adjustment	☐ Other _____																																								
Notes/Suggested Service: _____					☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use																																				
					<table border="1"><tr><td>Phil Nicodemus Digitally signed by Phil Nicodemus Date: 2025.05.19 14:01:20 -04'00'</td><td>Shayla Platt Digitally signed by Shayla Platt Date: 2025.05.19 14:41:38 -04'00'</td></tr></table>							Phil Nicodemus Digitally signed by Phil Nicodemus Date: 2025.05.19 14:01:20 -04'00'	Shayla Platt Digitally signed by Shayla Platt Date: 2025.05.19 14:41:38 -04'00'																												
Phil Nicodemus Digitally signed by Phil Nicodemus Date: 2025.05.19 14:01:20 -04'00'	Shayla Platt Digitally signed by Shayla Platt Date: 2025.05.19 14:41:38 -04'00'																																								
					Tech Review / Date _____ Admin Review / Date _____																																				

Stability Checks

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L
0.047 to 0.053 FFWCC Intoxilyzer - Alcohol Analyzer Model 8000 05/06/2025 Software: 8100.27 SN 80-007494 Test g/210L Time Air Blank 0.000 14:19 Control Test 0.048 14:20 Air Blank 0.000 14:21 Control Test 0.049 14:21 Air Blank 0.000 14:22 Control Test 0.048 14:23 Air Blank 0.000 14:23 Control Test Stats Average 0.0483 Std Dev 0.0006 Rel Std Dev(%) 1.1945 Operator's Signature 	0.077 to 0.083 FFWCC Intoxilyzer - Alcohol Analyzer Model 8000 05/06/2025 Software: 8100.27 SN 80-007494 Test g/210L Time Air Blank 0.000 14:01 Control Test 0.079 14:02 Air Blank 0.000 14:02 Control Test 0.079 14:03 Air Blank 0.000 14:04 Control Test 0.079 14:04 Air Blank 0.000 14:05 Control Test Stats Average 0.0790 Std Dev 0.0000 Rel Std Dev(%) 0.0000 Operator's Signature 	0.194 to 0.206 FFWCC Intoxilyzer - Alcohol Analyzer Model 8000 05/06/2025 Software: 8100.27 SN 80-007494 Test g/210L Time Air Blank 0.000 14:10 Control Test 0.197 14:11 Air Blank 0.000 14:11 Control Test 0.197 14:12 Air Blank 0.000 14:13 Control Test 0.196 14:13 Air Blank 0.000 14:14 Control Test Stats Average 0.1967 Std Dev 0.0006 Rel Std Dev(%) 0.2536 Operator's Signature 	0.077 to 0.083 FFWCC Intoxilyzer - Alcohol Analyzer Model 8000 05/06/2025 Software: 8100.27 SN 80-007494 Test g/210L Time Air Blank 0.000 13:34 Control Test 0.079 13:34 Air Blank 0.000 13:34 Control Test 0.079 13:35 Air Blank 0.000 13:35 Control Test 0.079 13:36 Air Blank 0.000 13:36 Control Test Stats Average 0.0790 Std Dev 0.0000 Rel Std Dev(%) 0.0000 Operator's Signature 

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: FFWCC

Time of Inspection: 13:03

Date of Inspection: 05/07/2025

Serial Number: 80-007494

Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202406K Exp: 06/19/2026	0.08g/210L Test (g/210L) Lot#:202406L Exp: 06/19/2026	0.20g/210L Test (g/210L) Lot#:202406N Exp: 06/20/2026	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG429602 Exp: 10/22/2026
0.000	0.049	0.079	0.197	0.078
0.000	0.049	0.079	0.197	0.079
0.000	0.049	0.079	0.197	0.078
0.000	0.049	0.079	0.196	0.079
0.000	0.049	0.079	0.197	0.079
0.000	0.049	0.079	0.197	0.079
0.000	0.049	0.079	0.197	0.079
0.000	0.049	0.079	0.197	0.079
0.000	0.049	0.079	0.197	0.079
0.000	0.049	0.079	0.197	0.079

Standard Deviations	0.0000	0.0000	0.0003	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0001 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

Taylor D Gutschow

TAYLOR D GUTSCHOW

Signature and Printed Name

05/07/2025
Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-007494 , manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-007494</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>FFWCC</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>05/07/2025</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>13:03</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.
*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.
This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Taylor
Gutschow
Digitally signed by Taylor Gutschow
Date: 2025.05.08 11:50:35 -04'00'

05/07/2025

Date

TAYLOR D GUTSCHOW,
Department Inspector

FDLE/ATP Form 69 December 2021

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality