

Alcohol Testing Program - Instrument Processing Sheet

Agency: Patrick AFB

Instrument Serial Number: 80-005146

Date In: 4/28/2026

DI Completion Date: N/A

☐ Ship ☐ P/U ☐ H/D ☒ CMI ☐ EE

Intake By: <u>IAS</u> Date: <u>4/28/2026</u>		Quality Checks By: <u>SLH</u> Date: <u>04/30/2026</u>		Flow Adjustment By: _____																											
☒ Annual ☐ Dropped Off ☐ Registration ☐ Return from CMI / EE ☐ Training Instrument Visual Inspection ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/Accessories ☒ Power Cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes: Mesh covering speaker is missing. IAS 4/28/26		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value: <u>91</u> ☒ Flow Verification (L/s) Flow Column #: <u>ATP 103</u> 32 mm <u>0.085</u> (.139-.169) 36 mm <u>0.101</u> (.156-.190) 53 mm <u>0.167</u> (.228-.278) 103 mm <u>0.468</u> (.447-.547) ☒ Barometric Pressure Check Gauge ID #: <u>28427</u> Gauge: <u>1007</u> Instrument: <u>995</u> ☒ Stability Checks		Flow Column #: _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value: _____ ☐ Post Adjustment Verification (L/S) Flow Column #: _____ 32 mm _____ (.139-.169) 36 mm _____ (.156-.190) 53 mm _____ (.228-.278) 103 mm _____ (.447-.547)																											
		<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot#/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP6291</td><td>202406K 06/19/2026</td></tr><tr><td>0.080</td><td>MP6292</td><td>202603B 03/03/2028</td></tr><tr><td>0.200</td><td>MP6293</td><td>202406N 06/20/2026</td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>AG510701 04/17/2027</td></tr></tbody></table>		Simulator	Serial #	Lot#/Exp	0.050	MP6291	202406K 06/19/2026	0.080	MP6292	202603B 03/03/2028	0.200	MP6293	202406N 06/20/2026	0.080 DGS	N/A	AG510701 04/17/2027	Maintenance By: _____ Date: _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Tank Sensor Tare ☐ Breath Tube Replacement ☐ Other:												
Simulator	Serial #	Lot#/Exp																													
0.050	MP6291	202406K 06/19/2026																													
0.080	MP6292	202603B 03/03/2028																													
0.200	MP6293	202406N 06/20/2026																													
0.080 DGS	N/A	AG510701 04/17/2027																													
Optical Bench Adjustment By: _____		Department Inspection By: _____																													
Barometric Pressure Gauge: _____ ID#: _____		Barometric Pressure ID#: _____																													
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td></td><td></td><td></td></tr><tr><td>0.100</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.300</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Gauge: _____ Instrument: _____ Mouth Alcohol Solution Lot #: _____ Exp: _____ Acetone Stock Solution Lot #: _____ Exp: _____	
Simulator	Serial #	Lot #	Expiration																												
0.000		N/A	N/A																												
0.040																															
0.100																															
0.200																															
0.300																															
0.080 DGS	N/A																														
☐ Post Optical Bench Adjustment Stability Checks		<table border="1"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td></td></tr><tr><td>Interferent</td><td></td></tr><tr><td>0.050</td><td></td></tr><tr><td>0.080</td><td></td></tr><tr><td>0.200</td><td></td></tr></tbody></table>		Simulator	Serial Number	0.000		Interferent		0.050		0.080		0.200																	
Simulator	Serial Number																														
0.000																															
Interferent																															
0.050																															
0.080																															
0.200																															
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td></td><td></td><td></td></tr><tr><td>0.080</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Attachments ☐ Form 41 ☒ Stability Checks ☐ Calibration Certificate ☐ Optical Bench Adjustment									
Simulator	Serial #	Lot #	Expiration																												
0.050																															
0.080																															
0.200																															
0.080 DGS	N/A																														
Gauge ID #: _____ Gauge: _____ Instrument: _____		☐ Post-Stability Checks ☐ Flow Adjustment ☒ Form 40 ☒ Other: RMA= Return Material Authorization																													
Notes/Suggested Service: During Quality Checks, the flow sensor needs to be evaluated, and flow, barometric pressure and stability checks were outside of acceptable criteria. The instrument will be sent for repair to address the flow sensor and upon return I will perform any required servicing prior to the Department Inspection. SLH 5/1/2026		☐ Instrument Complies with Chapter 11D-8, FAC ☒ Instrument Does Not Comply with Chapter 11D-8, FAC ☐ Return to/Place into Evidentiary Use ☒ Remain Out of Evidentiary Use ☐ Conduct an Agency Inspection Before Evidentiary Use																													
		Taylor Gutschow Digitally signed by Taylor Gutschow Date: 2026.05.09 17:48:55 -04'00'																													
		Kaitlyn Spearin Digitally signed by Kaitlyn Spearin Date: 2026.05.18 12:07:44 -04'00'																													
		Tech Review Admin Review																													

Florida Department of Law Enforcement Alcohol Testing Program

AGENCY INSPECTION REPORT - INTOXILYZER 8000

Agency: PATRICK AFB

Time of Inspection: 12:07

Date of Inspection: 04/30/2026

Serial Number: 80-005146

Software: 8100.27

Check or Test	YES	NO
Date and/or Time Adjusted		No
Diagnostic Check (Pre-Inspection): OK		No
Alcohol Free Subject Test: 0.000		No
Mouth Alcohol Test: Slope Not Met		No
Interferent Detect Test: Interferent Detect		No
Diagnostic Check (Post-Inspection): OK		No

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#: Exp:	0.08g/210L Test (g/210L) Lot#: Exp:	0.20g/210L Test (g/210L) Lot#: Exp:	0.08 g/210L Dry Gas Std Test (g/210L) Lot#: Exp:


Number of Simulators Used: _____

Remarks:

BYPASS AI, COMPLIANCE UNDETERMINED

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I hold a valid Florida Department of Law Enforcement Agency Inspector Permit and that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



Signature and Printed Name

LEANDRA HIGGINBOTHAM

04/30/2026

Date

#1

PATRICK AFB
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-005146
04/30/2026
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	12:33
Control Test	0.076 —	12:33
Air Blank	0.000	12:34
Control Test	0.078	12:34
Air Blank	0.000	12:35
Control Test	0.077	12:36
Air Blank	0.000	12:36
Control Test Stats		
Average	0.0770	
Std Dev	0.0010	
Rel Std Dev(%)	1.2987	

SIM lid was able to be
tightened — reran
Sut


Operator's Signature

perform
optical bench
adjustment. sub

Stability Checks

80-005146 sub
4/30/2026

0.050 g/210L	0.080 g/210L	0.200 g/210L	DGS 0.080 g/210L																																																																																																																																																
0.047 to 0.053 g/210L ☒	0.077 to 0.083 g/210L ☒	0.194 to 0.206 g/210L ☒	0.077 to 0.083 g/210L ☒ ±0.003 g/210L of Wet ☒																																																																																																																																																
PATRICK AFB Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-005146 04/30/2026 Software: 8100.27 <table><thead><tr><th>Test</th><th>g/210L</th><th>Time</th></tr></thead><tbody><tr><td>Air Blank</td><td>0.000</td><td>12:16</td></tr><tr><td>Control Test</td><td>0.040</td><td>12:17</td></tr><tr><td>Air Blank</td><td>0.000</td><td>12:18</td></tr><tr><td>Control Test</td><td>0.048</td><td>12:18</td></tr><tr><td>Air Blank</td><td>0.000</td><td>12:19</td></tr><tr><td>Control Test</td><td>0.048</td><td>12:20</td></tr><tr><td>Air Blank</td><td>0.000</td><td>12:20</td></tr><tr><td colspan="3">Control Test Stats</td></tr><tr><td>Average</td><td>0.0480</td><td></td></tr><tr><td>Std Dev</td><td>0.0000</td><td></td></tr><tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr></tbody></table> Operator's Signature <i>[Signature]</i>	Test	g/210L	Time	Air Blank	0.000	12:16	Control Test	0.040	12:17	Air Blank	0.000	12:18	Control Test	0.048	12:18	Air Blank	0.000	12:19	Control Test	0.048	12:20	Air Blank	0.000	12:20	Control Test Stats			Average	0.0480		Std Dev	0.0000		Rel Std Dev(%)	0.0000		#2 PATRICK AFB Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-005146 04/30/2026 Software: 8100.27 <table><thead><tr><th>Test</th><th>g/210L</th><th>Time</th></tr></thead><tbody><tr><td>Air Blank</td><td>0.000</td><td>12:47</td></tr><tr><td>Control Test</td><td>0.077</td><td>12:48</td></tr><tr><td>Air Blank</td><td>0.000</td><td>12:48</td></tr><tr><td>Control Test</td><td>0.078</td><td>12:49</td></tr><tr><td>Air Blank</td><td>0.000</td><td>12:50</td></tr><tr><td>Control Test</td><td>0.078</td><td>12:50</td></tr><tr><td>Air Blank</td><td>0.000</td><td>12:51</td></tr><tr><td colspan="3">Control Test Stats</td></tr><tr><td>Average</td><td>0.0777</td><td></td></tr><tr><td>Std Dev</td><td>0.0006</td><td></td></tr><tr><td>Rel Std Dev(%)</td><td>0.7434</td><td></td></tr></tbody></table> Operator's Signature <i>[Signature]</i>	Test	g/210L	Time	Air Blank	0.000	12:47	Control Test	0.077	12:48	Air Blank	0.000	12:48	Control Test	0.078	12:49	Air Blank	0.000	12:50	Control Test	0.078	12:50	Air Blank	0.000	12:51	Control Test Stats			Average	0.0777		Std Dev	0.0006		Rel Std Dev(%)	0.7434		PATRICK AFB Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-005146 04/30/2026 Software: 8100.27 <table><thead><tr><th>Test</th><th>g/210L</th><th>Time</th></tr></thead><tbody><tr><td>Air Blank</td><td>0.000</td><td>13:08</td></tr><tr><td>Control Test</td><td>0.198</td><td>13:08</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:09</td></tr><tr><td>Control Test</td><td>0.198</td><td>13:09</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:10</td></tr><tr><td>Control Test</td><td>0.199</td><td>13:11</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:11</td></tr><tr><td colspan="3">Control Test Stats</td></tr><tr><td>Average</td><td>0.1983</td><td></td></tr><tr><td>Std Dev</td><td>0.0006</td><td></td></tr><tr><td>Rel Std Dev(%)</td><td>0.2911</td><td></td></tr></tbody></table> Operator's Signature <i>[Signature]</i>	Test	g/210L	Time	Air Blank	0.000	13:08	Control Test	0.198	13:08	Air Blank	0.000	13:09	Control Test	0.198	13:09	Air Blank	0.000	13:10	Control Test	0.199	13:11	Air Blank	0.000	13:11	Control Test Stats			Average	0.1983		Std Dev	0.0006		Rel Std Dev(%)	0.2911		DGS PATRICK AFB Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-005146 04/30/2026 Software: 8100.27 <table><thead><tr><th>Test</th><th>g/210L</th><th>Time</th></tr></thead><tbody><tr><td>Air Blank</td><td>0.000</td><td>12:59</td></tr><tr><td>Control Test</td><td>0.082</td><td>13:00</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:00</td></tr><tr><td>Control Test</td><td>0.081</td><td>13:00</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:01</td></tr><tr><td>Control Test</td><td>0.082</td><td>13:01</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:02</td></tr><tr><td colspan="3">Control Test Stats</td></tr><tr><td>Average</td><td>0.0817</td><td></td></tr><tr><td>Std Dev</td><td>0.0006</td><td></td></tr><tr><td>Rel Std Dev(%)</td><td>0.7070</td><td></td></tr></tbody></table> Operator's Signature <i>[Signature]</i>	Test	g/210L	Time	Air Blank	0.000	12:59	Control Test	0.082	13:00	Air Blank	0.000	13:00	Control Test	0.081	13:00	Air Blank	0.000	13:01	Control Test	0.082	13:01	Air Blank	0.000	13:02	Control Test Stats			Average	0.0817		Std Dev	0.0006		Rel Std Dev(%)	0.7070	
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	12:16																																																																																																																																																	
Control Test	0.040	12:17																																																																																																																																																	
Air Blank	0.000	12:18																																																																																																																																																	
Control Test	0.048	12:18																																																																																																																																																	
Air Blank	0.000	12:19																																																																																																																																																	
Control Test	0.048	12:20																																																																																																																																																	
Air Blank	0.000	12:20																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0480																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	12:47																																																																																																																																																	
Control Test	0.077	12:48																																																																																																																																																	
Air Blank	0.000	12:48																																																																																																																																																	
Control Test	0.078	12:49																																																																																																																																																	
Air Blank	0.000	12:50																																																																																																																																																	
Control Test	0.078	12:50																																																																																																																																																	
Air Blank	0.000	12:51																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0777																																																																																																																																																		
Std Dev	0.0006																																																																																																																																																		
Rel Std Dev(%)	0.7434																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	13:08																																																																																																																																																	
Control Test	0.198	13:08																																																																																																																																																	
Air Blank	0.000	13:09																																																																																																																																																	
Control Test	0.198	13:09																																																																																																																																																	
Air Blank	0.000	13:10																																																																																																																																																	
Control Test	0.199	13:11																																																																																																																																																	
Air Blank	0.000	13:11																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.1983																																																																																																																																																		
Std Dev	0.0006																																																																																																																																																		
Rel Std Dev(%)	0.2911																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	12:59																																																																																																																																																	
Control Test	0.082	13:00																																																																																																																																																	
Air Blank	0.000	13:00																																																																																																																																																	
Control Test	0.081	13:00																																																																																																																																																	
Air Blank	0.000	13:01																																																																																																																																																	
Control Test	0.082	13:01																																																																																																																																																	
Air Blank	0.000	13:02																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0817																																																																																																																																																		
Std Dev	0.0006																																																																																																																																																		
Rel Std Dev(%)	0.7070																																																																																																																																																		

Return Material Authorization

Ship to:☒ CMI, Inc.☐ Enforcement ElectronicsShipment to repair facility authorized by: Zarius James on 5/1/2026Items Returned: ☒ Instrument ☐ Supplies ☐ Other Describe: _____Instrument Model: Intoxilyzer 8000 Serial Number: 80-005146

Bill To Address:

Patric AFB
Cocoa Beach, FL

Ship to Address:

FDLE Offsite Mail Facility
c/o FDLE HQ
813 B Lake Bradford Rd
Tallahassee, FL 32304

Reason for Return:

Flow sensor reading below 100 and flow rates were outside acceptable criteria.

I require an estimate **BEFORE** any repairs will be authorized and/or conductedPlease contact: Zarius James Phone #: 321-494-5587Email: Zarius.james@spaceforce.milATP Contact Name: LeAndra Higginbotham ATP Email: leandrahigginbotham@fdle.state.fl.us