

Flow Calibration Adjustment(s)

Performed by TDG

HILLSBOROUGH CSO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-007163
08/25/2025
Software: 8100.27

Flow Rate Calibration*****

1: Rate (Liters/min) = 5
SQRT(Diff) = 6.855
2: Rate (Liters/min) = 15
SQRT(Diff) = 11.660
3: Rate (Liters/min) = 30
SQRT(Diff) = 20.297
Dependent Data Scale Factor = 100000 L/min
Independent Data Scale Factor = 256
Rounded Slope = 721
Rounded Intercept = -720665
Correlation = 0.99884

Stability Checks

0.05g/210L	0.08g/210L	0.20g/210L	DGS 0.08g/210L																																																																																																																																																
0.047 to 0.053 ✓	0.077 to 0.083 ✓	0.194 to 0.206 ✓	0.077 to 0.083 ✓ ≤0.003 of Wet ✓																																																																																																																																																
<p>HILLSBOROUGH CSO Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-007163 08/25/2025 Software: 8100.27</p> <table style="width:100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align:left;">Test</th> <th style="text-align:left;">g/210L</th> <th style="text-align:left;">Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>15:30</td></tr> <tr><td>Control Test</td><td>0.048</td><td>15:30</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>15:31</td></tr> <tr><td>Control Test</td><td>0.048</td><td>15:31</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>15:32</td></tr> <tr><td>Control Test</td><td>0.048</td><td>15:33</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>15:33</td></tr> <tr><td colspan="3">Control Test Stats</td></tr> <tr><td>Average</td><td>0.0480</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </tbody> </table> <p style="text-align:center;">----- Operator's Signature <i>ML</i></p>	Test	g/210L	Time	Air Blank	0.000	15:30	Control Test	0.048	15:30	Air Blank	0.000	15:31	Control Test	0.048	15:31	Air Blank	0.000	15:32	Control Test	0.048	15:33	Air Blank	0.000	15:33	Control Test Stats			Average	0.0480		Std Dev	0.0000		Rel Std Dev(%)	0.0000		<p>HILLSBOROUGH CSO Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-007163 08/25/2025 Software: 8100.27</p> <table style="width:100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align:left;">Test</th> <th style="text-align:left;">g/210L</th> <th style="text-align:left;">Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>15:16</td></tr> <tr><td>Control Test</td><td>0.079</td><td>15:16</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>15:17</td></tr> <tr><td>Control Test</td><td>0.079</td><td>15:17</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>15:18</td></tr> <tr><td>Control Test</td><td>0.079</td><td>15:19</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>15:19</td></tr> <tr><td colspan="3">Control Test Stats</td></tr> <tr><td>Average</td><td>0.0790</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </tbody> </table> <p style="text-align:center;">----- Operator's Signature <i>ML</i></p>	Test	g/210L	Time	Air Blank	0.000	15:16	Control Test	0.079	15:16	Air Blank	0.000	15:17	Control Test	0.079	15:17	Air Blank	0.000	15:18	Control Test	0.079	15:19	Air Blank	0.000	15:19	Control Test Stats			Average	0.0790		Std Dev	0.0000		Rel Std Dev(%)	0.0000		<p>HILLSBOROUGH CSO Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-007163 08/25/2025 Software: 8100.27</p> <table style="width:100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align:left;">Test</th> <th style="text-align:left;">g/210L</th> <th style="text-align:left;">Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>15:23</td></tr> <tr><td>Control Test</td><td>0.196</td><td>15:23</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>15:24</td></tr> <tr><td>Control Test</td><td>0.195</td><td>15:24</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>15:25</td></tr> <tr><td>Control Test</td><td>0.196</td><td>15:26</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>15:26</td></tr> <tr><td colspan="3">Control Test Stats</td></tr> <tr><td>Average</td><td>0.1957</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.2951</td><td></td></tr> </tbody> </table> <p style="text-align:center;">----- Operator's Signature <i>ML</i></p>	Test	g/210L	Time	Air Blank	0.000	15:23	Control Test	0.196	15:23	Air Blank	0.000	15:24	Control Test	0.195	15:24	Air Blank	0.000	15:25	Control Test	0.196	15:26	Air Blank	0.000	15:26	Control Test Stats			Average	0.1957		Std Dev	0.0006		Rel Std Dev(%)	0.2951		<p>HILLSBOROUGH CSO Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-007163 08/25/2025 Software: 8100.27</p> <table style="width:100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align:left;">Test</th> <th style="text-align:left;">g/210L</th> <th style="text-align:left;">Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>15:35</td></tr> <tr><td>Control Test</td><td>0.077</td><td>15:36</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>15:36</td></tr> <tr><td>Control Test</td><td>0.077</td><td>15:36</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>15:37</td></tr> <tr><td>Control Test</td><td>0.077</td><td>15:37</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>15:38</td></tr> <tr><td colspan="3">Control Test Stats</td></tr> <tr><td>Average</td><td>0.0770</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </tbody> </table> <p style="text-align:center;">----- Operator's Signature <i>ML</i></p>	Test	g/210L	Time	Air Blank	0.000	15:35	Control Test	0.077	15:36	Air Blank	0.000	15:36	Control Test	0.077	15:36	Air Blank	0.000	15:37	Control Test	0.077	15:37	Air Blank	0.000	15:38	Control Test Stats			Average	0.0770		Std Dev	0.0000		Rel Std Dev(%)	0.0000	
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	15:30																																																																																																																																																	
Control Test	0.048	15:30																																																																																																																																																	
Air Blank	0.000	15:31																																																																																																																																																	
Control Test	0.048	15:31																																																																																																																																																	
Air Blank	0.000	15:32																																																																																																																																																	
Control Test	0.048	15:33																																																																																																																																																	
Air Blank	0.000	15:33																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0480																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	15:16																																																																																																																																																	
Control Test	0.079	15:16																																																																																																																																																	
Air Blank	0.000	15:17																																																																																																																																																	
Control Test	0.079	15:17																																																																																																																																																	
Air Blank	0.000	15:18																																																																																																																																																	
Control Test	0.079	15:19																																																																																																																																																	
Air Blank	0.000	15:19																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0790																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	15:23																																																																																																																																																	
Control Test	0.196	15:23																																																																																																																																																	
Air Blank	0.000	15:24																																																																																																																																																	
Control Test	0.195	15:24																																																																																																																																																	
Air Blank	0.000	15:25																																																																																																																																																	
Control Test	0.196	15:26																																																																																																																																																	
Air Blank	0.000	15:26																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.1957																																																																																																																																																		
Std Dev	0.0006																																																																																																																																																		
Rel Std Dev(%)	0.2951																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	15:35																																																																																																																																																	
Control Test	0.077	15:36																																																																																																																																																	
Air Blank	0.000	15:36																																																																																																																																																	
Control Test	0.077	15:36																																																																																																																																																	
Air Blank	0.000	15:37																																																																																																																																																	
Control Test	0.077	15:37																																																																																																																																																	
Air Blank	0.000	15:38																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0770																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: HILLSBOROUGH CSO
Time of Inspection: 12:34

Date of Inspection: 08/26/2025

Serial Number: 80-007163
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202406K Exp: 06/19/2026	0.08g/210L Test (g/210L) Lot#:202406L Exp: 06/19/2026	0.20g/210L Test (g/210L) Lot#:202406N Exp: 06/20/2026	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:AG429602 Exp: 10/22/2026
0.000	0.048	0.078	0.196	0.077
0.000	0.048	0.077	0.197	0.077
0.000	0.048	0.077	0.197	0.077
0.000	0.048	0.077	0.196	0.077
0.000	0.048	0.077	0.196	0.077
0.000	0.048	0.078	0.197	0.077
0.000	0.048	0.077	0.196	0.077
0.000	0.048	0.077	0.197	0.077
0.000	0.048	0.077	0.197	0.077
0.000	0.048	0.077	0.197	0.077
0.000	0.048	0.078	0.196	0.077

Standard Deviations	0.0000	0.0004	0.0005	0.0000
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0002 Number of Simulators Used: 5

Remarks:

The above instrument complies () does not comply () with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



TAYLOR D GUTSCHOW

Signature and Printed Name

08/26/2025
Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
4700 Terminal Drive, Suite 1
Ft. Myers, FL 33907

This is to certify the calibration of Intoxilyzer 8000 serial number 80-007163 , manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-007163</u>	UNCERTAINTY* ±	
Owning Agency:	<u>HILLSBOROUGH CSO</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>08/26/2025</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>12:34</u>	0.200 g/ 210 L	0.007
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence (k=3).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

08/26/2025

Date

Taylor
Gutschow

TAYLOR D GUTSCHOW,
Department Inspector

Digitally signed by Taylor
Gutschow
Date: 2025.08.26 14:58:18
-04'00'