

Alcohol Testing Program - Instrument Processing Sheet

Agency: BLOUNTSTOWN PD

Instrument Serial Number: 80-000862

Date In: 4/28/2026

DI Completion Date: 5/5/2026

* ☒ Ship * ☒ P/U ☐ H/D ☐ CMI ☐ EE

Intake By: WKP Date: 4/28/2026				Quality Checks By: IAS Date: 5/1/2026				Flow Adjustment By:			
☒ Annual ☒ Dropped Off ☐ Registration ☐ Return from CMI / EE ☐ Training Instrument Visual Inspection ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/Accessories ☐ Power Cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes:				☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value: 146 ☒ Flow Verification (L/s) Flow Column #: ATP102 32 mm .148 (.139-.169) 36 mm .164 (.156-.190) 53 mm .234 (.228-.278) 103 mm .503 (.447-.547) ☒ Barometric Pressure Check Gauge ID #: 34419 Gauge: 1010 Instrument: 1005 ☒ Stability Checks				Flow Column #: ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value: ☐ Post Adjustment Verification (L/S) Flow Column #: 32 mm (.139-.169) 36 mm (.156-.190) 53 mm (.228-.278) 103 mm (.447-.547)			
				Simulator		Serial #		Lot#/Exp		Maintenance By: Date:	
				0.050		MP5088		202603A 3/3/2028		☐ Battery Replacement	
				0.080		MP5089		202603B 3/3/2028		☐ Dry Gas Regulator Replacement	
				0.200		MP5090		202603D 3/4/2028		☐ Tank Sensor Tare	
				0.080 DGS		N/A		23825080A1 10/5/2027		☐ Breath Tube Replacement	
										☐ Other:	
Optical Bench Adjustment By:				Department Inspection By: KTS							
Barometric Pressure Gauge: ID#:				Barometric Pressure ID#: 28427							
Simulator		Serial #		Lot #		Expiration		Gauge: 1010 Instrument: 1008			
0.000				N/A		N/A		Mouth Alcohol Solution Lot #: 2025-D Exp: 9/25/2027			
0.040								Acetone Stock Solution Lot #: 2025-B Exp: 9/22/2027			
0.100								Simulator		Serial Number	
0.200								0.000		MP6289	
0.300								Interferent		MP6290	
0.080 DGS		N/A						0.050		MP6291	
☐ Post Optical Bench Adjustment Stability Checks				0.080				MP6292			
Simulator		Serial #		Lot #		Expiration		0.200		MP6293	
0.050								Attachments			
0.080								☒ Form 41		☐ Post-Stability Checks	
0.200								☒ Stability Checks		☐ Flow Adjustment	
0.080 DGS		N/A						☒ Calibration Certificate		☐ Form 40	
Gauge ID #: Instrument:				☐ Optical Bench Adjustment				☐ Other:			
Notes/Suggested Service:				☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC							
Tech Review: Added remarks comment on Form 41. KTS 5/12/26				☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use							
*Admin Review: Corrected return method. WKP 5/15/2026				☒ Conduct an Agency Inspection Before Evidentiary Use							
				Taylor Gutschow Digitally signed by Taylor Gutschow Date: 2026.05.13 14:02:00 -04'00'				LeAndra Higginbotham		Digitally signed by LeAndra Higginbotham Date: 2026.05.15 10:42:30 -04'00'	
				Tech Review				Admin Review			

Stability Checks

0.050 g/210L 0.047 to 0.053 g/210L	0.080 g/210L 0.077 to 0.083 g/210L	0.200 g/210L 0.194 to 0.206 g/210L	DGS 0.080 g/210L 0.077 to 0.083 g/210L ±0.003 g/210L of Wet																																																																																																																																																
BLOUNTSTOWN PD Intoxilyzer - Alcohol Analyzer Model: 8000 SN 80-000862 05/01/2026 Software: 8100.27 <table><thead><tr><th>Test</th><th>g/210L</th><th>Time</th></tr></thead><tbody><tr><td>Air Blank</td><td>0.000</td><td>13:17</td></tr><tr><td>Control Test</td><td>0.049</td><td>13:18</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:18</td></tr><tr><td>Control Test</td><td>0.049</td><td>13:19</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:20</td></tr><tr><td>Control Test</td><td>0.049</td><td>13:20</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:21</td></tr><tr><td>Control Test Stats</td><td></td><td></td></tr><tr><td>Average</td><td>0.0490</td><td></td></tr><tr><td>Std Dev</td><td>0.0000</td><td></td></tr><tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr></tbody></table> Asakella Smythonski Operator's Signature	Test	g/210L	Time	Air Blank	0.000	13:17	Control Test	0.049	13:18	Air Blank	0.000	13:18	Control Test	0.049	13:19	Air Blank	0.000	13:20	Control Test	0.049	13:20	Air Blank	0.000	13:21	Control Test Stats			Average	0.0490		Std Dev	0.0000		Rel Std Dev(%)	0.0000		BLOUNTSTOWN PD Intoxilyzer - Alcohol Analyzer Model: 8000 SN 80-000862 05/01/2026 Software: 8100.27 <table><thead><tr><th>Test</th><th>g/210L</th><th>Time</th></tr></thead><tbody><tr><td>Air Blank</td><td>0.000</td><td>13:09</td></tr><tr><td>Control Test</td><td>0.078</td><td>13:10</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:11</td></tr><tr><td>Control Test</td><td>0.078</td><td>13:12</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:12</td></tr><tr><td>Control Test</td><td>0.078</td><td>13:13</td></tr><tr><td>Air Blank</td><td>0.000</td><td>13:13</td></tr><tr><td>Control Test Stats</td><td></td><td></td></tr><tr><td>Average</td><td>0.0780</td><td></td></tr><tr><td>Std Dev</td><td>0.0000</td><td></td></tr><tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr></tbody></table> Asakella Smythonski Operator's Signature	Test	g/210L	Time	Air Blank	0.000	13:09	Control Test	0.078	13:10	Air Blank	0.000	13:11	Control Test	0.078	13:12	Air Blank	0.000	13:12	Control Test	0.078	13:13	Air Blank	0.000	13:13	Control Test Stats			Average	0.0780		Std Dev	0.0000		Rel Std Dev(%)	0.0000		BLOUNTSTOWN PD Intoxilyzer - Alcohol Analyzer Model: 8000 SN 80-000862 05/01/2026 Software: 8100.27 <table><thead><tr><th>Test</th><th>g/210L</th><th>Time</th></tr></thead><tbody><tr><td>Air Blank</td><td>0.000</td><td>14:07</td></tr><tr><td>Control Test</td><td>0.201</td><td>14:08</td></tr><tr><td>Air Blank</td><td>0.000</td><td>14:09</td></tr><tr><td>Control Test</td><td>0.199</td><td>14:09</td></tr><tr><td>Air Blank</td><td>0.000</td><td>14:10</td></tr><tr><td>Control Test</td><td>0.197</td><td>14:11</td></tr><tr><td>Air Blank</td><td>0.000</td><td>14:11</td></tr><tr><td>Control Test Stats</td><td></td><td></td></tr><tr><td>Average</td><td>0.1990</td><td></td></tr><tr><td>Std Dev</td><td>0.0020</td><td></td></tr><tr><td>Rel Std Dev(%)</td><td>1.0150</td><td></td></tr></tbody></table> Asakella Smythonski Operator's Signature	Test	g/210L	Time	Air Blank	0.000	14:07	Control Test	0.201	14:08	Air Blank	0.000	14:09	Control Test	0.199	14:09	Air Blank	0.000	14:10	Control Test	0.197	14:11	Air Blank	0.000	14:11	Control Test Stats			Average	0.1990		Std Dev	0.0020		Rel Std Dev(%)	1.0150		BLOUNTSTOWN PD Intoxilyzer - Alcohol Analyzer Model: 8000 SN 80-000862 05/01/2026 Software: 8100.27 <table><thead><tr><th>Test</th><th>g/210L</th><th>Time</th></tr></thead><tbody><tr><td>Air Blank</td><td>0.000</td><td>14:14</td></tr><tr><td>Control Test</td><td>0.080</td><td>14:15</td></tr><tr><td>Air Blank</td><td>0.000</td><td>14:15</td></tr><tr><td>Control Test</td><td>0.080</td><td>14:16</td></tr><tr><td>Air Blank</td><td>0.000</td><td>14:16</td></tr><tr><td>Control Test</td><td>0.080</td><td>14:16</td></tr><tr><td>Air Blank</td><td>0.000</td><td>14:17</td></tr><tr><td>Control Test Stats</td><td></td><td></td></tr><tr><td>Average</td><td>0.0800</td><td></td></tr><tr><td>Std Dev</td><td>0.0000</td><td></td></tr><tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr></tbody></table> Asakella Smythonski Operator's Signature	Test	g/210L	Time	Air Blank	0.000	14:14	Control Test	0.080	14:15	Air Blank	0.000	14:15	Control Test	0.080	14:16	Air Blank	0.000	14:16	Control Test	0.080	14:16	Air Blank	0.000	14:17	Control Test Stats			Average	0.0800		Std Dev	0.0000		Rel Std Dev(%)	0.0000	
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	13:17																																																																																																																																																	
Control Test	0.049	13:18																																																																																																																																																	
Air Blank	0.000	13:18																																																																																																																																																	
Control Test	0.049	13:19																																																																																																																																																	
Air Blank	0.000	13:20																																																																																																																																																	
Control Test	0.049	13:20																																																																																																																																																	
Air Blank	0.000	13:21																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0490																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	13:09																																																																																																																																																	
Control Test	0.078	13:10																																																																																																																																																	
Air Blank	0.000	13:11																																																																																																																																																	
Control Test	0.078	13:12																																																																																																																																																	
Air Blank	0.000	13:12																																																																																																																																																	
Control Test	0.078	13:13																																																																																																																																																	
Air Blank	0.000	13:13																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0780																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	14:07																																																																																																																																																	
Control Test	0.201	14:08																																																																																																																																																	
Air Blank	0.000	14:09																																																																																																																																																	
Control Test	0.199	14:09																																																																																																																																																	
Air Blank	0.000	14:10																																																																																																																																																	
Control Test	0.197	14:11																																																																																																																																																	
Air Blank	0.000	14:11																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.1990																																																																																																																																																		
Std Dev	0.0020																																																																																																																																																		
Rel Std Dev(%)	1.0150																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	14:14																																																																																																																																																	
Control Test	0.080	14:15																																																																																																																																																	
Air Blank	0.000	14:15																																																																																																																																																	
Control Test	0.080	14:16																																																																																																																																																	
Air Blank	0.000	14:16																																																																																																																																																	
Control Test	0.080	14:16																																																																																																																																																	
Air Blank	0.000	14:17																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0800																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		

Florida Department of Law Enforcement

Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: BLOUNTSTOWN PD
Time of Inspection: 08:54

Date of Inspection: 05/05/2026

Serial Number: 80-000862
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202603A Exp: 03/03/2028	0.08g/210L Test (g/210L) Lot#:202603B Exp: 03/03/2028	0.20g/210L Test (g/210L) Lot#:202603D Exp: 03/04/2028	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:23825080A1 Exp: 10/05/2027
0.000	0.050	0.079	0.201	0.081
0.000	0.050	0.079	0.202	0.081
0.000	0.050	0.079	0.202	0.081
0.000	0.050	0.079	0.202	0.082
0.000	0.050	0.079	0.202	0.081
0.000	0.050	0.079	0.202	0.081
0.000	0.050	0.079	0.202	0.081
0.000	0.050	0.079	0.202	0.081
0.000	0.050	0.080	0.202	0.081
0.000	0.051	0.079	0.202	0.081

Standard Deviations	0.0003	0.0003	0.0003	0.0003
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0003 Number of Simulators Used: 5


Remarks:

A F / M A: No Sample Provided.

Test timed out before sample was provided. Repeated test and provided sample in allowable time. KTS 5/12/26

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

 KATIE T SPEARIN
Signature and Printed Name

05/05/2026
Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000862, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000862</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>BLOUNTSTOWN PD</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>05/05/2026</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>08:54</u>	0.200 g/ 210 L	0.008
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

05/05/2026

Date

KATIE T SPEARIN,

Department Inspector

FDLE/ATP Form 69 January 2026

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality