

Alcohol Testing Program - Instrument Processing Sheet

Agency: SANTA ROSA COUNTY SO

Instrument Serial Number: 80-001302

Date In: 6/9/2026

DI Completion Date: N/A

☐ Ship☐ P/U☐ H/D☒ CMI☐ EE

Intake By: <u>SLH</u> Date: <u>6/9/2026</u>		Quality Checks By: <u>IAS</u> Date: <u>6/11/2026</u>		Flow Adjustment By: _____																																									
☒ Annual ☐ Dropped Off ☐ Registration ☐ Return from CMI / EE ☐ Training Instrument Visual Inspection ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/Accessories ☐ Power Cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes:		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value: <u>111</u> ☒ Flow Verification (L/s) Flow Column #: <u>ATP102</u> 32 mm <u>.152</u> (.139-.169) 36 mm <u>.160</u> (.156-.190) 53 mm <u>.242</u> (.228-.278) 103 mm <u>.523</u> (.447-.547) ☒ Barometric Pressure Check Gauge ID #: <u>28427</u> Gauge: <u>1011</u> Instrument: <u>1012</u> ☒ Stability Checks		Flow Column #: _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value: _____ ☐ Post Adjustment Verification (L/S) Flow Column #: _____ 32 mm _____ (.139-.169) 36 mm _____ (.156-.190) 53 mm _____ (.228-.278) 103 mm _____ (.447-.547)																																									
		<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot#/Exp</th></tr></thead><tbody><tr><td>0.050</td><td>MP5088</td><td>202603A 3/3/2028</td></tr><tr><td>0.080</td><td>MP6292</td><td>202603B 3/3/2028</td></tr><tr><td>0.200</td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td>23825080A1 10/5/2027</td></tr></tbody></table>		Simulator	Serial #	Lot#/Exp	0.050	MP5088	202603A 3/3/2028	0.080	MP6292	202603B 3/3/2028	0.200			0.080 DGS	N/A	23825080A1 10/5/2027	<table border="1"><thead><tr><th>Maintenance By:</th><th>Date:</th></tr></thead><tbody><tr><td>☐ Battery Replacement</td><td></td></tr><tr><td>☐ Dry Gas Regulator Replacement</td><td></td></tr><tr><td>☐ Tank Sensor Tare</td><td></td></tr><tr><td>☐ Breath Tube Replacement</td><td></td></tr><tr><td>☐ Other:</td><td></td></tr></tbody></table>		Maintenance By:	Date:	☐ Battery Replacement		☐ Dry Gas Regulator Replacement		☐ Tank Sensor Tare		☐ Breath Tube Replacement		☐ Other:														
Simulator	Serial #	Lot#/Exp																																											
0.050	MP5088	202603A 3/3/2028																																											
0.080	MP6292	202603B 3/3/2028																																											
0.200																																													
0.080 DGS	N/A	23825080A1 10/5/2027																																											
Maintenance By:	Date:																																												
☐ Battery Replacement																																													
☐ Dry Gas Regulator Replacement																																													
☐ Tank Sensor Tare																																													
☐ Breath Tube Replacement																																													
☐ Other:																																													
Optical Bench Adjustment By: _____		Department Inspection By: _____																																											
Barometric Pressure Gauge: _____ ID#: _____		Barometric Pressure ID#: _____																																											
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.000</td><td></td><td>N/A</td><td>N/A</td></tr><tr><td>0.040</td><td></td><td></td><td></td></tr><tr><td>0.100</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.300</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Gauge: _____ Instrument: _____ Mouth Alcohol Solution Lot #: _____ Exp: _____ Acetone Stock Solution Lot #: _____ Exp: _____		<table border="1"><thead><tr><th>Simulator</th><th>Serial Number</th></tr></thead><tbody><tr><td>0.000</td><td></td></tr><tr><td>Interferent</td><td></td></tr><tr><td>0.050</td><td></td></tr><tr><td>0.080</td><td></td></tr><tr><td>0.200</td><td></td></tr></tbody></table>		Simulator	Serial Number	0.000		Interferent		0.050		0.080		0.200	
Simulator	Serial #	Lot #	Expiration																																										
0.000		N/A	N/A																																										
0.040																																													
0.100																																													
0.200																																													
0.300																																													
0.080 DGS	N/A																																												
Simulator	Serial Number																																												
0.000																																													
Interferent																																													
0.050																																													
0.080																																													
0.200																																													
☐ Post Optical Bench Adjustment Stability Checks		Attachments																																											
<table border="1"><thead><tr><th>Simulator</th><th>Serial #</th><th>Lot #</th><th>Expiration</th></tr></thead><tbody><tr><td>0.050</td><td></td><td></td><td></td></tr><tr><td>0.080</td><td></td><td></td><td></td></tr><tr><td>0.200</td><td></td><td></td><td></td></tr><tr><td>0.080 DGS</td><td>N/A</td><td></td><td></td></tr></tbody></table>		Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			☐ Form 41 ☒ Stability Checks ☐ Calibration Certificate ☐ Optical Bench Adjustment		☐ Post-Stability Checks ☐ Flow Adjustment ☐ Form 40 ☒ Other: Return Material Authorization																					
Simulator	Serial #	Lot #	Expiration																																										
0.050																																													
0.080																																													
0.200																																													
0.080 DGS	N/A																																												
Gauge ID #: _____ Gauge: _____ Instrument: _____																																													
Notes/Suggested Service:		☐ Instrument Complies with Chapter 11D-8, FAC ☒ Instrument Does Not Comply with Chapter 11D-8, FAC ☐ Return to/Place into Evidentiary Use ☒ Remain Out of Evidentiary Use ☐ Conduct an Agency Inspection Before Evidentiary Use																																											
		<table border="0"><tr><td>LeAndra Higginbotham Tech Review</td><td>Digitally signed by LeAndra Higginbotham Date: 2026.06.18 18:29:05 -04'00'</td><td>Kaitlyn Spearin Admin Review</td><td>Digitally signed by Kaitlyn Spearin Date: 2026.06.19 05:55:26 -04'00'</td></tr></table>				LeAndra Higginbotham Tech Review	Digitally signed by LeAndra Higginbotham Date: 2026.06.18 18:29:05 -04'00'	Kaitlyn Spearin Admin Review	Digitally signed by Kaitlyn Spearin Date: 2026.06.19 05:55:26 -04'00'																																				
LeAndra Higginbotham Tech Review	Digitally signed by LeAndra Higginbotham Date: 2026.06.18 18:29:05 -04'00'	Kaitlyn Spearin Admin Review	Digitally signed by Kaitlyn Spearin Date: 2026.06.19 05:55:26 -04'00'																																										

Stability Checks

0.050 g/210L 0.047 to 0.053 g/210L	0.080 g/210L 0.077 to 0.083 g/210L	0.200 g/210L 0.194 to 0.206 g/210L	DGS 0.080 g/210L 0.077 to 0.083 g/210L ±0.003 g/210L of Wet																																																																																																															
SANTA ROSA COUNTY SO Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-001302 06/11/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>11:57</td></tr> <tr><td>Control Test</td><td>0.000</td><td>11:57</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:58</td></tr> <tr><td>Control Test</td><td>0.000</td><td>11:58</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:59</td></tr> <tr><td>Control Test</td><td>0.000</td><td>11:59</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>12:00</td></tr> <tr><td>Control Test</td><td>0.000</td><td>12:00</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0000</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </tbody> </table>	Test	g/210L	Time	Air Blank	0.000	11:57	Control Test	0.000	11:57	Air Blank	0.000	11:58	Control Test	0.000	11:58	Air Blank	0.000	11:59	Control Test	0.000	11:59	Air Blank	0.000	12:00	Control Test	0.000	12:00	Control Test Stats			Average	0.0000		Std Dev	0.0000		Rel Std Dev(%)	0.0000		SANTA ROSA COUNTY SO Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-001302 06/11/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>12:19</td></tr> <tr><td>Control Test</td><td>0.000</td><td>12:20</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>12:20</td></tr> <tr><td>Control Test</td><td>0.000</td><td>12:21</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>12:21</td></tr> <tr><td>Control Test</td><td>0.000</td><td>12:22</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>12:22</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0000</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </tbody> </table>	Test	g/210L	Time	Air Blank	0.000	12:19	Control Test	0.000	12:20	Air Blank	0.000	12:20	Control Test	0.000	12:21	Air Blank	0.000	12:21	Control Test	0.000	12:22	Air Blank	0.000	12:22	Control Test Stats			Average	0.0000		Std Dev	0.0000		Rel Std Dev(%)	0.0000		Did not run due to instrument needing repair. IAS 6/12/26	SANTA ROSA COUNTY SO Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-001302 06/11/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>11:26</td></tr> <tr><td>Control Test</td><td>0.079</td><td>11:26</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:27</td></tr> <tr><td>Control Test</td><td>0.078</td><td>11:27</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:27</td></tr> <tr><td>Control Test</td><td>0.079</td><td>11:28</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:28</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0787</td><td></td></tr> <tr><td>Std Dev</td><td>0.0016</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.7339</td><td></td></tr> </tbody> </table>	Test	g/210L	Time	Air Blank	0.000	11:26	Control Test	0.079	11:26	Air Blank	0.000	11:27	Control Test	0.078	11:27	Air Blank	0.000	11:27	Control Test	0.079	11:28	Air Blank	0.000	11:28	Control Test Stats			Average	0.0787		Std Dev	0.0016		Rel Std Dev(%)	0.7339	
Test	g/210L	Time																																																																																																																
Air Blank	0.000	11:57																																																																																																																
Control Test	0.000	11:57																																																																																																																
Air Blank	0.000	11:58																																																																																																																
Control Test	0.000	11:58																																																																																																																
Air Blank	0.000	11:59																																																																																																																
Control Test	0.000	11:59																																																																																																																
Air Blank	0.000	12:00																																																																																																																
Control Test	0.000	12:00																																																																																																																
Control Test Stats																																																																																																																		
Average	0.0000																																																																																																																	
Std Dev	0.0000																																																																																																																	
Rel Std Dev(%)	0.0000																																																																																																																	
Test	g/210L	Time																																																																																																																
Air Blank	0.000	12:19																																																																																																																
Control Test	0.000	12:20																																																																																																																
Air Blank	0.000	12:20																																																																																																																
Control Test	0.000	12:21																																																																																																																
Air Blank	0.000	12:21																																																																																																																
Control Test	0.000	12:22																																																																																																																
Air Blank	0.000	12:22																																																																																																																
Control Test Stats																																																																																																																		
Average	0.0000																																																																																																																	
Std Dev	0.0000																																																																																																																	
Rel Std Dev(%)	0.0000																																																																																																																	
Test	g/210L	Time																																																																																																																
Air Blank	0.000	11:26																																																																																																																
Control Test	0.079	11:26																																																																																																																
Air Blank	0.000	11:27																																																																																																																
Control Test	0.078	11:27																																																																																																																
Air Blank	0.000	11:27																																																																																																																
Control Test	0.079	11:28																																																																																																																
Air Blank	0.000	11:28																																																																																																																
Control Test Stats																																																																																																																		
Average	0.0787																																																																																																																	
Std Dev	0.0016																																																																																																																	
Rel Std Dev(%)	0.7339																																																																																																																	
<i>Isabella Sypcinski</i> Operator's Signature	<i>Isabella Sypcinski</i> Operator's Signature		<i>Isabella Sypcinski</i> Operator's Signature																																																																																																															

#3 run of .05g/210L
Wet Stability

Ran another stability
check due to RFI
Exception message
in Run #2. IAS 6/12/26

SANTA ROSA COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model: 8000 SN 85-001302
06/11/2026
Software: 8.00.27

Test	g/210L	Time
Air Blank	0.000	12:09
Control Test	0.000	12:10
Air Blank	0.000	12:10
Control Test	0.000	12:11
Air Blank	0.000	12:11
Control Test	0.000	12:12
Air Blank	0.000	12:12
Control Test Status		
Average	0.0000	
Std Dev	0.0000	
Rel Std Dev(%)	0.0000	

Adellea Sushanova
Operator's Signature

#2 run of .05g/210L
Wet Stability

Ran another
stability check
to confirm the
correct sample
type was
selected. IAS 6/12/26

SANTA ROSA COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model: 8000 SN 85-001302
06/11/2026
Software: 8.00.27

Test	g/210L	Time
Air Blank	0.000	12:06
Control Test	0.000	12:07
Air Blank	0.000	12:07
Control Test	RFI*	12:08
Air Blank	0.000	12:08
*RFI Detect		

Adellea Sushanova
Operator's Signature

Return Material Authorization

Ship to:☒ CMI, Inc.☐ Enforcement ElectronicsShipment to repair facility authorized by: Duron Nelson on 6/15/2026Items Returned: ☒ Instrument ☐ Supplies ☐ Other Describe: _____Instrument Model: Intoxilyzer 8000 Serial Number: 80-001302

Bill To Address:

Santa Rosa County Sheriff Office
ATTN: Sgt Raymond Spencer
5755 East Milton Rd
Milton, FL 32565

Ship to Address:

FDLE Offsite Mail Facility
c/o FDLE HQ
813 B Lake Bradford Rd
Tallahassee, FL 32304

Reason for Return:

The instrument was reading the alcohol reference solution concentration as zero during the stability checks and intermittently flagged radio frequency interference.

I require an estimate **BEFORE** any repairs will be authorized and/or conducted

Please contact: Raymond Spencer Phone #: 8504547668Email: rspencer@srsso.netATP Contact Name: Wen-Chi PiersonATP Email: Wen-ChiPierson@fdle.state.fl.us