

Alcohol Testing Program - Instrument Processing Sheet

Agency: FFWCC

Instrument Serial Number: 80-000892

Date In: 7/22/2026

DI Completion Date: 7/23/2026

☐ Ship

☒ P/U

☐ H/D

☐ CMI

☐ EE

Intake By: <u>WKP</u> Date: <u>7/22/2026</u>		Quality Checks By: <u>WKP</u> Date: <u>7/22/2028</u>		Flow Adjustment By: _____																															
☒ Annual ☒ Dropped Off ☐ Registration ☐ Return from CMI / EE ☐ Training Instrument Visual Inspection ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/Accessories ☐ Power Cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes:		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value: <u>224</u> ☒ Flow Verification (L/s) Flow Column #: <u>ATP 105</u> 32 mm <u>0.148</u> (.139-.169) 36 mm <u>0.167</u> (.156-.190) 53 mm <u>0.242</u> (.228-.278) 103 mm <u>0.539</u> (.447-.547) ☒ Barometric Pressure Check Gauge ID #: <u>34419</u> Gauge: <u>1012</u> Instrument: <u>1010</u> ☒ Stability Checks		Flow Column #: _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value: _____ ☐ Post Adjustment Verification (L/S) Flow Column #: _____ 32 mm (.139-.169) 36 mm (.156-.190) 53 mm (.228-.278) 103 mm (.447-.547)																															
						<table border="1" style="width:100%; border-collapse: collapse;"> <tr> <th style="width:15%;">Simulator</th> <th style="width:20%;">Serial #</th> <th style="width:25%;">Lot#/Exp</th> <th style="width:40%;">Maintenance By: _____ Date: _____</th> </tr> <tr> <td rowspan="2">0.050</td> <td rowspan="2">MP6291</td> <td>202603A</td> <td>☐ Battery Replacement</td> </tr> <tr> <td>3/3/2028</td> <td>☐ Dry Gas Regulator Replacement</td> </tr> <tr> <td rowspan="2">0.080</td> <td rowspan="2">MP6292</td> <td>202603B</td> <td>☐ Tank Sensor Tare</td> </tr> <tr> <td>3/3/2028</td> <td>☐ Breath Tube Replacement</td> </tr> <tr> <td rowspan="2">0.200</td> <td rowspan="2">MP6293</td> <td>202603D</td> <td>☐ Other:</td> </tr> <tr> <td>3/4/2028</td> <td></td> </tr> <tr> <td rowspan="2">0.080 DGS</td> <td rowspan="2">N/A</td> <td>23825080A1</td> <td></td> </tr> <tr> <td>10/5/2027</td> <td></td> </tr> </table>		Simulator	Serial #	Lot#/Exp	Maintenance By: _____ Date: _____	0.050	MP6291	202603A	☐ Battery Replacement	3/3/2028	☐ Dry Gas Regulator Replacement	0.080	MP6292	202603B	☐ Tank Sensor Tare	3/3/2028	☐ Breath Tube Replacement	0.200	MP6293	202603D	☐ Other:	3/4/2028		0.080 DGS	N/A	23825080A1		10/5/2027	
						Simulator	Serial #	Lot#/Exp	Maintenance By: _____ Date: _____																										
						0.050	MP6291	202603A	☐ Battery Replacement																										
								3/3/2028	☐ Dry Gas Regulator Replacement																										
0.080	MP6292	202603B	☐ Tank Sensor Tare																																
		3/3/2028	☐ Breath Tube Replacement																																
0.200	MP6293	202603D	☐ Other:																																
		3/4/2028																																	
0.080 DGS	N/A	23825080A1																																	
		10/5/2027																																	
Optical Bench Adjustment By: _____ Department Inspection By: <u>WKP</u> Barometric Pressure Gauge: _____ ID#: _____ Barometric Pressure ID#: <u>28427</u>																																			
<table border="1" style="width:100%; border-collapse: collapse;"> <tr> <th style="width:15%;">Simulator</th> <th style="width:20%;">Serial #</th> <th style="width:25%;">Lot #</th> <th style="width:40%;">Expiration</th> </tr> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </table>		Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Gauge: <u>1014</u> Instrument: <u>1014</u> Mouth Alcohol Solution Lot #: <u>2025-D</u> Exp: <u>9/25/2027</u> Acetone Stock Solution Lot #: <u>2025-B</u> Exp: <u>9/22/2027</u>					
Simulator	Serial #	Lot #	Expiration																																
0.000		N/A	N/A																																
0.040																																			
0.100																																			
0.200																																			
0.300																																			
0.080 DGS	N/A																																		
☐ Post Optical Bench Adjustment Stability Checks		<table border="1" style="width:100%; border-collapse: collapse;"> <tr> <th style="width:15%;">Simulator</th> <th style="width:20%;">Serial #</th> <th style="width:25%;">Lot #</th> <th style="width:40%;">Expiration</th> </tr> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </table>		Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Gauge ID #: _____ Gauge: _____ Instrument: _____											
Simulator	Serial #	Lot #	Expiration																																
0.050																																			
0.080																																			
0.200																																			
0.080 DGS	N/A																																		
Notes/Suggested Service:		☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Optical Bench Adjustment		☐ Post-Stability Checks ☐ Flow Adjustment ☐ Form 40 ☐ Other:																															
		☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC																																	
		☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use																																	
		☒ Conduct an Agency Inspection Before Evidentiary Use																																	
		<table style="width:100%;"> <tr> <td style="width:50%;"> Digitally signed by LeAndra Higginbotham Date: 2026.07.27 10:44:31 -04'00' </td> <td style="width:50%;"> Digitally signed by Shayla Platt Date: 2026.07.29 12:41:54 -04'00' </td> </tr> </table>				Digitally signed by LeAndra Higginbotham Date: 2026.07.27 10:44:31 -04'00'	Digitally signed by Shayla Platt Date: 2026.07.29 12:41:54 -04'00'																												
		Digitally signed by LeAndra Higginbotham Date: 2026.07.27 10:44:31 -04'00'	Digitally signed by Shayla Platt Date: 2026.07.29 12:41:54 -04'00'																																
Tech Review _____ Admin Review _____																																			

Stability Checks

0.05g/210L 0.047 to 0.053	0.08g/210L 0.077 to 0.083	0.20g/210L 0.194 to 0.206	DGS 0.08g/210L 0.077 to 0.083 ≤ 0.003 of Wet																																																																																																																																																
FFA00 Intoxilyzer - Alcohol Analyzer Model 8100 SN 80-000892 07/22/2026 Software: 8100.27	FFA00 Intoxilyzer - Alcohol Analyzer Model 8100 SN 80-000892 07/22/2026 Software: 8100.27	FFA00 Intoxilyzer - Alcohol Analyzer Model 8100 SN 80-000892 07/22/2026 Software: 8100.27	FFA00 Intoxilyzer - Alcohol Analyzer Model 8100 SN 80-000892 07/22/2026 Software: 8100.27																																																																																																																																																
<table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>12:24</td></tr> <tr><td>Control Test</td><td>0.050</td><td>12:24</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>12:25</td></tr> <tr><td>Control Test</td><td>0.050</td><td>12:26</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>12:26</td></tr> <tr><td>Control Test</td><td>0.051</td><td>12:27</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>12:28</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0503</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>1.1471</td><td></td></tr> </tbody> </table>	Test	g/210L	Time	Air Blank	0.000	12:24	Control Test	0.050	12:24	Air Blank	0.000	12:25	Control Test	0.050	12:26	Air Blank	0.000	12:26	Control Test	0.051	12:27	Air Blank	0.000	12:28	Control Test Stats			Average	0.0503		Std Dev	0.0006		Rel Std Dev(%)	1.1471		<table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>12:31</td></tr> <tr><td>Control Test</td><td>0.081</td><td>12:32</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>12:33</td></tr> <tr><td>Control Test</td><td>0.080</td><td>12:33</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>12:34</td></tr> <tr><td>Control Test</td><td>0.079</td><td>12:35</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>12:35</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0800</td><td></td></tr> <tr><td>Std Dev</td><td>0.0010</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>1.2500</td><td></td></tr> </tbody> </table>	Test	g/210L	Time	Air Blank	0.000	12:31	Control Test	0.081	12:32	Air Blank	0.000	12:33	Control Test	0.080	12:33	Air Blank	0.000	12:34	Control Test	0.079	12:35	Air Blank	0.000	12:35	Control Test Stats			Average	0.0800		Std Dev	0.0010		Rel Std Dev(%)	1.2500		<table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>12:41</td></tr> <tr><td>Control Test</td><td>0.204</td><td>12:41</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>12:41</td></tr> <tr><td>Control Test</td><td>0.202</td><td>12:42</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>12:42</td></tr> <tr><td>Control Test</td><td>0.202</td><td>12:43</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>12:44</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.2027</td><td></td></tr> <tr><td>Std Dev</td><td>0.0012</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.5698</td><td></td></tr> </tbody> </table>	Test	g/210L	Time	Air Blank	0.000	12:41	Control Test	0.204	12:41	Air Blank	0.000	12:41	Control Test	0.202	12:42	Air Blank	0.000	12:42	Control Test	0.202	12:43	Air Blank	0.000	12:44	Control Test Stats			Average	0.2027		Std Dev	0.0012		Rel Std Dev(%)	0.5698		<table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>1.000</td><td>12:55</td></tr> <tr><td>Control Test</td><td>1.080</td><td>12:56</td></tr> <tr><td>Air Blank</td><td>1.000</td><td>12:56</td></tr> <tr><td>Control Test</td><td>1.081</td><td>12:57</td></tr> <tr><td>Air Blank</td><td>1.000</td><td>12:57</td></tr> <tr><td>Control Test</td><td>1.080</td><td>12:58</td></tr> <tr><td>Air Blank</td><td>1.000</td><td>12:58</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>1.0803</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>1.7187</td><td></td></tr> </tbody> </table>	Test	g/210L	Time	Air Blank	1.000	12:55	Control Test	1.080	12:56	Air Blank	1.000	12:56	Control Test	1.081	12:57	Air Blank	1.000	12:57	Control Test	1.080	12:58	Air Blank	1.000	12:58	Control Test Stats			Average	1.0803		Std Dev	0.0006		Rel Std Dev(%)	1.7187	
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	12:24																																																																																																																																																	
Control Test	0.050	12:24																																																																																																																																																	
Air Blank	0.000	12:25																																																																																																																																																	
Control Test	0.050	12:26																																																																																																																																																	
Air Blank	0.000	12:26																																																																																																																																																	
Control Test	0.051	12:27																																																																																																																																																	
Air Blank	0.000	12:28																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0503																																																																																																																																																		
Std Dev	0.0006																																																																																																																																																		
Rel Std Dev(%)	1.1471																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	12:31																																																																																																																																																	
Control Test	0.081	12:32																																																																																																																																																	
Air Blank	0.000	12:33																																																																																																																																																	
Control Test	0.080	12:33																																																																																																																																																	
Air Blank	0.000	12:34																																																																																																																																																	
Control Test	0.079	12:35																																																																																																																																																	
Air Blank	0.000	12:35																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0800																																																																																																																																																		
Std Dev	0.0010																																																																																																																																																		
Rel Std Dev(%)	1.2500																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	12:41																																																																																																																																																	
Control Test	0.204	12:41																																																																																																																																																	
Air Blank	0.000	12:41																																																																																																																																																	
Control Test	0.202	12:42																																																																																																																																																	
Air Blank	0.000	12:42																																																																																																																																																	
Control Test	0.202	12:43																																																																																																																																																	
Air Blank	0.000	12:44																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.2027																																																																																																																																																		
Std Dev	0.0012																																																																																																																																																		
Rel Std Dev(%)	0.5698																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	1.000	12:55																																																																																																																																																	
Control Test	1.080	12:56																																																																																																																																																	
Air Blank	1.000	12:56																																																																																																																																																	
Control Test	1.081	12:57																																																																																																																																																	
Air Blank	1.000	12:57																																																																																																																																																	
Control Test	1.080	12:58																																																																																																																																																	
Air Blank	1.000	12:58																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	1.0803																																																																																																																																																		
Std Dev	0.0006																																																																																																																																																		
Rel Std Dev(%)	1.7187																																																																																																																																																		
 Operator's Signature	 Operator's Signature	 Operator's Signature	 Operator's Signature																																																																																																																																																

Florida Department of Law Enforcement

Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: FFWCC

Time of Inspection: 12:04

Date of Inspection: 07/23/2026

Serial Number: 80-000892

Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202603A Exp: 03/03/2028	0.08g/210L Test (g/210L) Lot#:202603B Exp: 03/03/2028	0.20g/210L Test (g/210L) Lot#:202603D Exp: 03/04/2028	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:23825080A1 Exp: 10/05/2027
0.000	0.051	0.081	0.203	0.079
0.000	0.050	0.080	0.204	0.079
0.000	0.051	0.080	0.204	0.079
0.000	0.051	0.081	0.203	0.079
0.000	0.051	0.081	0.203	0.079
0.000	0.051	0.080	0.203	0.079
0.000	0.051	0.080	0.203	0.079
0.000	0.051	0.081	0.203	0.079
0.000	0.051	0.081	0.203	0.079
0.000	0.051	0.081	0.203	0.079


Standard Deviations	0.0003	0.0005	0.0004	0.0000
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0003 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



WEN-CHI K. PIERSON

Signature and Printed Name

07/23/2026
Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000892, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000892</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>FFWCC</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>07/23/2026</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>12:04</u>	0.200 g/ 210 L	0.008
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

07/23/2026

Date

Wen-Chi
Pierson

Digitally signed by
Wen-Chi Pierson
Date: 2026.07.23
14:39:47 -04'00'

WEN-CHI K PIERSON,
Department Inspector