

Alcohol Testing Program - Instrument Processing Sheet

Agency: WAKULLA COUNTY SO

Instrument Serial Number: 80-000962

Date In: 8/25/2026

DI Completion Date: 8/26/2026

☐ Ship ☒ P/U ☐ H/D ☐ CMI ☐ EE

Intake By: <u>WKP</u> Date: <u>8/25/2026</u>		Quality Checks By: <u>WKP</u> Date: <u>8/25/2026</u>		Flow Adjustment By: _____																																							
☒ Annual ☒ Dropped Off ☐ Registration ☐ Return from CMI / EE ☐ Training Instrument Visual Inspection ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/Accessories ☐ Power Cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes:		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value: <u>199</u> ☒ Flow Verification (L/s) Flow Column #: <u>ATP 102</u> 32 mm <u>0.156</u> (.139-.169) 36 mm <u>0.171</u> (.156-.190) 53 mm <u>0.246</u> (.228-.278) 103 mm <u>0.503</u> (.447-.547) ☒ Barometric Pressure Check Gauge ID #: <u>34420</u> Gauge: <u>1012</u> Instrument: <u>1008</u> ☒ Stability Checks		Flow Column #: _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value: _____ ☐ Post Adjustment Verification (L/S) Flow Column #: _____ 32 mm _____ (.139-.169) 36 mm _____ (.156-.190) 53 mm _____ (.228-.278) 103 mm _____ (.447-.547)																																							
						<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th style="width: 15%;">Simulator</th> <th style="width: 20%;">Serial #</th> <th style="width: 25%;">Lot#/Exp</th> <th style="width: 40%;">Maintenance By: _____ Date: _____</th> </tr> <tr> <td>0.050</td> <td>MP5088</td> <td>202603A 3/3/2028</td> <td rowspan="5"> ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Tank Sensor Tare ☐ Breath Tube Replacement ☐ Other: </td> </tr> <tr> <td>0.080</td> <td>MP5089</td> <td>202603B 3/3/2028</td> </tr> <tr> <td>0.200</td> <td>MP5090</td> <td>202603D 3/4/2028</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>23725080A1 10/5/2027</td> </tr> <tr> <td colspan="3"></td> </tr> </table>		Simulator	Serial #	Lot#/Exp	Maintenance By: _____ Date: _____	0.050	MP5088	202603A 3/3/2028	☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Tank Sensor Tare ☐ Breath Tube Replacement ☐ Other:	0.080	MP5089	202603B 3/3/2028	0.200	MP5090	202603D 3/4/2028	0.080 DGS	N/A	23725080A1 10/5/2027																			
						Simulator	Serial #	Lot#/Exp	Maintenance By: _____ Date: _____																																		
						0.050	MP5088	202603A 3/3/2028	☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Tank Sensor Tare ☐ Breath Tube Replacement ☐ Other:																																		
						0.080	MP5089	202603B 3/3/2028																																			
0.200	MP5090	202603D 3/4/2028																																									
0.080 DGS	N/A	23725080A1 10/5/2027																																									
Optical Bench Adjustment By: <u>WKP</u>		Department Inspection By: <u>WKP</u>																																									
Barometric Pressure Gauge: <u>1013</u> ID#: <u>28662</u>		Barometric Pressure ID#: <u>34420</u>																																									
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th style="width: 15%;">Simulator</th> <th style="width: 20%;">Serial #</th> <th style="width: 25%;">Lot #</th> <th style="width: 40%;">Expiration</th> </tr> <tr> <td>0.000</td> <td>MP6294</td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td>MP6295</td> <td>25090</td> <td>3/11/2027</td> </tr> <tr> <td>0.100</td> <td>MP6296</td> <td>24390</td> <td>10/29/2026</td> </tr> <tr> <td>0.200</td> <td>MP6297</td> <td>25020</td> <td>1/14/2027</td> </tr> <tr> <td>0.300</td> <td>MP6298</td> <td>24430</td> <td>12/10/2026</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG526603</td> <td>9/23/2027</td> </tr> </table>		Simulator	Serial #	Lot #	Expiration	0.000	MP6294	N/A	N/A	0.040	MP6295	25090	3/11/2027	0.100	MP6296	24390	10/29/2026	0.200	MP6297	25020	1/14/2027	0.300	MP6298	24430	12/10/2026	0.080 DGS	N/A	AG526603	9/23/2027	Gauge: <u>1013</u> Instrument: <u>1012</u> Mouth Alcohol Solution Lot #: <u>2025-D</u> Exp: <u>9/25/2027</u> Acetone Stock Solution Lot #: <u>2025-B</u> Exp: <u>9/22/2027</u> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th style="width: 50%;">Simulator</th> <th style="width: 50%;">Serial Number</th> </tr> <tr> <td>0.000</td> <td>MP5086</td> </tr> <tr> <td>Interferent</td> <td>MP5087</td> </tr> <tr> <td>0.050</td> <td>MP5088</td> </tr> <tr> <td>0.080</td> <td>MP5089</td> </tr> <tr> <td>0.200</td> <td>MP5090</td> </tr> </table>		Simulator	Serial Number	0.000	MP5086	Interferent	MP5087	0.050	MP5088	0.080	MP5089	0.200	MP5090
Simulator	Serial #	Lot #	Expiration																																								
0.000	MP6294	N/A	N/A																																								
0.040	MP6295	25090	3/11/2027																																								
0.100	MP6296	24390	10/29/2026																																								
0.200	MP6297	25020	1/14/2027																																								
0.300	MP6298	24430	12/10/2026																																								
0.080 DGS	N/A	AG526603	9/23/2027																																								
Simulator	Serial Number																																										
0.000	MP5086																																										
Interferent	MP5087																																										
0.050	MP5088																																										
0.080	MP5089																																										
0.200	MP5090																																										
☒ Post Optical Bench Adjustment Stability Checks		Attachments																																									
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th style="width: 15%;">Simulator</th> <th style="width: 20%;">Serial #</th> <th style="width: 25%;">Lot #</th> <th style="width: 40%;">Expiration</th> </tr> <tr> <td>0.050</td> <td>MP5088</td> <td>202603A</td> <td>3/3/2028</td> </tr> <tr> <td>0.080</td> <td>MP5089</td> <td>202603B</td> <td>3/3/2028</td> </tr> <tr> <td>0.200</td> <td>MP5090</td> <td>202603D</td> <td>3/4/2028</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>23725080A1</td> <td>10/5/2027</td> </tr> </table>		Simulator	Serial #	Lot #	Expiration	0.050	MP5088	202603A	3/3/2028	0.080	MP5089	202603B	3/3/2028	0.200	MP5090	202603D	3/4/2028	0.080 DGS	N/A	23725080A1	10/5/2027	☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☒ Optical Bench Adjustment ☒ Average Calculations																					
Simulator	Serial #	Lot #	Expiration																																								
0.050	MP5088	202603A	3/3/2028																																								
0.080	MP5089	202603B	3/3/2028																																								
0.200	MP5090	202603D	3/4/2028																																								
0.080 DGS	N/A	23725080A1	10/5/2027																																								
Gauge ID #: <u>28427</u> Gauge: <u>1012</u> Instrument: <u>1012</u>																																											
Notes/Suggested Service:		☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use																																									
		<table style="width: 100%;"> <tr> <td style="width: 50%; vertical-align: top;"> Digitally signed by Taylor Gutschow Date: 2026.08.30 20:46:15 -04'00' </td> <td style="width: 50%; vertical-align: top;"> Kaitlyn Spearin Digitally signed by Kaitlyn Spearin Date: 2026.08.31 14:14:27 -04'00' </td> </tr> </table>		Digitally signed by Taylor Gutschow Date: 2026.08.30 20:46:15 -04'00'	Kaitlyn Spearin Digitally signed by Kaitlyn Spearin Date: 2026.08.31 14:14:27 -04'00'																																						
		Digitally signed by Taylor Gutschow Date: 2026.08.30 20:46:15 -04'00'	Kaitlyn Spearin Digitally signed by Kaitlyn Spearin Date: 2026.08.31 14:14:27 -04'00'																																								
<table style="width: 100%;"> <tr> <td style="width: 50%; text-align: center;">Tech Review</td> <td style="width: 50%; text-align: center;">Admin Review</td> </tr> </table>		Tech Review	Admin Review																																								
Tech Review	Admin Review																																										

Stability Checks

0.05g/210L 0.047 to 0.053	0.08g/210L 0.077 to 0.083	0.20g/210L 0.194 to 0.206	DGS 0.08g/210L 0.077 to 0.083 ✓ 50.003 of Wet ✓																																																																																																																																																
ARKULLA COUNTY SO Intoxilyzer - Alcohol Analyzer Model: 8000 SN 80-000362 08/25/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>13:41</td></tr> <tr><td>Control Test</td><td>0.048</td><td>13:42</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>13:42</td></tr> <tr><td>Control Test</td><td>0.048</td><td>13:43</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>13:44</td></tr> <tr><td>Control Test</td><td>0.048</td><td>13:44</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>13:45</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0480</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </tbody> </table>	Test	g/210L	Time	Air Blank	0.000	13:41	Control Test	0.048	13:42	Air Blank	0.000	13:42	Control Test	0.048	13:43	Air Blank	0.000	13:44	Control Test	0.048	13:44	Air Blank	0.000	13:45	Control Test Stats			Average	0.0480		Std Dev	0.0000		Rel Std Dev(%)	0.0000		ARKULLA COUNTY SO Intoxilyzer - Alcohol Analyzer Model: 8000 SN 80-000362 08/25/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>13:47</td></tr> <tr><td>Control Test</td><td>0.076</td><td>13:47</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>13:48</td></tr> <tr><td>Control Test</td><td>0.075</td><td>13:48</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>13:49</td></tr> <tr><td>Control Test</td><td>0.076</td><td>13:49</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>13:50</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0757</td><td></td></tr> <tr><td>Std Dev</td><td>0.0016</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.7633</td><td></td></tr> </tbody> </table>	Test	g/210L	Time	Air Blank	0.000	13:47	Control Test	0.076	13:47	Air Blank	0.000	13:48	Control Test	0.075	13:48	Air Blank	0.000	13:49	Control Test	0.076	13:49	Air Blank	0.000	13:50	Control Test Stats			Average	0.0757		Std Dev	0.0016		Rel Std Dev(%)	0.7633		ARKULLA COUNTY SO Intoxilyzer - Alcohol Analyzer Model: 8000 SN 80-000362 08/25/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>13:51</td></tr> <tr><td>Control Test</td><td>0.195</td><td>13:52</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>13:53</td></tr> <tr><td>Control Test</td><td>0.194</td><td>13:53</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>13:54</td></tr> <tr><td>Control Test</td><td>0.194</td><td>13:55</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>13:55</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.1943</td><td></td></tr> <tr><td>Std Dev</td><td>0.0036</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.2571</td><td></td></tr> </tbody> </table>	Test	g/210L	Time	Air Blank	0.000	13:51	Control Test	0.195	13:52	Air Blank	0.000	13:53	Control Test	0.194	13:53	Air Blank	0.000	13:54	Control Test	0.194	13:55	Air Blank	0.000	13:55	Control Test Stats			Average	0.1943		Std Dev	0.0036		Rel Std Dev(%)	0.2571		ARKULLA COUNTY SO Intoxilyzer - Alcohol Analyzer Model: 8000 SN 80-000362 08/25/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>13:17</td></tr> <tr><td>Control Test</td><td>0.078</td><td>13:18</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>13:18</td></tr> <tr><td>Control Test</td><td>0.078</td><td>13:18</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>13:19</td></tr> <tr><td>Control Test</td><td>0.078</td><td>13:19</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>13:20</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0780</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </tbody> </table>	Test	g/210L	Time	Air Blank	0.000	13:17	Control Test	0.078	13:18	Air Blank	0.000	13:18	Control Test	0.078	13:18	Air Blank	0.000	13:19	Control Test	0.078	13:19	Air Blank	0.000	13:20	Control Test Stats			Average	0.0780		Std Dev	0.0000		Rel Std Dev(%)	0.0000	
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	13:41																																																																																																																																																	
Control Test	0.048	13:42																																																																																																																																																	
Air Blank	0.000	13:42																																																																																																																																																	
Control Test	0.048	13:43																																																																																																																																																	
Air Blank	0.000	13:44																																																																																																																																																	
Control Test	0.048	13:44																																																																																																																																																	
Air Blank	0.000	13:45																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0480																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	13:47																																																																																																																																																	
Control Test	0.076	13:47																																																																																																																																																	
Air Blank	0.000	13:48																																																																																																																																																	
Control Test	0.075	13:48																																																																																																																																																	
Air Blank	0.000	13:49																																																																																																																																																	
Control Test	0.076	13:49																																																																																																																																																	
Air Blank	0.000	13:50																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0757																																																																																																																																																		
Std Dev	0.0016																																																																																																																																																		
Rel Std Dev(%)	0.7633																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	13:51																																																																																																																																																	
Control Test	0.195	13:52																																																																																																																																																	
Air Blank	0.000	13:53																																																																																																																																																	
Control Test	0.194	13:53																																																																																																																																																	
Air Blank	0.000	13:54																																																																																																																																																	
Control Test	0.194	13:55																																																																																																																																																	
Air Blank	0.000	13:55																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.1943																																																																																																																																																		
Std Dev	0.0036																																																																																																																																																		
Rel Std Dev(%)	0.2571																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	13:17																																																																																																																																																	
Control Test	0.078	13:18																																																																																																																																																	
Air Blank	0.000	13:18																																																																																																																																																	
Control Test	0.078	13:18																																																																																																																																																	
Air Blank	0.000	13:19																																																																																																																																																	
Control Test	0.078	13:19																																																																																																																																																	
Air Blank	0.000	13:20																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0780																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		
<i>newp</i> Operator's Signature	<i>newp</i> Operator's Signature	<i>newp</i> Operator's Signature	<i>newp</i> Operator's Signature																																																																																																																																																

WAKULLA COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000962
08/26/2026 09:15:28

Auto Calibration

pg 1 of 2

<<<<< 3um >>>>> <<<<< 9um >>>>>

Solution = 0.000 g/210L or 0.0000 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	0.1060	(-0.0050)	0.1450	(-0.0150)
Sample #2	0.0730	(0.0850)	0.1370	(0.0310)
Sample #3	0.0910	(0.1400)	0.1140	(0.0510)
Sample #4	0.0750	(0.1840)	0.1350	(0.0540)
Avg % Abs	0.0797	(0.1363)	0.1287	(0.0453)
STD DEV	0.0099	(0.0496)	0.0127	(0.0125)
REL STD DEV	12.384	(36.383)	9.902	(27.581)

Solution = 0.040 g/210L or 0.1905 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	0.7500	(-0.0070)	1.5500	(0.0110)
Sample #2	0.7490	(0.0100)	1.5370	(0.0170)
Sample #3	0.7450	(0.0300)	1.5440	(0.0210)
Sample #4	0.7260	(0.0590)	1.5380	(0.0370)
Avg % Abs	0.7400	(0.0330)	1.5397	(0.0250)
STD DEV	0.0123	(0.0246)	0.0038	(0.0106)
REL STD DEV	1.661	(74.659)	0.246	(42.332)

Solution = 0.100 g/210L or 0.4762 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	1.7030	(-0.0100)	3.5660	(-0.0080)
Sample #2	1.7140	(-0.0060)	3.6090	(-0.0130)
Sample #3	1.7160	(0.0080)	3.5850	(0.0040)
Sample #4	1.7170	(0.0330)	3.5850	(0.0080)
Avg % Abs	1.7157	(0.0117)	3.5930	(-0.0003)
STD DEV	0.0015	(0.0198)	0.0139	(0.0112)
REL STD DEV	0.089	(169.344)	0.386	(3345.145)

Solution = 0.200 g/210L or 0.9524 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	3.3520	(-0.0110)	6.8890	(-0.0080)
Sample #2	3.3270	(0.0140)	6.8520	(0.0130)
Sample #3	3.3390	(0.0170)	6.8740	(0.0090)
Sample #4	3.3230	(0.0490)	6.8680	(0.0180)
Avg % Abs	3.3297	(0.0267)	6.8647	(0.0133)
STD DEV	0.0083	(0.0194)	0.0114	(0.0045)
REL STD DEV	0.250	(72.747)	0.166	(33.819)

Solution = 0.300 g/210L or 1.4286 mg/l, Samples = 4, Discarded = 1

Sample	% Abs	(% Abs Ref)	% Abs	(% Abs Ref)
Sample #1	4.9140	(-0.0130)	9.9590	(-0.0020)
Sample #2	4.9010	(0.0030)	9.9570	(0.0000)
Sample #3	4.8940	(0.0070)	9.9690	(0.0020)
Sample #4	4.8870	(0.0140)	9.9520	(0.0000)
Avg % Abs	4.8940	(0.0080)	9.9593	(0.0007)
STD DEV	0.0070	(0.0056)	0.0087	(0.0012)
REL STD DEV	0.143	(69.597)	0.088	(173.205)

WAKULLA COUNTY SO
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000962
08/26/2026 09:15:28

Auto Calibration

pg 2 of 2

<<<< 3um >>>>			<<<< 9um >>>>		
-----			-----		
Zero Order Coef	-224.35			-169.03	
First Order Coef	2863.05			1326.68	
Second Order Coef	20.61			12.50	
-----			-----		
Act	Fit	Residual	Act	Fit	Residual
(g/210L)	(g/210L)	(g/210L)	(g/210L)	(g/210L)	(g/210L)
0.000	0.000	-0.0001	0.000	0.000	-0.0000
0.040	0.040	-0.0000	0.040	0.040	0.0000
0.100	0.100	0.0003	0.100	0.100	0.0001
0.200	0.200	-0.0003	0.200	0.200	-0.0001
0.300	0.300	0.0001	0.300	0.300	0.0000
-----			-----		

<<<< 3um >>>>		<<<< 9um >>>>	
-----		-----	
Solution = 0.080 g/210L or 0.3810 mg/l, Samples = 4, Discarded = 1			
Sample			
Sample #1	3500.00		3455.00
Sample #2	3388.00		3403.00
Sample #3	3424.00		3405.00
Sample #4	3398.00		3396.00
Avg	3403.3333		3401.3333
STD DEV	18.5831		4.7258
REL STD DEV	0.546		0.139
H2O adjust (mg/l*10k)	406		408

Barometric Pressure = 1012

*****CALIBRATION SUCCESSFUL*****

may
8/26/2026

Post-Cal Stability Checks

0.05g/210L 0.047 to 0.053	0.08g/210L 0.077 to 0.083	0.20g/210L 0.194 to 0.206	DGS 0.08g/210L 0.077 to 0.083																																																																																																																																				
WAKULLA COUNTY SO Intoxilizer - Alcohol Analyzer Model: 8000 08/26/2026 Software: 8100.27 SN 80-000962 Test 9/21/24 Time <table border="1"> <tr><td>Air Blank</td><td>0.000</td><td>10:55</td></tr> <tr><td>Control Test</td><td>0.049</td><td>10:56</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:57</td></tr> <tr><td>Control Test</td><td>0.050</td><td>10:57</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:58</td></tr> <tr><td>Control Test</td><td>0.049</td><td>10:59</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:59</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0493</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>1.1703</td><td></td></tr> </table> Operator's Signature <i>mary</i>	Air Blank	0.000	10:55	Control Test	0.049	10:56	Air Blank	0.000	10:57	Control Test	0.050	10:57	Air Blank	0.000	10:58	Control Test	0.049	10:59	Air Blank	0.000	10:59	Control Test Stats			Average	0.0493		Std Dev	0.0006		Rel Std Dev(%)	1.1703		WAKULLA COUNTY SO Intoxilizer - Alcohol Analyzer Model: 8000 08/26/2026 Software: 8100.27 SN 80-000962 Test 9/21/24 Time <table border="1"> <tr><td>Air Blank</td><td>0.000</td><td>11:10</td></tr> <tr><td>Control Test</td><td>0.078</td><td>11:10</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:11</td></tr> <tr><td>Control Test</td><td>0.078</td><td>11:11</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:12</td></tr> <tr><td>Control Test</td><td>0.078</td><td>11:13</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:13</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0780</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </table> Operator's Signature <i>mary</i>	Air Blank	0.000	11:10	Control Test	0.078	11:10	Air Blank	0.000	11:11	Control Test	0.078	11:11	Air Blank	0.000	11:12	Control Test	0.078	11:13	Air Blank	0.000	11:13	Control Test Stats			Average	0.0780		Std Dev	0.0000		Rel Std Dev(%)	0.0000		WAKULLA COUNTY SO Intoxilizer - Alcohol Analyzer Model: 8000 08/26/2026 Software: 8100.27 SN 80-000962 Test 9/21/24 Time <table border="1"> <tr><td>Air Blank</td><td>0.000</td><td>11:00</td></tr> <tr><td>Control Test</td><td>0.198</td><td>11:01</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:01</td></tr> <tr><td>Control Test</td><td>0.197</td><td>11:02</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:03</td></tr> <tr><td>Control Test</td><td>0.198</td><td>11:03</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>11:04</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.1977</td><td></td></tr> <tr><td>Std Dev</td><td>0.0016</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.2921</td><td></td></tr> </table> Operator's Signature <i>mary</i>	Air Blank	0.000	11:00	Control Test	0.198	11:01	Air Blank	0.000	11:01	Control Test	0.197	11:02	Air Blank	0.000	11:03	Control Test	0.198	11:03	Air Blank	0.000	11:04	Control Test Stats			Average	0.1977		Std Dev	0.0016		Rel Std Dev(%)	0.2921		WAKULLA COUNTY SO Intoxilizer - Alcohol Analyzer Model: 8000 08/26/2026 Software: 8100.27 SN 80-000962 Test 9/21/24 Time <table border="1"> <tr><td>Air Blank</td><td>0.000</td><td>10:24</td></tr> <tr><td>Control Test</td><td>0.080</td><td>10:24</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:25</td></tr> <tr><td>Control Test</td><td>0.080</td><td>10:25</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:26</td></tr> <tr><td>Control Test</td><td>0.080</td><td>10:26</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:26</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0800</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </table> Operator's Signature <i>mary</i>	Air Blank	0.000	10:24	Control Test	0.080	10:24	Air Blank	0.000	10:25	Control Test	0.080	10:25	Air Blank	0.000	10:26	Control Test	0.080	10:26	Air Blank	0.000	10:26	Control Test Stats			Average	0.0800		Std Dev	0.0000		Rel Std Dev(%)	0.0000	
Air Blank	0.000	10:55																																																																																																																																					
Control Test	0.049	10:56																																																																																																																																					
Air Blank	0.000	10:57																																																																																																																																					
Control Test	0.050	10:57																																																																																																																																					
Air Blank	0.000	10:58																																																																																																																																					
Control Test	0.049	10:59																																																																																																																																					
Air Blank	0.000	10:59																																																																																																																																					
Control Test Stats																																																																																																																																							
Average	0.0493																																																																																																																																						
Std Dev	0.0006																																																																																																																																						
Rel Std Dev(%)	1.1703																																																																																																																																						
Air Blank	0.000	11:10																																																																																																																																					
Control Test	0.078	11:10																																																																																																																																					
Air Blank	0.000	11:11																																																																																																																																					
Control Test	0.078	11:11																																																																																																																																					
Air Blank	0.000	11:12																																																																																																																																					
Control Test	0.078	11:13																																																																																																																																					
Air Blank	0.000	11:13																																																																																																																																					
Control Test Stats																																																																																																																																							
Average	0.0780																																																																																																																																						
Std Dev	0.0000																																																																																																																																						
Rel Std Dev(%)	0.0000																																																																																																																																						
Air Blank	0.000	11:00																																																																																																																																					
Control Test	0.198	11:01																																																																																																																																					
Air Blank	0.000	11:01																																																																																																																																					
Control Test	0.197	11:02																																																																																																																																					
Air Blank	0.000	11:03																																																																																																																																					
Control Test	0.198	11:03																																																																																																																																					
Air Blank	0.000	11:04																																																																																																																																					
Control Test Stats																																																																																																																																							
Average	0.1977																																																																																																																																						
Std Dev	0.0016																																																																																																																																						
Rel Std Dev(%)	0.2921																																																																																																																																						
Air Blank	0.000	10:24																																																																																																																																					
Control Test	0.080	10:24																																																																																																																																					
Air Blank	0.000	10:25																																																																																																																																					
Control Test	0.080	10:25																																																																																																																																					
Air Blank	0.000	10:26																																																																																																																																					
Control Test	0.080	10:26																																																																																																																																					
Air Blank	0.000	10:26																																																																																																																																					
Control Test Stats																																																																																																																																							
Average	0.0800																																																																																																																																						
Std Dev	0.0000																																																																																																																																						
Rel Std Dev(%)	0.0000																																																																																																																																						

Florida Department of Law Enforcement

Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: WAKULLA COUNTY SO
Time of Inspection: 13:55

Date of Inspection: 08/26/2026

Serial Number: 80-000962
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202603A Exp: 03/03/2028	0.08g/210L Test (g/210L) Lot#:202603B Exp: 03/03/2028	0.20g/210L Test (g/210L) Lot#:202603D Exp: 03/04/2028	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:23725080A1 Exp: 10/05/2027
0.000	0.049	0.078	0.196	0.080
0.000	0.049	0.077	0.196	0.080
0.000	0.049	0.078	0.197	0.080
0.000	0.049	0.077	0.197	0.079
0.000	0.049	0.077	0.197	0.080
0.000	0.049	0.078	0.197	0.079
0.000	0.049	0.078	0.197	0.079
0.000	0.049	0.078	0.198	0.079
0.000	0.050	0.078	0.198	0.079
0.000	0.049	0.078	0.197	0.079

Standard Deviations	0.0003	0.0004	0.0006	0.0005
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0004 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



WEN-CHI K PIERSON
Signature and Printed Name

08/26/2026
Date

Florida Department of Law Enforcement
Alcohol Testing Program - Average Calculations for Calibration Certificate

Calculations By: WKP

Serial Number: 80-000962

Date: 8/27/2026

Solution:

0.05 g/210 L Test: 0.491 / 10 = 0.049 g/210L
(SUM) (AVERAGE)

0.08 g/210L Test: 0.777 / 10 = 0.078 g/210L
(SUM) (AVERAGE)

0.20 g/210L Test: 1.970 / 10 = 0.197 g/210L
(SUM) (AVERAGE)

0.08 g/210L Dry Gas Std Test: 0.794 / 10 = 0.079 g/210L
(SUM) (AVERAGE)

Comments:

Average = (Sum of observations) / (Total number of observations)

All results are reported in g/210L



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000962, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000962</u>	Average of y $\pm$ Uncertainty*
Owning Agency:	<u>WAKULLA COUNTY SO</u>	0.049 g/ 210 L 0.004
Calibration Date:	<u>08/26/2026</u>	0.078 g/ 210 L 0.004
Calibration Time:	<u>13:55</u>	0.197 g/ 210 L 0.008
		0.079 g/ 210 L Dry Gas Control 0.005

All results are reported in g/210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence (k=3).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Wen-Chi

Pierson

Chi Pierson

Date: 2026.08.27 11:58:43
-04'00'

Date

08/26/2026

WEN-CHI K PIERSON,

Department Inspector

FDLE/ATP Form 69 August 2026

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality