

Alcohol Testing Program - Instrument Processing Sheet

Agency: Hillsborough County SO

Instrument Serial Number: 80-000830

Date In: 6/9/2026

DI Completion Date: 6/17/26

☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake By: SLH Date: 6/9/2026		Quality Checks By: KTS Date: 6/10/2026		Flow Adjustment By: _____																																				
☒ Annual ☐ Dropped Off ☐ Registration ☐ Return from CMI / EE ☐ Training Instrument Visual Inspection ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/Accessories ☐ Power Cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes:		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value: 215 ☒ Flow Verification (L/s) Flow Column #: ATP103 32 mm 0.156 (.139-.169) 36 mm 0.171 (.156-.190) 53 mm 0.246 (.228-.278) 103 mm 0.515 (.447-.547) ☒ Barometric Pressure Check Gauge ID #: 28427 Gauge: 1014 Instrument: 1014 ☒ Stability Checks		Flow Column #: _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value: _____ ☐ Post Adjustment Verification (L/S) Flow Column #: _____ 32 mm (.139-.169) 36 mm (.156-.190) 53 mm (.228-.278) 103 mm (.447-.547)																																				
						<table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot#/Exp</th> <th>Maintenance By:</th> <th>Date:</th> </tr> </thead> <tbody> <tr> <td rowspan="2">0.050</td> <td rowspan="2">MP5088</td> <td>202603A</td> <td>☐ Battery Replacement</td> <td rowspan="2"></td> </tr> <tr> <td>3/3/2028</td> <td>☐ Dry Gas Regulator Replacement</td> </tr> <tr> <td rowspan="2">0.080</td> <td rowspan="2">MP5089</td> <td>202603B</td> <td>☐ Tank Sensor Tare</td> <td rowspan="2"></td> </tr> <tr> <td>3/3/2028</td> <td>☐ Breath Tube Replacement</td> </tr> <tr> <td rowspan="2">0.200</td> <td rowspan="2">MP5090</td> <td>202603D</td> <td>☐ Other:</td> <td rowspan="2"></td> </tr> <tr> <td>3/4/2028</td> <td></td> </tr> <tr> <td rowspan="2">0.080 DGS</td> <td rowspan="2">N/A</td> <td>23825080A1</td> <td></td> <td rowspan="2"></td> </tr> <tr> <td>10/5/2027</td> <td></td> </tr> </tbody> </table>		Simulator	Serial #	Lot#/Exp	Maintenance By:	Date:	0.050	MP5088	202603A	☐ Battery Replacement		3/3/2028	☐ Dry Gas Regulator Replacement	0.080	MP5089	202603B	☐ Tank Sensor Tare		3/3/2028	☐ Breath Tube Replacement	0.200	MP5090	202603D	☐ Other:		3/4/2028		0.080 DGS	N/A	23825080A1			10/5/2027	
						Simulator	Serial #	Lot#/Exp	Maintenance By:	Date:																														
						0.050	MP5088	202603A	☐ Battery Replacement																															
								3/3/2028	☐ Dry Gas Regulator Replacement																															
0.080	MP5089	202603B	☐ Tank Sensor Tare																																					
		3/3/2028	☐ Breath Tube Replacement																																					
0.200	MP5090	202603D	☐ Other:																																					
		3/4/2028																																						
0.080 DGS	N/A	23825080A1																																						
		10/5/2027																																						
<table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td>MP6294</td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td>MP6295</td> <td>25090</td> <td>3/11/2027</td> </tr> <tr> <td>0.100</td> <td>MP6296</td> <td>25282</td> <td>8/12/2027</td> </tr> <tr> <td>0.200</td> <td>MP6297</td> <td>25020</td> <td>1/14/2027</td> </tr> <tr> <td>0.300</td> <td>MP6298</td> <td>25150</td> <td>5/6/2027</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>AG510701</td> <td>4/17/2027</td> </tr> </tbody> </table>		Simulator	Serial #	Lot #	Expiration	0.000	MP6294	N/A	N/A	0.040	MP6295	25090	3/11/2027	0.100	MP6296	25282	8/12/2027	0.200	MP6297	25020	1/14/2027	0.300	MP6298	25150	5/6/2027	0.080 DGS	N/A	AG510701	4/17/2027	Department Inspection By: KTS Barometric Pressure Gauge: 1011 ID#: 34420 Barometric Pressure ID#: 28427* Gauge: 1011 / 1009 Instrument: 1012 / 1010 Mouth Alcohol Solution Lot #: 2025-D* Exp: 9/25/2027 Acetone Stock Solution Lot #: 2025-B* Exp: 9/22/2027										
Simulator	Serial #	Lot #	Expiration																																					
0.000	MP6294	N/A	N/A																																					
0.040	MP6295	25090	3/11/2027																																					
0.100	MP6296	25282	8/12/2027																																					
0.200	MP6297	25020	1/14/2027																																					
0.300	MP6298	25150	5/6/2027																																					
0.080 DGS	N/A	AG510701	4/17/2027																																					
☒ Post Optical Bench Adjustment Stability Checks <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>Simulator</th> <th>Serial #</th> <th>Lot #</th> <th>Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>MP5088</td> <td>202603A</td> <td>3/3/2028</td> </tr> <tr> <td>0.080</td> <td>MP5089</td> <td>202603B</td> <td>3/3/2028</td> </tr> <tr> <td>0.200</td> <td>MP5090</td> <td>202603D</td> <td>3/4/2028</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>23825080A1</td> <td>10/5/2027</td> </tr> </tbody> </table>		Simulator	Serial #	Lot #	Expiration	0.050	MP5088	202603A	3/3/2028	0.080	MP5089	202603B	3/3/2028	0.200	MP5090	202603D	3/4/2028	0.080 DGS	N/A	23825080A1	10/5/2027	<table border="1" style="width:100%; border-collapse: collapse;"> <tbody> <tr> <td>0.000</td> <td>MP5086 / MP6289</td> </tr> <tr> <td>0.050</td> <td>MP5087 *</td> </tr> <tr> <td>0.080</td> <td>MP5088 *</td> </tr> <tr> <td>0.200</td> <td>MP5089 *</td> </tr> <tr> <td>0.200</td> <td>MP5090 *</td> </tr> </tbody> </table>		0.000	MP5086 / MP6289	0.050	MP5087 *	0.080	MP5088 *	0.200	MP5089 *	0.200	MP5090 *							
Simulator	Serial #	Lot #	Expiration																																					
0.050	MP5088	202603A	3/3/2028																																					
0.080	MP5089	202603B	3/3/2028																																					
0.200	MP5090	202603D	3/4/2028																																					
0.080 DGS	N/A	23825080A1	10/5/2027																																					
0.000	MP5086 / MP6289																																							
0.050	MP5087 *																																							
0.080	MP5088 *																																							
0.200	MP5089 *																																							
0.200	MP5090 *																																							
Gauge ID #: 28427 Gauge: 1011 Instrument: 1013		Attachments ☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☒ Optical Bench Adjustment		☒ Post-Stability Checks ☐ Flow Adjustment ☐ Form 40 ☐ Other:																																				
Notes/Suggested Service: Conducted DI before post-stability checks. Performed post-stabilities and second DI. KTS 6/17/26 * indicates the same serial number used for equipment for the second department inspection and solution lot numbers. KTS 6/17/26 Tech Review: added initials and pressure gauge value, Corrected stability concentration, KTS 6/22/26		☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use																																						
		<table style="width:100%;"> <tr> <td style="width: 50%;"> Wen-Chi Pierson Digitally signed by Wen-Chi Pierson Date: 2026.06.30 14:52:54 -04'00' </td> <td style="width: 50%;"> Taylor Gutschow Digitally signed by Taylor Gutschow Date: 2026.08.03 10:56:34 -04'00' </td> </tr> </table>				Wen-Chi Pierson Digitally signed by Wen-Chi Pierson Date: 2026.06.30 14:52:54 -04'00'	Taylor Gutschow Digitally signed by Taylor Gutschow Date: 2026.08.03 10:56:34 -04'00'																																	
		Wen-Chi Pierson Digitally signed by Wen-Chi Pierson Date: 2026.06.30 14:52:54 -04'00'	Taylor Gutschow Digitally signed by Taylor Gutschow Date: 2026.08.03 10:56:34 -04'00'																																					
<table style="width:100%;"> <tr> <td style="width: 50%; text-align: center;">Tech Review</td> <td style="width: 50%; text-align: center;">Admin Review</td> </tr> </table>				Tech Review	Admin Review																																			
Tech Review	Admin Review																																							

Stability Checks

0.050 g/210L	0.080 g/210L	0.200 g/210L	DGS 0.080 g/210L
0.047 to 0.053 g/210L	0.077 to 0.083 g/210L	0.194 to 0.206 g/210L	0.077 to 0.083 g/210L ≤ 0.003 g/210L of Wet

HILLBOROUGH CO 50 Intoxilyzer - Alcotest Analyzer Model 8000 05/10/2026 Software: 8100.27 Test g/210L Time Air Blank 0.000 09:35 Control Test 0.046 09:35 Air Blank 0.000 09:36 Control Test 0.048 09:37 Air Blank 0.000 09:37 Control Test 0.048 09:38 Air Blank 0.000 09:38 Control Test Stats Average 0.0480 Std Dev 0.0000 Rel Std Dev(%) 0.0000 <i>Katz</i> Operator's Signature	HILLBOROUGH CO 50 Intoxilyzer - Alcotest Analyzer Model 8000 06/10/2026 Software: 8100.27 Test g/210L Time Air Blank 0.000 09:40 Control Test 0.078 09:41 Air Blank 0.000 09:41 Control Test 0.000 09:42 Air Blank 0.000 09:43 Control Test 0.077 09:43 Air Blank 0.000 09:44 Control Test Stats Average 0.0773 Std Dev 0.0006 Rel Std Dev(%) 0.7465 <i>Katz</i> Operator's Signature	HILLBOROUGH CO 50 Intoxilyzer - Alcotest Analyzer Model 8000 06/10/2026 Software: 8100.27 Test g/210L Time Air Blank 0.000 09:45 Control Test 0.199 09:46 Air Blank 0.000 09:46 Control Test 0.200 09:47 Air Blank 0.000 09:48 Control Test 0.200 09:48 Air Blank 0.000 09:49 Control Test Stats Average 0.1997 Std Dev 0.0006 Rel Std Dev(%) 0.2892 <i>Katz</i> Operator's Signature	HILLBOROUGH CO 50 Intoxilyzer - Alcotest Analyzer Model 8000 06/10/2026 Software: 8100.27 Test g/210L Time Air Blank 0.000 09:31 Control Test 0.079 09:32 Air Blank 0.000 09:32 Control Test 0.078 09:32 Air Blank 0.000 09:33 Control Test 0.077 09:33 Air Blank 0.000 09:33 Control Test Stats Average 0.0780 Std Dev 0.0010 Rel Std Dev(%) 1.2821 <i>Katz</i> Operator's Signature
---	---	---	---

088000-08

80-000830

Conducted additional
stabilities on ^{0.080* KTS 6/22/26}~~0.050~~ g/210L
wet to attempt to
reproduce AI's reported
issue. KTS 6/10/26

HILLSBOROUGH CO SO
Intoxilyzer - Alcohol Analyzer
Model: 8100 SN 60-000630
06/10/2026
Software: 8100.27

Test	g/210L	Time
Air Blank	0.000	12:21
Control Test	0.077	12:21
Air Blank	0.000	12:21
Control Test	0.076	12:22
Air Blank	0.000	12:22
Control Test	0.076	12:23
Air Blank	0.000	12:24
Control Test	0.077	12:24
Air Blank	0.000	12:25
Control Test	0.077	12:25
Air Blank	0.000	12:26
Control Test	0.077	12:27
Air Blank	0.000	12:27
Control Test	0.077	12:28
Air Blank	0.000	12:29
Control Test	0.076	12:29
Air Blank	0.000	12:30
Control Test	0.076	12:31
Air Blank	0.000	12:31
Control Test	0.077	12:32
Air Blank	0.000	12:32
Control Test State		
Average	0.0766	
Std Dev	0.0035	
Rel Std Dev(%)	0.6741	


Operator's Signature

```
Dry Gas H2O Adjust Results *****
Barometric Pressure = 1013
3 um H2O Adjust (mg/L*10,000) = 528
9 um H2O Adjust (mg/L*10,000) = 564
**** AUTO CAL PASS
```

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: HILLSBOROUGH CO SO
Time of Inspection: 12:06

Date of Inspection: 06/11/2026

Serial Number: 80-000830
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	


Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202603A Exp: 03/03/2028	0.08g/210L Test (g/210L) Lot#:202603B Exp: 03/03/2028	0.20g/210L Test (g/210L) Lot#:202603D Exp: 03/04/2028	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:23825080A1 Exp: 10/05/2027
0.000	0.049	0.078	0.199	0.081
0.000	0.049	0.077	0.199	0.081
0.000	0.049	0.078	0.199	0.081
0.000	0.050	0.077	0.199	0.080
0.000	0.050	0.077	0.199	0.080
0.000	0.049	0.077	0.199	0.080
0.000	0.050	0.078	0.200	0.080
0.000	0.049	0.078	0.200	0.080
0.000	0.050	0.078	0.200	0.080
0.000	0.050	0.078	0.200	0.080
Standard Deviations	0.0005	0.0005	0.0005	0.0004

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0004 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



KATIE T SPEARIN
Signature and Printed Name

06/11/2026
Date

Post-Optical

Adjustment

Stability Checks

0.050 g/210L 0.047 to 0.053 g/210L	0.080 g/210L 0.077 to 0.083 g/210L	0.200 g/210L 0.194 to 0.206 g/210L	DGS 0.080 g/210L 0.077 to 0.083 g/210L ≤ 0.003 g/210L of Wet																																																																																																																																																
HILLSBOROUGH CO SO Intoxilyzer - Alcohol Analyzer Model: 8000 06/12/2026 Software: 8100.27 Test <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>18:33</td></tr> <tr><td>Control Test</td><td>0.050</td><td>18:34</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>18:34</td></tr> <tr><td>Control Test</td><td>0.050</td><td>18:35</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>18:36</td></tr> <tr><td>Control Test</td><td>0.050</td><td>18:36</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>18:37</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0500</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </tbody> </table> Operator's Signature	Test	g/210L	Time	Air Blank	0.000	18:33	Control Test	0.050	18:34	Air Blank	0.000	18:34	Control Test	0.050	18:35	Air Blank	0.000	18:36	Control Test	0.050	18:36	Air Blank	0.000	18:37	Control Test Stats			Average	0.0500		Std Dev	0.0000		Rel Std Dev(%)	0.0000		HILLSBOROUGH CO SO Intoxilyzer - Alcohol Analyzer Model: 8000 06/12/2026 Software: 8100.27 Test <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>18:38</td></tr> <tr><td>Control Test</td><td>0.078</td><td>18:39</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>18:40</td></tr> <tr><td>Control Test</td><td>0.079</td><td>18:41</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>18:41</td></tr> <tr><td>Control Test</td><td>0.079</td><td>18:42</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>18:42</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0787</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.7339</td><td></td></tr> </tbody> </table> Operator's Signature	Test	g/210L	Time	Air Blank	0.000	18:38	Control Test	0.078	18:39	Air Blank	0.000	18:40	Control Test	0.079	18:41	Air Blank	0.000	18:41	Control Test	0.079	18:42	Air Blank	0.000	18:42	Control Test Stats			Average	0.0787		Std Dev	0.0006		Rel Std Dev(%)	0.7339		HILLSBOROUGH CO SO Intoxilyzer - Alcohol Analyzer Model: 8000 06/12/2026 Software: 8100.27 Test <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>18:44</td></tr> <tr><td>Control Test</td><td>0.198</td><td>18:45</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>18:45</td></tr> <tr><td>Control Test</td><td>0.199</td><td>18:46</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>18:46</td></tr> <tr><td>Control Test</td><td>0.199</td><td>18:47</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>18:48</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.1983</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.2911</td><td></td></tr> </tbody> </table> Operator's Signature	Test	g/210L	Time	Air Blank	0.000	18:44	Control Test	0.198	18:45	Air Blank	0.000	18:45	Control Test	0.199	18:46	Air Blank	0.000	18:46	Control Test	0.199	18:47	Air Blank	0.000	18:48	Control Test Stats			Average	0.1983		Std Dev	0.0006		Rel Std Dev(%)	0.2911		HILLSBOROUGH CO SO Intoxilyzer - Alcohol Analyzer Model: 8000 06/12/2026 Software: 8100.27 Test <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>18:27</td></tr> <tr><td>Control Test</td><td>0.081</td><td>18:27</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>18:28</td></tr> <tr><td>Control Test</td><td>0.079</td><td>18:28</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>18:29</td></tr> <tr><td>Control Test</td><td>0.079</td><td>18:29</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>18:30</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0797</td><td></td></tr> <tr><td>Std Dev</td><td>0.0012</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>1.4494</td><td></td></tr> </tbody> </table> Operator's Signature	Test	g/210L	Time	Air Blank	0.000	18:27	Control Test	0.081	18:27	Air Blank	0.000	18:28	Control Test	0.079	18:28	Air Blank	0.000	18:29	Control Test	0.079	18:29	Air Blank	0.000	18:30	Control Test Stats			Average	0.0797		Std Dev	0.0012		Rel Std Dev(%)	1.4494	
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	18:33																																																																																																																																																	
Control Test	0.050	18:34																																																																																																																																																	
Air Blank	0.000	18:34																																																																																																																																																	
Control Test	0.050	18:35																																																																																																																																																	
Air Blank	0.000	18:36																																																																																																																																																	
Control Test	0.050	18:36																																																																																																																																																	
Air Blank	0.000	18:37																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0500																																																																																																																																																		
Std Dev	0.0000																																																																																																																																																		
Rel Std Dev(%)	0.0000																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	18:38																																																																																																																																																	
Control Test	0.078	18:39																																																																																																																																																	
Air Blank	0.000	18:40																																																																																																																																																	
Control Test	0.079	18:41																																																																																																																																																	
Air Blank	0.000	18:41																																																																																																																																																	
Control Test	0.079	18:42																																																																																																																																																	
Air Blank	0.000	18:42																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0787																																																																																																																																																		
Std Dev	0.0006																																																																																																																																																		
Rel Std Dev(%)	0.7339																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	18:44																																																																																																																																																	
Control Test	0.198	18:45																																																																																																																																																	
Air Blank	0.000	18:45																																																																																																																																																	
Control Test	0.199	18:46																																																																																																																																																	
Air Blank	0.000	18:46																																																																																																																																																	
Control Test	0.199	18:47																																																																																																																																																	
Air Blank	0.000	18:48																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.1983																																																																																																																																																		
Std Dev	0.0006																																																																																																																																																		
Rel Std Dev(%)	0.2911																																																																																																																																																		
Test	g/210L	Time																																																																																																																																																	
Air Blank	0.000	18:27																																																																																																																																																	
Control Test	0.081	18:27																																																																																																																																																	
Air Blank	0.000	18:28																																																																																																																																																	
Control Test	0.079	18:28																																																																																																																																																	
Air Blank	0.000	18:29																																																																																																																																																	
Control Test	0.079	18:29																																																																																																																																																	
Air Blank	0.000	18:30																																																																																																																																																	
Control Test Stats																																																																																																																																																			
Average	0.0797																																																																																																																																																		
Std Dev	0.0012																																																																																																																																																		
Rel Std Dev(%)	1.4494																																																																																																																																																		

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: HILLSBOROUGH CO SO
Time of Inspection: 12:07

Date of Inspection: 06/17/2026

Serial Number: 80-000830
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202603A Exp: 03/03/2026	0.08g/210L Test (g/210L) Lot#:202603B Exp: 03/03/2026	0.20g/210L Test (g/210L) Lot#:202603D Exp: 03/04/2026	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:23825080A1 Exp: 10/05/2027
0.000	0.049	0.078	0.198	0.081
0.000	0.049	0.078	0.198	0.081
0.000	0.050	0.078	0.198	0.081
0.000	0.050	0.078	0.199	0.080
0.000	0.049	0.079	0.199	0.081
0.000	0.050	0.079	0.199	0.080
0.000	0.050	0.079	0.199	0.080
0.000	0.050	0.079	0.199	0.080
0.000	0.050	0.079	0.199	0.080
0.000	0.050	0.079	0.200	0.081

Standard Deviations	0.0004	0.0005	0.0006	0.0005
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0005 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

 KATIE T SPEARIN
Signature and Printed Name

06/17/2026
Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000830, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000830</u>	UNCERTAINTY* $\pm$
Owning Agency:	<u>HILLSBOROUGH CO SO</u>	0.050 g/210 L 0.004
Calibration Date:	<u>06/17/2026</u>	0.080 g/210 L 0.004
Calibration Time:	<u>12:07</u>	0.200 g/210 L 0.008
		0.080 g/210 L Dry Gas Control 0.005

All results are reported in g/210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence (k=3).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/IEC 17025 standards. This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

Date

06/17/2026

Katie T Spearin
KATIE T SPEARIN,

Department Inspector

FDLE/ATP Form 69 January 2026

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

Alcohol Testing Program - Instrument Processing Sheet

Agency: Hillborough County SO

Instrument Serial Number: 80-000830

Date In: 2/19/2026

DI Completion Date: 2/26/2026

☒ Ship ☐ P/U ☐ H/D ☐ CMI ☐ EE

Intake By: <u>SLH</u> Date: <u>2/20/2026</u>		Quality Checks By: <u>KTS</u> Date: <u>2/25/2026</u>		Flow Adjustment By: _____																																																											
☒ Annual ☐ Dropped Off ☐ Registration ☒ Return from CMI / EE ☐ Training Instrument Visual Inspection ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/Accessories ☐ Power Cord ☐ Printer Cable ☒ Static Bag ☐ 12V DC Cable Notes:		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value: <u>211</u> ☒ Flow Verification (L/s) Flow Column #: <u>ATP103</u> 32 mm <u>0.152</u> (.139-.169) 36 mm <u>0.164</u> (.156-.190) 53 mm <u>0.238</u> (.228-.278) 103 mm <u>0.515</u> (.447-.547) ☒ Barometric Pressure Check Gauge ID #: <u>28421</u> Gauge: <u>1017</u> Instrument: <u>1014</u> ☒ Stability Checks		Flow Column #: _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value: _____ ☐ Post Adjustment Verification (L/S) Flow Column #: _____ 32 mm (.139-.169) 36 mm (.156-.190) 53 mm (.228-.278) 103 mm (.447-.547)																																																											
						<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Simulator</th> <th style="width: 20%;">Serial #</th> <th style="width: 25%;">Lot#/Exp</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td>MP5088</td> <td>202406K 6/19/2026</td> </tr> <tr> <td>0.080</td> <td>MP5089</td> <td>202406L 6/19/2026</td> </tr> <tr> <td>0.200</td> <td>MP5090</td> <td>202406N 6/20/2026</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td>28424080A3 11/5/2026</td> </tr> </tbody> </table>		Simulator	Serial #	Lot#/Exp	0.050	MP5088	202406K 6/19/2026	0.080	MP5089	202406L 6/19/2026	0.200	MP5090	202406N 6/20/2026	0.080 DGS	N/A	28424080A3 11/5/2026	Maintenance By: _____ Date: _____ ☐ Battery Replacement ☐ Dry Gas Regulator Replacement ☐ Tank Sensor Tare ☐ Breath Tube Replacement ☐ Other:																																								
						Simulator	Serial #	Lot#/Exp																																																							
						0.050	MP5088	202406K 6/19/2026																																																							
						0.080	MP5089	202406L 6/19/2026																																																							
0.200	MP5090	202406N 6/20/2026																																																													
0.080 DGS	N/A	28424080A3 11/5/2026																																																													
Optical Bench Adjustment By: _____ Barometric Pressure Gauge: _____ ID#: _____ <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Simulator</th> <th style="width: 20%;">Serial #</th> <th style="width: 25%;">Lot #</th> <th style="width: 20%;">Expiration</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> ☐ Post Optical Bench Adjustment Stability Checks <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Simulator</th> <th style="width: 20%;">Serial #</th> <th style="width: 25%;">Lot #</th> <th style="width: 20%;">Expiration</th> </tr> </thead> <tbody> <tr> <td>0.050</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> </tr> </tbody> </table> Gauge ID #: _____ Gauge: _____ Instrument: _____		Simulator	Serial #	Lot #	Expiration	0.000		N/A	N/A	0.040				0.100				0.200				0.300				0.080 DGS	N/A			Simulator	Serial #	Lot #	Expiration	0.050				0.080				0.200				0.080 DGS	N/A			Department Inspection By: <u>KTS</u> Barometric Pressure ID#: <u>28421</u> Gauge: <u>1013</u> Instrument: <u>1011</u> Mouth Alcohol Solution Lot #: <u>2025-D</u> Exp: <u>9/25/2027</u> Acetone Stock Solution Lot #: <u>2025-B</u> Exp: <u>9/22/2027</u> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Simulator</th> <th style="width: 50%;">Serial Number</th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td>MP5086</td> </tr> <tr> <td>Interferent</td> <td>MP5087</td> </tr> <tr> <td>0.050</td> <td>MP5088</td> </tr> <tr> <td>0.080</td> <td>MP5089</td> </tr> <tr> <td>0.200</td> <td>MP5090</td> </tr> </tbody> </table>		Simulator	Serial Number	0.000	MP5086	Interferent	MP5087	0.050	MP5088	0.080	MP5089	0.200	MP5090
Simulator	Serial #	Lot #	Expiration																																																												
0.000		N/A	N/A																																																												
0.040																																																															
0.100																																																															
0.200																																																															
0.300																																																															
0.080 DGS	N/A																																																														
Simulator	Serial #	Lot #	Expiration																																																												
0.050																																																															
0.080																																																															
0.200																																																															
0.080 DGS	N/A																																																														
Simulator	Serial Number																																																														
0.000	MP5086																																																														
Interferent	MP5087																																																														
0.050	MP5088																																																														
0.080	MP5089																																																														
0.200	MP5090																																																														
Notes/Suggested Service:		Attachments ☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Optical Bench Adjustment		☐ Post-Stability Checks ☐ Flow Adjustment ☐ Form 40 ☐ Other:																																																											
		☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use																																																													
		Digitally signed by Shayla Platt Date: 2026.03.06 13:13:57 -05'00'		Digitally signed by Shayla Platt Date: 2026.03.06 13:14:22 -05'00'																																																											
		Tech Review		Admin Review																																																											

Stability Checks

0.050 g/210L	0.080 g/210L	0.200 g/210L	DGS 0.080 g/210L
0.047 to 0.053 g/210L	0.077 to 0.083 g/210L	0.194 to 0.206 g/210L	0.077 to 0.083 g/210L
0.003 g/210L of Wet			
WILLSBOROUGH CO SC Intoxilyzer - Alcohol Analyzer Model: 8000 02/25/2026 Software: 8100.27 Test g/210L Time Air Blank 0.000 06:10 Control Test 0.148 06:11 Air Blank 0.000 06:11 Control Test 0.047 06:12 Air Blank 0.000 06:12 Control Test 0.047 06:13 Air Blank 0.000 06:14 Control Test Stats Average 0.0473 Std Dev 0.0006 Rel Std Dev(%) 1.2198	WILLSBOROUGH CO SC Intoxilyzer - Alcohol Analyzer Model: 8000 02/25/2026 Software: 8100.27 Test g/210L Time Air Blank 0.000 16:25 Control Test 0.078 16:26 Air Blank 0.000 16:26 Control Test 0.078 16:27 Air Blank 0.000 16:27 Control Test 0.078 16:28 Air Blank 0.000 16:29 Control Test Stats Average 0.0780 Std Dev 0.0000 Rel Std Dev(%) 0.0000	WILLSBOROUGH CO SC Intoxilyzer - Alcohol Analyzer Model: 8000 02/25/2026 Software: 8100.27 Test g/210L Time Air Blank 0.000 06:30 Control Test 0.200 06:30 Air Blank 0.000 06:31 Control Test 0.200 06:32 Air Blank 0.000 06:32 Control Test 0.200 06:33 Air Blank 0.000 06:33 Control Test Stats Average 0.2000 Std Dev 0.0000 Rel Std Dev(%) 0.0000	WILLSBOROUGH CO SC Intoxilyzer - Alcohol Analyzer Model: 8000 02/25/2026 Software: 8100.27 Test g/210L Time Air Blank 0.000 06:20 Control Test 0.081 06:20 Air Blank 0.000 06:20 Control Test 0.079 06:21 Air Blank 0.000 06:22 Control Test 0.080 06:22 Air Blank 0.000 06:23 Control Test Stats Average 0.0800 Std Dev 0.0010 Rel Std Dev(%) 1.2500
Performed Root Case Analysis	Performed Root Case Analysis	Performed Root Case Analysis	Performed Root Case Analysis
Operator's Signature	Operator's Signature	Operator's Signature	Operator's Signature

20-000830

Inadvertently hit Dry Stability

Test instead of wet.

Katz

2/25/26

HILLSBOROUGH CO. 50
Intoxilyzer - Alcohol Analyzer
Model 8000 SN 80-000830
02/25/2026
Software: 8100.27

Test	g/210L	Time
Air Blank	ABT*	08:24
Air Blank	0.000	08:24

*Sequence Aborted

Katz

Operator's Signature

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: HILLSBOROUGH CO SO
Time of Inspection: 08:33

Date of Inspection: 02/26/2026

Serial Number: 80-000830
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202406K Exp: 06/19/2026	0.08g/210L Test (g/210L) Lot#:202406L Exp: 06/19/2026	0.20g/210L Test (g/210L) Lot#:202406N Exp: 06/20/2026	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:28424080A3 Exp: 11/05/2026
0.000	0.046	0.077	0.200	0.081
0.000	0.047	0.077	0.201	0.081
0.000	0.047	0.077	0.200	0.081
0.000	0.047	0.077	0.201	0.080
0.000	0.047	0.077	0.200	0.080
0.000	0.047	0.077	0.200	0.080
0.000	0.047	0.077	0.200	0.080
0.000	0.047	0.077	0.200	0.080
0.000	0.047	0.077	0.200	0.080
0.000	0.047	0.077	0.201	0.080

Standard Deviations	0.0003	0.0000	0.0004	0.0004
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0002 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

KATIE T SPEARIN

Signature and Printed Name

02/26/2026
Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000830, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000830</u>	UNCERTAINTY* $\pm$
Owning Agency:	<u>HILLSBOROUGH CO SO</u>	0.050 g/ 210 L 0.004
Calibration Date:	<u>02/26/2026</u>	0.080 g/ 210 L 0.004
Calibration Time:	<u>08:33</u>	0.200 g/ 210 L 0.008
		0.080 g/ 210 L Dry Gas Control 0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

02/26/2026

Date

KATIE T SPEARIN,

Department Inspector

FDLE/ATP Form 69 January 2026

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality