

Alcohol Testing Program - Instrument Processing Sheet

Agency: Blountstown PD

Instrument Serial Number: 80-000862

Date In: 7/30/2026

DI Completion Date: 8/6/2026

☐ Ship ☒ P/U ☐ H/D ☐ CMI ☐ EE

Intake By: IAS Date: 7/30/2026				Quality Checks By: WKP Date: 8/6/2026				Flow Adjustment By: _____			
☒ Annual ☒ Dropped Off ☐ Registration ☐ Return from CMI / EE ☐ Training Instrument Visual Inspection ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/Accessories ☐ Power Cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes: Battery change requested. IAS 7/30/26				☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value: 141 ☒ Flow Verification (L/s) Flow Column #: ATP 105 32 mm 0.152 (.139-.169) 36 mm 0.171 (.156-.190) 53 mm 0.238 (.228-.278) 103 mm 0.503 (.447-.547) ☒ Barometric Pressure Check Gauge ID #: 28427 Gauge: 1017 Instrument: 1013 ☒ Stability Checks				Flow Column #: _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value: _____ ☐ Post Adjustment Verification (L/S) Flow Column #: _____ 32 mm (.139-.169) 36 mm (.156-.190) 53 mm (.228-.278) 103 mm (.447-.547)			
				Simulator		Serial #		Lot#/Exp		Maintenance By: WKP Date: 7/31/2026	
				0.050		MP6291		202603A 3/3/2028		☒ Battery Replacement	
				0.080		MP6292		202603B 3/3/2028		☐ Dry Gas Regulator Replacement	
				0.200		MP6293		202603D 3/4/2028		☐ Tank Sensor Tare	
0.080 DGS		N/A		23725080A1 10/5/2027		☐ Breath Tube Replacement					
Optical Bench Adjustment By: _____				Department Inspection By: WKP				☐ Other:			
Barometric Pressure Gauge: _____ ID#: _____				Barometric Pressure ID#: 28427							
Simulator		Serial #		Lot #		Expiration		Gauge: 1017 Instrument: 1013		Mouth Alcohol Solution Lot #: 2025-D Exp: 9/25/2027	
0.000				N/A		N/A		Acetone Stock Solution Lot #: 2025-B Exp: 9/22/2027			
0.040								Simulator		Serial Number	
0.100								0.000		MP6289	
0.200								Interferent		MP6290	
0.300								0.050		MP6291	
0.080 DGS		N/A						0.080		MP6292	
☐ Post Optical Bench Adjustment Stability Checks				Simulator		Serial #		Lot #		Expiration	
0.050								0.200		MP6293	
0.080								Attachments			
0.200								☒ Form 41		☐ Post-Stability Checks	
0.080 DGS		N/A						☒ Stability Checks		☐ Flow Adjustment	
Gauge ID #: _____				Gauge: _____ Instrument: _____				☒ Calibration Certificate			
								☐ Optical Bench Adjustment			
Notes/Suggested Service:				☒ Instrument Complies with Chapter 11D-8, FAC							
				☐ Instrument Does Not Comply with Chapter 11D-8, FAC							
				☒ Return to/Place into Evidentiary Use							
				☐ Remain Out of Evidentiary Use							
				☒ Conduct an Agency Inspection Before Evidentiary Use							
				LeAndra Higginbotham Date: 2026.08.10 09:26:39 -04'00'				Kaitlyn Spearin Date: 2026.08.10 12:57:52 -04'00'			
				Tech Review				Admin Review			

Florida Department of Law Enforcement

Alcohol Testing Program

AGENCY INSPECTION REPORT - INTOXILYZER 8000

Agency: BLOUNTSTOWN PD
Time of Inspection: 08:59

Date of Inspection: 08/06/2026

Serial Number: 80-000862
Software: 8100.27

Check or Test	YES	NO
Date and/or Time Adjusted		No
Diagnostic Check (Pre-Inspection): OK		No
Alcohol Free Subject Test: 0.000		No
Mouth Alcohol Test: Slope Not Met		No
Interferent Detect Test: Interferent Detect		No
Diagnostic Check (Post-Inspection): OK		No

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:_____ Exp:_____	0.08g/210L Test (g/210L) Lot#:_____ Exp:_____	0.20g/210L Test (g/210L) Lot#:_____ Exp:_____	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:_____ Exp:_____

Number of Simulators Used: _____

Remarks:

BYPASS AI TO OPERATE INSTRUMENT. COMPLIANCE NOT DETERMINED.

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I hold a valid Florida Department of Law Enforcement Agency Inspector Permit and that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



WEN-CHI K PIERSON

Signature and Printed Name

08/06/2026
Date

Stability Checks

0.05g/210L 0.047 to 0.053	0.08g/210L 0.077 to 0.083	0.20g/210L 0.194 to 0.206	DGS 0.08g/210L 0.077 to 0.083 ≤ 0.003 of Wet																																																																																																																																																												
BLOUNTSTOWN PD Intoxilyzer - Alcohol Analyzer Model: 8000 SN 80-000862 08/06/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>09:54</td></tr> <tr><td>Control Test</td><td>0.050</td><td>09:54</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>09:55</td></tr> <tr><td>Control Test</td><td>0.050</td><td>09:56</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>09:56</td></tr> <tr><td>Control Test</td><td>0.050</td><td>09:57</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>09:57</td></tr> <tr><td>Control Test</td><td>0.050</td><td>09:57</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0500</td><td></td></tr> <tr><td>Std Dev</td><td>0.0000</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.0000</td><td></td></tr> </tbody> </table> <i>menp</i> Operator's Signature	Test	g/210L	Time	Air Blank	0.000	09:54	Control Test	0.050	09:54	Air Blank	0.000	09:55	Control Test	0.050	09:56	Air Blank	0.000	09:56	Control Test	0.050	09:57	Air Blank	0.000	09:57	Control Test	0.050	09:57	Control Test Stats			Average	0.0500		Std Dev	0.0000		Rel Std Dev(%)	0.0000		BLOUNTSTOWN PD Intoxilyzer - Alcohol Analyzer Model: 8000 SN 80-000862 08/06/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>10:01</td></tr> <tr><td>Control Test</td><td>0.078</td><td>10:02</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:03</td></tr> <tr><td>Control Test</td><td>0.079</td><td>10:03</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:04</td></tr> <tr><td>Control Test</td><td>0.078</td><td>10:05</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:05</td></tr> <tr><td>Control Test</td><td>0.078</td><td>10:05</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0783</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.7370</td><td></td></tr> </tbody> </table> <i>menp</i> Operator's Signature	Test	g/210L	Time	Air Blank	0.000	10:01	Control Test	0.078	10:02	Air Blank	0.000	10:03	Control Test	0.079	10:03	Air Blank	0.000	10:04	Control Test	0.078	10:05	Air Blank	0.000	10:05	Control Test	0.078	10:05	Control Test Stats			Average	0.0783		Std Dev	0.0006		Rel Std Dev(%)	0.7370		BLOUNTSTOWN PD Intoxilyzer - Alcohol Analyzer Model: 8000 SN 80-000862 08/06/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>10:14</td></tr> <tr><td>Control Test</td><td>0.201</td><td>10:15</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:15</td></tr> <tr><td>Control Test</td><td>0.199</td><td>10:16</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:17</td></tr> <tr><td>Control Test</td><td>0.199</td><td>10:17</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>10:18</td></tr> <tr><td>Control Test</td><td>0.000</td><td>10:18</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.1997</td><td></td></tr> <tr><td>Std Dev</td><td>0.0012</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.5783</td><td></td></tr> </tbody> </table> <i>menp</i> Operator's Signature	Test	g/210L	Time	Air Blank	0.000	10:14	Control Test	0.201	10:15	Air Blank	0.000	10:15	Control Test	0.199	10:16	Air Blank	0.000	10:17	Control Test	0.199	10:17	Air Blank	0.000	10:18	Control Test	0.000	10:18	Control Test Stats			Average	0.1997		Std Dev	0.0012		Rel Std Dev(%)	0.5783		BLOUNTSTOWN PD Intoxilyzer - Alcohol Analyzer Model: 8000 SN 80-000862 08/06/2026 Software: 8100.27 <table border="1"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.000</td><td>09:45</td></tr> <tr><td>Control Test</td><td>0.080</td><td>09:45</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>09:46</td></tr> <tr><td>Control Test</td><td>0.081</td><td>09:46</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>09:47</td></tr> <tr><td>Control Test</td><td>0.081</td><td>09:47</td></tr> <tr><td>Air Blank</td><td>0.000</td><td>09:47</td></tr> <tr><td>Control Test</td><td>0.000</td><td>09:47</td></tr> <tr><td>Control Test Stats</td><td></td><td></td></tr> <tr><td>Average</td><td>0.0807</td><td></td></tr> <tr><td>Std Dev</td><td>0.0006</td><td></td></tr> <tr><td>Rel Std Dev(%)</td><td>0.7157</td><td></td></tr> </tbody> </table> <i>menp</i> Operator's Signature	Test	g/210L	Time	Air Blank	0.000	09:45	Control Test	0.080	09:45	Air Blank	0.000	09:46	Control Test	0.081	09:46	Air Blank	0.000	09:47	Control Test	0.081	09:47	Air Blank	0.000	09:47	Control Test	0.000	09:47	Control Test Stats			Average	0.0807		Std Dev	0.0006		Rel Std Dev(%)	0.7157	
Test	g/210L	Time																																																																																																																																																													
Air Blank	0.000	09:54																																																																																																																																																													
Control Test	0.050	09:54																																																																																																																																																													
Air Blank	0.000	09:55																																																																																																																																																													
Control Test	0.050	09:56																																																																																																																																																													
Air Blank	0.000	09:56																																																																																																																																																													
Control Test	0.050	09:57																																																																																																																																																													
Air Blank	0.000	09:57																																																																																																																																																													
Control Test	0.050	09:57																																																																																																																																																													
Control Test Stats																																																																																																																																																															
Average	0.0500																																																																																																																																																														
Std Dev	0.0000																																																																																																																																																														
Rel Std Dev(%)	0.0000																																																																																																																																																														
Test	g/210L	Time																																																																																																																																																													
Air Blank	0.000	10:01																																																																																																																																																													
Control Test	0.078	10:02																																																																																																																																																													
Air Blank	0.000	10:03																																																																																																																																																													
Control Test	0.079	10:03																																																																																																																																																													
Air Blank	0.000	10:04																																																																																																																																																													
Control Test	0.078	10:05																																																																																																																																																													
Air Blank	0.000	10:05																																																																																																																																																													
Control Test	0.078	10:05																																																																																																																																																													
Control Test Stats																																																																																																																																																															
Average	0.0783																																																																																																																																																														
Std Dev	0.0006																																																																																																																																																														
Rel Std Dev(%)	0.7370																																																																																																																																																														
Test	g/210L	Time																																																																																																																																																													
Air Blank	0.000	10:14																																																																																																																																																													
Control Test	0.201	10:15																																																																																																																																																													
Air Blank	0.000	10:15																																																																																																																																																													
Control Test	0.199	10:16																																																																																																																																																													
Air Blank	0.000	10:17																																																																																																																																																													
Control Test	0.199	10:17																																																																																																																																																													
Air Blank	0.000	10:18																																																																																																																																																													
Control Test	0.000	10:18																																																																																																																																																													
Control Test Stats																																																																																																																																																															
Average	0.1997																																																																																																																																																														
Std Dev	0.0012																																																																																																																																																														
Rel Std Dev(%)	0.5783																																																																																																																																																														
Test	g/210L	Time																																																																																																																																																													
Air Blank	0.000	09:45																																																																																																																																																													
Control Test	0.080	09:45																																																																																																																																																													
Air Blank	0.000	09:46																																																																																																																																																													
Control Test	0.081	09:46																																																																																																																																																													
Air Blank	0.000	09:47																																																																																																																																																													
Control Test	0.081	09:47																																																																																																																																																													
Air Blank	0.000	09:47																																																																																																																																																													
Control Test	0.000	09:47																																																																																																																																																													
Control Test Stats																																																																																																																																																															
Average	0.0807																																																																																																																																																														
Std Dev	0.0006																																																																																																																																																														
Rel Std Dev(%)	0.7157																																																																																																																																																														

Florida Department of Law Enforcement Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: BLOUNTSTOWN PD
Time of Inspection: 13:43

Date of Inspection: 08/06/2026

Serial Number: 80-000862
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202603A Exp: 03/03/2028	0.08g/210L Test (g/210L) Lot#:202603B Exp: 03/03/2028	0.20g/210L Test (g/210L) Lot#:202603D Exp: 03/04/2028	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:23725080A1 Exp: 10/05/2027
0.000	0.049	0.078	0.199	0.079
0.000	0.049	0.078	0.199	0.080
0.000	0.049	0.078	0.199	0.079
0.000	0.049	0.078	0.199	0.079
0.000	0.049	0.078	0.200	0.080
0.000	0.049	0.078	0.200	0.080
0.000	0.049	0.078	0.199	0.080
0.000	0.049	0.079	0.199	0.079
0.000	0.049	0.077	0.200	0.080
0.000	0.049	0.078	0.200	0.080

Standard Deviations	0.0000	0.0004	0.0005	0.0005
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0003 Number of Simulators Used: 5

Remarks:

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.



WEN-CHI K. PIERSON

Signature and Printed Name

08/06/2026
Date

Florida Department of Law Enforcement
Alcohol Testing Program - Average Calculations for Calibration Certificate

Calculations By: WKP

Serial Number: 80-000862

Date: 8/7/2026

Solution:

0.05 g/210 L Test: 0.490 / 10 = 0.049 g/210L
(SUM) (AVERAGE)

0.08 g/210L Test: 0.780 / 10 = 0.078 g/210L
(SUM) (AVERAGE)

0.20 g/210L Test: 1.994 / 10 = 0.199 g/210L
(SUM) (AVERAGE)

0.08 g/210L Dry Gas Std Test: 0.796 / 10 = 0.080 g/210L
(SUM) (AVERAGE)

Comments:

Average = (Sum of observations) / (Total number of observations)

All results are reported in g/210L



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000862, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000862</u>	Average of $y \pm$ Uncertainty*
Owning Agency:	<u>BLOUNTSTOWN PD</u>	0.049 g/ 210 L 0.004
Calibration Date:	<u>08/06/2026</u>	0.078 g/ 210 L 0.004
Calibration Time:	<u>13:43</u>	0.199 g/ 210 L 0.008
		0.080 g/ 210 L Dry Gas Control 0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

08/06/2026

Date

Wen-Chi
Pierson

Digitally signed by Wen-Chi Pierson
Date: 2026.08.07 08:36:45
-04'00'

WEN-CHI K PIERSON,
Department Inspector

FDLE/ATP Form 69 August 2026

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality

Page 1 of 1

Alcohol Testing Program - Instrument Processing Sheet

Agency: BLOUNTSTOWN PD

Instrument Serial Number: 80-000862

Date In: 4/28/2026

DI Completion Date: 5/5/2026

* ☒ Ship * ☒ P/U ☐ H/D ☐ CMI ☐ EE

Intake By: <u>WKP</u> Date: <u>4/28/2026</u>		Quality Checks By: <u>IAS</u> Date: <u>5/1/2026</u>		Flow Adjustment By: _____																																										
☒ Annual ☒ Dropped Off ☐ Registration ☐ Return from CMI / EE ☐ Training Instrument Visual Inspection ☒ Case ☒ Handle ☒ Keyboard ☒ Dry Gas Shelf ☒ Feet ☒ Breath Tube ☒ Ports ☒ Screws Tight Other Equipment/Accessories ☐ Power Cord ☐ Printer Cable ☐ Static Bag ☐ 12V DC Cable Notes:		☒ Breath Tube Screen ☒ Replace External O-Rings ☒ Instrument Set Up Verified ☒ R-Value: <u>146</u> ☒ Flow Verification (L/s) Flow Column #: <u>ATP102</u> 32 mm <u>.148</u> (.139-.169) 36 mm <u>.164</u> (.156-.190) 53 mm <u>.234</u> (.228-.278) 103 mm <u>.503</u> (.447-.547) ☒ Barometric Pressure Check Gauge ID #: <u>34419</u> Gauge: <u>1010</u> Instrument: <u>1005</u> ☒ Stability Checks		Flow Column #: _____ ☐ 5L/min – 17mm ☐ 15L/min – 53mm ☐ 30L/min – 103mm ☐ R-Value: _____ ☐ Post Adjustment Verification (L/S) Flow Column #: _____ 32 mm _____ (.139-.169) 36 mm _____ (.156-.190) 53 mm _____ (.228-.278) 103 mm _____ (.447-.547)																																										
						<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Simulator</th> <th style="width: 20%;">Serial #</th> <th style="width: 25%;">Lot#/Exp</th> <th style="width: 40%;">Maintenance By: _____ Date: _____</th> </tr> </thead> <tbody> <tr> <td rowspan="2">0.050</td> <td rowspan="2">MP5088</td> <td>202603A</td> <td>☐ Battery Replacement</td> </tr> <tr> <td>3/3/2028</td> <td>☐ Dry Gas Regulator Replacement</td> </tr> <tr> <td rowspan="2">0.080</td> <td rowspan="2">MP5089</td> <td>202603B</td> <td>☐ Tank Sensor Tare</td> </tr> <tr> <td>3/3/2028</td> <td>☐ Breath Tube Replacement</td> </tr> <tr> <td rowspan="2">0.200</td> <td rowspan="2">MP5090</td> <td>202603D</td> <td>☐ Other:</td> </tr> <tr> <td>3/4/2028</td> <td></td> </tr> <tr> <td rowspan="2">0.080 DGS</td> <td rowspan="2">N/A</td> <td>23825080A1</td> <td></td> </tr> <tr> <td>10/5/2027</td> <td></td> </tr> </tbody> </table>		Simulator	Serial #	Lot#/Exp	Maintenance By: _____ Date: _____	0.050	MP5088	202603A	☐ Battery Replacement	3/3/2028	☐ Dry Gas Regulator Replacement	0.080	MP5089	202603B	☐ Tank Sensor Tare	3/3/2028	☐ Breath Tube Replacement	0.200	MP5090	202603D	☐ Other:	3/4/2028		0.080 DGS	N/A	23825080A1		10/5/2027												
						Simulator	Serial #	Lot#/Exp	Maintenance By: _____ Date: _____																																					
						0.050	MP5088	202603A	☐ Battery Replacement																																					
								3/3/2028	☐ Dry Gas Regulator Replacement																																					
0.080	MP5089	202603B	☐ Tank Sensor Tare																																											
		3/3/2028	☐ Breath Tube Replacement																																											
0.200	MP5090	202603D	☐ Other:																																											
		3/4/2028																																												
0.080 DGS	N/A	23825080A1																																												
		10/5/2027																																												
Optical Bench Adjustment By: _____ Department Inspection By: <u>KTS</u> Barometric Pressure Gauge: _____ ID#: _____ Barometric Pressure ID#: <u>28427</u> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Simulator</th> <th style="width: 15%;">Serial #</th> <th style="width: 15%;">Lot #</th> <th style="width: 15%;">Expiration</th> <th style="width: 40%;">Gauge: <u>1010</u> Instrument: <u>1008</u></th> </tr> </thead> <tbody> <tr> <td>0.000</td> <td></td> <td>N/A</td> <td>N/A</td> <td>Mouth Alcohol Solution Lot #: <u>2025-D</u> Exp: <u>9/25/2027</u></td> </tr> <tr> <td>0.040</td> <td></td> <td></td> <td></td> <td>Acetone Stock Solution Lot #: <u>2025-B</u> Exp: <u>9/22/2027</u></td> </tr> <tr> <td>0.100</td> <td></td> <td></td> <td></td> <td>Simulator Serial Number</td> </tr> <tr> <td>0.200</td> <td></td> <td></td> <td></td> <td>0.000 MP6289</td> </tr> <tr> <td>0.300</td> <td></td> <td></td> <td></td> <td>Interferent MP6290</td> </tr> <tr> <td>0.080 DGS</td> <td>N/A</td> <td></td> <td></td> <td>0.050 MP6291</td> </tr> <tr> <td colspan="4">☐ Post Optical Bench Adjustment Stability Checks</td> <td>0.080 MP6292</td> </tr> <tr> <td>0.050</td> <td></td> <td></td> <td></td> <td>0.200 MP6293</td> </tr> </tbody> </table>		Simulator	Serial #	Lot #	Expiration	Gauge: <u>1010</u> Instrument: <u>1008</u>	0.000		N/A	N/A	Mouth Alcohol Solution Lot #: <u>2025-D</u> Exp: <u>9/25/2027</u>	0.040				Acetone Stock Solution Lot #: <u>2025-B</u> Exp: <u>9/22/2027</u>	0.100				Simulator Serial Number	0.200				0.000 MP6289	0.300				Interferent MP6290	0.080 DGS	N/A			0.050 MP6291	☐ Post Optical Bench Adjustment Stability Checks				0.080 MP6292	0.050				0.200 MP6293
Simulator	Serial #	Lot #	Expiration	Gauge: <u>1010</u> Instrument: <u>1008</u>																																										
0.000		N/A	N/A	Mouth Alcohol Solution Lot #: <u>2025-D</u> Exp: <u>9/25/2027</u>																																										
0.040				Acetone Stock Solution Lot #: <u>2025-B</u> Exp: <u>9/22/2027</u>																																										
0.100				Simulator Serial Number																																										
0.200				0.000 MP6289																																										
0.300				Interferent MP6290																																										
0.080 DGS	N/A			0.050 MP6291																																										
☐ Post Optical Bench Adjustment Stability Checks				0.080 MP6292																																										
0.050				0.200 MP6293																																										
Gauge ID #: _____ Gauge: _____ Instrument: _____		Attachments ☒ Form 41 ☒ Stability Checks ☒ Calibration Certificate ☐ Optical Bench Adjustment		☐ Post-Stability Checks ☐ Flow Adjustment ☐ Form 40 ☐ Other:																																										
Notes/Suggested Service: Tech Review: Added remarks comment on Form 41. KTS 5/12/26 *Admin Review: Corrected return method. WKP 5/15/2026		☒ Instrument Complies with Chapter 11D-8, FAC ☐ Instrument Does Not Comply with Chapter 11D-8, FAC ☒ Return to/Place into Evidentiary Use ☐ Remain Out of Evidentiary Use ☒ Conduct an Agency Inspection Before Evidentiary Use																																												
		<table border="0" style="width: 100%;"> <tr> <td style="width: 50%; vertical-align: top;"> Taylor Gutschow Digitally signed by Taylor Gutschow Date: 2026.05.13 14:02:00 -04'00' </td> <td style="width: 50%; vertical-align: top;"> LeAndra Higginbotham Digitally signed by LeAndra Higginbotham Date: 2026.05.15 10:42:30 -04'00' </td> </tr> </table>				Taylor Gutschow Digitally signed by Taylor Gutschow Date: 2026.05.13 14:02:00 -04'00'	LeAndra Higginbotham Digitally signed by LeAndra Higginbotham Date: 2026.05.15 10:42:30 -04'00'																																							
		Taylor Gutschow Digitally signed by Taylor Gutschow Date: 2026.05.13 14:02:00 -04'00'	LeAndra Higginbotham Digitally signed by LeAndra Higginbotham Date: 2026.05.15 10:42:30 -04'00'																																											
Tech Review Admin Review																																														

Stability Checks

0.050 g/210L	0.080 g/210L	0.200 g/210L	DGS 0.080 g/210L
0.047 to 0.053 g/210L	0.077 to 0.083 g/210L	0.194 to 0.206 g/210L	0.077 to 0.083 g/210L
BLOUNTSTOWN PD Intoxilyzer - Alcohol Analyzer Model: 8000 05/01/2026 Software: 8100.27 Test 9/210L Time Air Blank 0.000 13:17 Control Test 0.049 13:18 Air Blank 0.000 13:18 Control Test 0.049 13:19 Air Blank 0.000 13:20 Control Test 0.049 13:20 Air Blank 0.000 13:21 Control Test Stats Average 0.0490 Std Dev 0.0000 Rel Std Dev(%) 0.0000	BLOUNTSTOWN PD Intoxilyzer - Alcohol Analyzer Model: 8000 05/01/2026 Software: 8100.27 Test 9/210L Time Air Blank 0.000 13:09 Control Test 0.078 13:10 Air Blank 0.000 13:11 Control Test 0.078 13:12 Air Blank 0.000 13:13 Control Test 0.078 13:13 Control Test Stats Average 0.0780 Std Dev 0.0000 Rel Std Dev(%) 0.0000	BLOUNTSTOWN PD Intoxilyzer - Alcohol Analyzer Model: 8000 05/01/2026 Software: 8100.27 Test 9/210L Time Air Blank 0.000 14:07 Control Test 0.201 14:08 Air Blank 0.000 14:09 Control Test 0.199 14:09 Air Blank 0.000 14:10 Control Test 0.197 14:11 Air Blank 0.000 14:11 Control Test Stats Average 0.1990 Std Dev 0.0020 Rel Std Dev(%) 0.0050	BLOUNTSTOWN PD Intoxilyzer - Alcohol Analyzer Model: 8000 05/01/2026 Software: 8100.27 Test 9/210L Time Air Blank 0.000 14:14 Control Test 0.080 14:15 Air Blank 0.000 14:15 Control Test 0.080 14:16 Air Blank 0.000 14:16 Control Test 0.080 14:16 Air Blank 0.000 14:17 Control Test Stats Average 0.0810 Std Dev 0.0000 Rel Std Dev(%) 0.0000
<i>Lucretia L. Luykstra</i> Operator's Signature	<i>Lucretia L. Luykstra</i> Operator's Signature	<i>Lucretia L. Luykstra</i> Operator's Signature	<i>Lucretia L. Luykstra</i> Operator's Signature

Florida Department of Law Enforcement

Alcohol Testing Program

DEPARTMENT INSPECTION REPORT - INTOXILYZER 8000

Agency: BLOUNTSTOWN PD
Time of Inspection: 08:54

Date of Inspection: 05/05/2026

Serial Number: 80-000862
Software: 8100.27

Check or Test	YES	NO	Check or Test	YES	NO
Diagnostic Check (Pre-Inspection): OK	Yes		Date and/or Time Adjusted		No
Minimum Sample Volume Check: OK	Yes		Barometric Pressure Sensor Check: OK	Yes	
Alcohol Free Subject Test: 0.000	Yes		Mouth Alcohol Test: Slope Not Met	Yes	
Interferent Detect Test: Interferent Detect	Yes		Diagnostic Check (Post-Inspection): OK	Yes	

Alcohol Free Test (g/210L)	0.05g/210L Test (g/210L) Lot#:202603A Exp: 03/03/2028	0.08g/210L Test (g/210L) Lot#:202603B Exp: 03/03/2028	0.20g/210L Test (g/210L) Lot#:202603D Exp: 03/04/2028	0.08 g/210L Dry Gas Std Test (g/210L) Lot#:23825080A1 Exp: 10/05/2027
0.000	0.050	0.079	0.201	0.081
0.000	0.050	0.079	0.202	0.081
0.000	0.050	0.079	0.202	0.081
0.000	0.050	0.079	0.202	0.082
0.000	0.050	0.079	0.202	0.081
0.000	0.050	0.079	0.202	0.081
0.000	0.050	0.079	0.202	0.081
0.000	0.050	0.079	0.202	0.081
0.000	0.050	0.080	0.202	0.081
0.000	0.051	0.079	0.202	0.081

Standard Deviations	0.0003	0.0003	0.0003	0.0003
---------------------	--------	--------	--------	--------

Average Standard Deviation of 0.05, 0.08 and 0.20 g/210L Tests: 0.0003 Number of Simulators Used: 5


Remarks:

A F / M A: No Sample Provided.

Test timed out before sample was provided. Repeated test and provided sample in allowable time. KTS 5/12/26

The above instrument complies (☒) does not comply (☐) with Chapter 11D-8, FAC.

I certify that I performed this inspection in accordance with the provisions of Chapter 11D-8, FAC.

 KATIE T SPEARIN
Signature and Printed Name

05/05/2026
Date



Calibration Certificate

Florida Department of Law Enforcement
Alcohol Testing Program
2331 Phillips Road
Tallahassee, FL 32308

This is to certify the calibration of Intoxilyzer 8000 serial number 80-000862, manufactured by CMI, Inc. was calibrated in accordance with FDLE/ATP Form 36 - Department Inspection Procedures - Intoxilyzer 8000.

Serial Number:	<u>80-000862</u>	UNCERTAINTY* $\pm$	
Owning Agency:	<u>BLOUNTSTOWN PD</u>	0.050 g/ 210 L	0.004
Calibration Date:	<u>05/05/2026</u>	0.080 g/ 210 L	0.004
Calibration Time:	<u>08:54</u>	0.200 g/ 210 L	0.008
		0.080 g/ 210 L Dry Gas Control	0.005

All results are reported in g/ 210 L.

Bias is limited by calibration acceptance criteria. All calibration results must be within ± 0.005 or 5%, whichever is greater, of the target alcohol concentration.

*Uncertainty is based on fleet-wide data and is expressed to a 99.73% level of confidence ($k=3$).

The instrument results before and after any adjustment are found in the associated pre and post stability checks.

TRACEABILITY INFORMATION

This instrument was calibrated using solutions prepared by Alcohol Countermeasure Systems, Inc. (ACS). ACS prepared and certified these CRMs in accordance with ISO 17034 and ISO/ IEC 17025 Standards.

Simulator temperatures are traceable to NIST. Simulator temperatures are checked with NIST traceable digital thermometers calibrated by Precision Metrology in accordance with ISO/ IEC 17025 standards.

Dry gas control measurements are traceable to NIST through the use of CRMs supplied by an accredited CRM supplier. The supplier of dry gas standard controls prepared and certified the CRMs in accordance with ISO Guide 34 and ISO/ IEC 17025 standards.

This document shall not be reproduced except in full, without written approval of the Florida Department of Law Enforcement Alcohol Testing Program.

05/05/2026

Date

KATIE T SPEARIN,

Department Inspector

FDLE/ATP Form 69 January 2026

Issuing Authority: Alcohol Testing Program

Service • Integrity • Respect • Quality